

BUTTONS

LOS ANGELES

PACKAGE CONTENTS



BUTTONS CLIP PRO
OPEN-EAR EARPHONES
(2 PIECES)



BUTTONS CLIP PRO
DEDICATED PORTABLE
CHARGING CASE



USB
CHARGING
CABLE



PRODUCT MANUAL &
WARRANTY CARD




STORAGE
POUCH



EAR CAP

Important Notice: Do not use the Product if any parts are missing or damaged. For troubleshooting articles, videos, and product repair or replacement information, please visit the BUTTONS official website at www.buttonsaair.com. Contact our customer service at service@buttonsaair.com (Global).

DOWNLOAD THE OFFICIAL BUTTONS EARPHONES APP




1. Scan the QR code below with your smartphone camera to download the BUTTONS APP, and follow the on-screen instructions to complete installation.

2. Alternatively, users can search for the APP in their phone's app store and follow the installation prompts.

Note: For the best app experience, your device should meet these minimum requirements:

Android platform	iOS platform
Operating system: Android 9.0 or later; SoC: Qualcomm Snapdragon 660 equivalent or better; RAM: 4 GB or more;	Operating system: iOS 15.0 or later; SoC: A12 or better; RAM: 3 GB or more;

3. After installation, you can use it according to the interface prompts of the APP software, or click the ☰ button in the upper right corner of the default page (Figure A) to quickly access the APP user guide.



4. About BUTTONS APP Features: Once you've downloaded and installed the BUTTONS APP and paired your phone with BUTTONS CLIP PRO earphones via Bluetooth, the APP will automatically bind with the earphones. The APP allows you to monitor battery levels, function status, and other basic information for better device management.

After registering and logging in as a new user, you'll unlock additional features including, including EQ sound effects selection, smart AI interaction, AI translation, and more exciting features waiting for you to explore (learn more about these features through the instructions button after installing the APP).


BUTTONS AND LED INDICATOR GUIDE

BATTERY LEVEL DISPLAY

-  >40%
-  15%-40%
-  5%-15%

CHARGING STATUS

-  Charging
-  Fully charged
-  Charging error



Battery check



Pairing mode



Factory reset



 White light solid

 Green light solid

 Red light flashing

 White light flashing

 Red light solid


 Light off

POWER ON & POWER OFF

ON

Earphones automatically power on when the charging case lid is opened;



Note: When using for the first time, please remove the insulating protective film on the metal contacts of the left and right earphones to ensure normal charging.



OFF

Earphones power off when placed in the charging case and the lid is closed to begin charging.

Note: When returning earphones to the case, ensure the speaker portion faces the outer sides of the case.



PROPER WEARING INSTRUCTIONS

This is an open-ear design that doesn't require insertion into the ear canal. The earphones are reversible and automatically detect wearing orientation. Please refer to the diagram on the right for product area names.

Ear clip

C-bridge

Loudspeaker



EARPHONE CONTROLS




MUSIC



VOICE



BLUETOOTH PAIRING



Enable Bluetooth on your phone, find "BUTTONS CLIP PRO" in the Bluetooth device list and tap to connect. When prompted to "Authorize Bluetooth pairing request", tap "Pair". Voice prompt "Connected" indicates successful pairing. Voice prompt "Disconnected" indicates connection loss. After initial pairing, the earphones will automatically connect when the case is opened.

BUTTONS CLIP PRO EAR CAP INSTALLATION GUIDE


① IDENTIFY ORIENTATION

A1 at the top right
(dot facing upward)
A2 on the bottom left,
A3 on the bottom right



② ALIGN AND INSERT

Align A3 with the top of the earbud.
Then wrap A2 downward around the earbud
and gently rotate to secure into place.



④ INSTALLATION COMPLETE

To remove, gently lift the ear cap
and detach it outward from the
earbud.



③ ADJUST FIT

Ensure the ear cap fits snugly and remains
securely in place without shifting.



Note:

- Avoid excessive pulling during installation to prevent damage to the ear cap, make sure the ear cap is fully fitted to ensure stability and optimal audio performance.
- If the ear cap becomes dirty, rinse gently with clean water and allow it to air dry before reuse.

CHARGING INSRUCTIONS

Charging the Case:

Charging: LED breathes/pulses

Fully Charged: LED stay solid

Charging Error: Red LED flashes quickly for 5s, then turns off

Charging the Earphones:

Place earphones in the charging case - a white light flash indicates proper contact with charging pins.

Close the lid to begin charging automatically.


Low Battery: Voice prompt "Battery Low".

Charging Status: After placing earphones in case and closing lid, breathing LED indicates charging.

Fully Charged: LED indicator turns off.

Note: These light indicators apply only when charging the case separately. When opening the case lid: Green LED indicates low case battery, charging needed; Red LED indicates critically low case battery, charge immediately.

Please use a standard 5V-1A charger. Using chargers outside these specifications may damage the device.




- | | |
|--------------------|----------------------|
| ● Needs Charging | ⦿ Currently Charging |
| ● Battery Depleted | ○ Fully Charged |
| ⦿ Charging Error | ● LED Off |

WEARING DETECTION AND SLEEP MODE

Wearing Detection:

During music playback, removing one or both earphones automatically pauses music. playback resumes automatically when earphones are worn again. During phone calls, removing both earphones automatically switches audio to phone speaker. Audio returns to earphones when either or both earphones are worn again.

Note: Tap controls are disabled when earphones are detected as not being worn. For double and triple taps, use your index fingertip to tap the cover. First-time users may need practice to master the operation. Taps that are too hard/soft or too fast/slow may fail to trigger the controls.



Sleep Mode:

Entering Sleep Mode: Earphones automatically enter sleep mode after a period when: unable to pair with Bluetooth device; removed from ears and not in use; out of Bluetooth range.

Exiting Sleep Mode: Place earphones back in charging case, open and close the lid once, then remove them to exit sleep mode.



SAFETY GUIDELINES

Input: DC 5V=500mA

Output: DC 5V=280mA

Bluetooth Operating Frequency & Transmission Power: 2402MHz-2480MHz, <11dBm

Package Contents:BUTTONS CLIP PRO earphones x2 BUTTONS CLIP PRO portable charging case x1 USB Type-A to Type-C charging cable x1 Product manual x1 Storage pouch x1 Ear Cap x4

Declaration: Contains safety information.

Declaration: Contains a lithium-ion battery. The battery must be properly recycled or disposed of.

Warning: To avoid hearing damage, do not listen at high volume for extended periods.

Warning: Device contains magnets.

Warning: Choking hazard. This product contains small parts.

Warning: The symbol indicates that this product must not be disposed of with household waste. It should be taken to an appropriate collection facility for recycling. Proper disposal and recycling

help protect natural resources, human health, and the environment. For more information on disposal and recycling, please contact your local authorities or the retailer where you purchased this product.



Compliance and Warranty:

EU Compliance Declaration

Beijing Techao Weijia Electronic Science & Technology Co., Ltd. hereby declares that this radio equipment complies with the EU Directive 2014/53/EU. The full text of the EU compliance declaration can be found at www.buttonsair.com

Made for

iPhone | iPad

Control	Tapping
Speaker	Φ12mm dual magnetic horn
Frequency response range	20-20KHz
Impedance	160hm
Call microphone	2mic+VPU
Radio frequency communication range	15m
Waterproofing grade	IP54
Earphones battery	45mAh*2
Charging case battery	480mAh
Bluetooth version	5.4
Weight	Approx. 6.6g (per earbud), 97.4g (2 earbuds + charging case)
Warranty period	1 year

Product Name: BUTTONS CLIP PRO
Product Type: Ear-Clip True Wireless Bluetooth Earbuds
Product Model: CLIPBTN20
Charging Voltage/Current: 5V=1A
FCC ID: 2A83I-CLIPBTN20
Made in China

Manufacturer: Beijing Techao Weijia Electronic Science & Technology Co., Ltd.
Address: Address: Room 2107, 2nd Floor Building 8, No.1 Courtyard, Shuangqiao Middle Road, Chaoyang District, Beijing

(1) FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Cleaning Instructions for Black Leather:

This product is made with high-quality leather. To ensure it stays in excellent condition and maintains its aesthetic appeal over time, please follow these cleaning guidelines:

Never use cleaning agents that contain alcohol, bleach, or other harsh chemicals. Such substances can cause the leather to fade, crack, or become damaged, which would affect the product's overall feel and longevity.

We recommend using a clean, soft cloth to gently wipe the surface, effectively removing dust and stains, and keeping the leather looking fresh and polished.

COMPATIBLE WITH:

iPhone 17e, iPhone 17 Pro Max, iPhone 17 Pro, iPhone Air, iPhone 17, iPhone 16e, iPhone 16 ProMax, iPhone 16 Pro, iPhone 16 Plus, iPhone 16, iPhone 15 Pro Max, iPhone 15 Pro, iPhone 15Plus, iPhone 15, iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone SE (3rd generation), iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPad Air 13-inch (M4), iPad Air 11-inch (M4), iPad Pro 13-inch (M5), iPad Pro 11-inch (M5), iPad Air 13-inch (M3), iPad Air 11-inch (M3), iPad (A16), iPad mini (A17 Pro), iPad Pro 13-inch (M4), iPad Pro 11-inch (M4), iPad Air 13-inch (M2), iPad Air 11-inch (M2), iPad Pro 12.9-inch (6th generation), iPad Pro 11-inch (4th generation), iPad (10th generation), iPad Air (5th generation), iPad (9th generation), iPad mini (6th generation), iPad Pro 12.9-inch (5th generation), iPad Pro 11-inch (3rd generation), iPad (8th generation), iPad Air (4th generation), iPad Pro 11-inch (2nd generation), iPad Pro 12.9-inch (4th generation)

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Apple, Apple TV, Apple Watch, iPad, iPad Air, iPad Pro, iPhone, Lightning, and tvOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

Apple, Apple TV, Apple Watch, iPad, iPad Air, iPad Pro, iPhone, Lightning, and tvOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The trademark "iPhone" is used in Japan with a license from Aiphone K.K.

ABOUT THE WARRANTY

BUTTONS Limited Warranty

Important Notice: By using your BUTTONS earphones (the "Product"), you agree to the terms of this BUTTONS Limited Warranty (the "Warranty"). If you do not agree to these terms, please refrain from using the Product and return it within the return period specified in BUTTONS' return policy.

Who is Covered by this Warranty?

This limited warranty is available only to end users (the "End Users") who have purchased the Product from BUTTONS-authorized dealers in their respective region or country.

Limited Warranty:

Subject to the terms and conditions of this warranty, BUTTONS offers a one (1) year warranty period starting from the date of the original retail purchase by the End User (the "Warranty Period"). This warranty ensures that the Product will be free from material defects in design, materials, and workmanship under normal and customary consumer use, and in accordance with any BUTTONS-written guidelines, specifications, or instructions (including environmental and storage requirements). Any non-conforming products must be reported to BUTTONS, accompanied by documentation and supporting information reasonably required by BUTTONS to verify, diagnose, and correct the non-conformity.

Warranty Conditions and Exclusions:

This warranty is valid only if: (i) the original receipt from a BUTTONS-authorized dealer, showing the purchase date and serial number, is submitted along with the Product for repair or replacement; (ii) the warranty seals and serial numbers on the Product have not been tampered with, removed, or defaced; and (iii) the Product has not been modified, altered, damaged, misused, or neglected by the End User or any other party in any way.

This warranty does not cover: (a) Consumable parts, such as batteries, that are designed to wear out over time, unless the failure is due to a defect in materials or workmanship; (b) Cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports, as well as normal wear and tear resulting from ordinary aging of the device; (c) Damage caused by using the Product with third-party devices or products not provided or recommended by BUTTONS.

ABOUT THE WARRANTY

Warranty Service Instructions

If, after appropriate inspection, BUTTONS determines that the Product does not conform to this warranty during the Warranty Period, BUTTONS or its authorized service provider will, at its sole discretion, repair or replace the Product in accordance with these terms.

This warranty provision represents the End User's sole and exclusive remedy for any warranty claims regarding the Product and constitutes BUTTONS' entire liability and obligation under the warranty.

If BUTTONS or its authorized service provider repairs or replaces the Product (the repaired or replaced product hereinafter referred to as the "Replacement"), the Replacement will be covered by the warranty for the remainder of the original Warranty Period or for ninety (90) days from the date of repair or replacement, whichever is longer. Repairs or replacements may involve the use of functionally equivalent reconditioned, previously installed, or refurbished parts or components. All replaced parts or components will become the property of BUTTONS.

All warranty returns must be processed through the original sales channel, designated distributor, platform, offline store, or customer service representative, who will assist with forwarding the product to the specified after-sales service center.

Before initiating a warranty return, users must provide BUTTONS or its authorized service provider with the following information:

1. Original purchase receipt, packaging, and accessories
2. Product model, color, and size
3. Serial number
4. Contact information (name and phone number)

The product must be returned with shipping costs prepaid. Any related returns will be sent back at the End User's expense. If BUTTONS determines that the returned product does not meet the warranty terms outlined herein, the End User will also be responsible for the costs incurred by BUTTONS in returning the product to the End User.

This warranty, apart from the aforementioned contents, also covers any other statutory rights and remedies that the End User may have under applicable laws, specifically for products sold to End Users located outside mainland China. To obtain information about any applicable statutory rights or warranty services in such cases, please first contact the dealer from whom the product was purchased or the distributor that provided the product.

包装内包含以下物件



BUTTONS CLIP PRO
耳夹式耳机 (2只)



BUTTONS CLIP PRO
耳机专属便携式充电舱



USB充电线



产品手册及保修卡



包装布袋



耳机帽

注意：如果产品的任何部分缺失或损坏，请勿使用。请访问BUTTONS官网www.buttonsair.com，了解故障排除文章、视频以及产品维修或更换信息。或联系客服邮箱地址[service@buttonsair.com\(Global\)](mailto:service@buttonsair.com(Global))，中国大陆地区用户，也可在工作时间拨打官方售后电话：400-600-8802 (CN)。

下载BUTTONS耳机官方应用软件




1.使用您的智能手机摄像头扫描右方二维码下载BUTTONS APP，并按照手机页面提示完成安装。

2.通常，用户也可尝试从各手机品牌的应用市场搜索该APP，并尝试按照手机页面提示完成下载安装。

注意: 为了更好体验这款APP，您的手机软硬件系统需满足以下要求:

安卓平台	iOS平台
操作系统: Android9.0或更新版本; SOC: Qualcomm Snapdragon 660相当或更高性能; RAM: 4GB或更大容量;	操作系统: iOS15或更新版本; SOC: A12 或更高性能; RAM: 3GB或更大容量;

3.安装后可按照APP软件的界面提示使用，
或可点击默认页面(图A)左上角的  按钮，
点击“使用帮助快速”查阅APP使用指南。



4.关于BUTTONS APP功能简介如果您完成了BUTTONS APP的下载和安装，并让手机与BUTTONS CLIP PRO耳机通过蓝牙设备列表正确配对后，打开BUTTONS APP会自动绑定耳机。配合该APP您可以查看耳机电量、功能状态等基础信息，方便您更好地管理耳机设备。

如果您按BUTTONS APP的页面提示完成新用户注册和登陆，您将可以使用APP的更多功能，包括EQ音效选择、智能AI互动、AI翻译等更多精彩内容 and 科技功能等您探索(安装APP后通过说明按钮，您可学习更多功能的使用方法)。


按键及指示灯说明

电量显示

- >40%
- 15%-40%
- 5%-15%

充电显示

- 正在充电
- 充电完成
- 充电故障



电量



<3s



配对模式



≥3s



恢复出厂设置



≥8s

○ 白灯常亮

● 绿灯常亮

● 红灯闪烁

○ 白灯闪烁

● 红灯常亮


● 指示灯熄灭

开机&关机

ON

耳机在充电盒中，打开充电盒盖，耳机自动开机。

注：首次使用时，请移除左右耳机金属触点上的绝缘保护膜，以确保正常充电。



OFF

耳机放入充电盒中，合上充电盒盖子，耳机断连并开始充电。

注：放回充电盒时，保持带有扬声器的部分，朝向充电盒左右外侧。



正确佩戴耳机

本产品为开放式耳机，无需塞入耳道。耳机不区分左右，可根据佩戴情况自动识别。请根据右图所示了解产品区域名称。

扬声器在前，耳后夹在后，轻掰开C桥，将耳机夹在耳朵上。可上下调整耳机至舒适位置，完成佩戴。

耳后夹

C桥

扬声器



耳机操作



音乐



语音



语音唤醒
HALI

唤醒
"HALI HALI"




通话



X2: 连击两次 X3: 连击三次

配对连接



打开手机蓝牙开关，在蓝牙设备列表中找到“BUTTONS CLIP PRO”并点击连接。

系统弹出“授权蓝牙配对请求”对话框，点击“配对”按钮，耳机语音提示“Connected”，表明耳机连接成功。蓝牙连接断开时，耳机语音提示“Disconnected”。

第一次连接成功后，下一次打开充电盒盖，将会自动开始蓝牙连接。

BUTTONS CLIP PRO耳帽安装示意

①

识别方向


A1右上（圆点朝上）
A2左下、A3右下



②

对齐并套入

把A3对准音筒上方，
再将A2向下包住耳机，
轻轻旋转按入。



③

调整贴合

确保耳套都贴合牢固、不松动。



④

安装完成

如需拆卸，轻轻掀起，
再向外取下耳帽。




注意：·安装时请避免用力拉扯，以免损坏耳帽。请确认耳帽已完全贴合，避免影响佩戴稳定性与声音效果。

·如耳帽沾有污渍，请用清水轻轻冲洗并自然晾干后再使用。

充电

给充电盒充电

正在充电：充电盒LED指示灯呼吸闪烁
充电完成：充电盒LED指示灯长亮
充电故障：充电盒LED指示灯红色快闪
5s后熄灭



给耳机充电

将耳机放入充电盒中，白灯会闪烁一下，表示金属触点接触正常，合上盖子自动为耳机充电。
耳机低电：语音提示：“Battery Low”。
充电状态：打开充电盒，放入耳机，合上充电盒盖子，充电盒LED指示灯呼吸闪，表示耳机处在充电状态。
充电完成：充电盒LED指示灯熄灭。

- | | |
|--|---|
|  需要充电 |  正在充电 |
|  电量耗尽 |  充电完成 |
|  充电故障 |  指示灯熄灭 |

注：上述灯光指示仅适用于单独为充电盒充电时使用；当打开充电盒盖，如LED指示灯显示绿色，则表明充电盒电量低，需要对设备进行充电。当打开充电盒盖，如LED指示灯亮红色，则表明充电盒电量将耗尽，请马上对设备充电。
请使用正规5V-1A充电器为本机充电，超出规格充电器会造成设备损坏。

佩戴检测和休眠模式

佩戴检测


音乐播放过程中，取下一只或两只耳机同时取下后，音乐自动暂停，耳机再次放入耳中后，音乐自动恢复播放。

手机通话过程中，取下两只耳机后，自动切换成手机听筒。

佩戴任意一只或两只耳机后，自动切回耳机端。

注：当检测到耳机未佩戴时，耳机将不支持敲击操作。

双击或三连击操作时，建议您使用食指指尖敲击C桥。首次使用时您需要一些练习以熟练操作，敲击力度过大/过小及速度过快/过慢都可能导致耳机敲击操作无法成功触发。



休眠模式

进入休眠：

耳机如出现无法与蓝牙设备配对、或从耳中取下不用、再或脱离蓝牙范围等情况超过一定时间，则自动进入休眠模式；

退出休眠：

将耳机放回充电盒，开合盖一次，再次取出，耳机退出休眠模式。



安全指南

输入Input: DC 5V=500mA

输出Output: DC 5V=280mA

蓝牙工作频率&发射功率: 2402MHz-2480MHz, <11dBm

内含物: BUTTONS CLIP PRO耳机x2 BUTTONS CLIP PRO耳机便携充电盒x1

USB Type-A到Type-C充电线x1 产品手册x1 收纳袋x1 耳帽x4

清洁注意事项:

本产品部分采用高品质皮革材质, 为确保其长久保持良好状态与美观, 清洁时请务必留意: 严禁使用含有酒精、漂白剂等刺激性成分的清洁剂, 此类清洁剂可能会对皮革造成褪色、干裂或材质损伤, 影响产品的整体质感与使用寿命。

建议您使用干净、柔软的布料, 轻轻擦拭即可有效去除表面灰尘与污渍, 使皮革始终光洁如新。

声明: 内有安全信息说明

声明: 内含锂离子电池。电池必须妥善回收或处理。

警告: 为避免听力损伤, 请勿长时间以高音量收听。

警告: 设备内含有磁铁

警告: 窒息危险, 本产品含有小零件。

警告: 带有此符号表示不得将本产品作为生活垃圾丢弃, 应将其运送到适当的收集设施进行回收。正确的处置和回收利用有助于保护自然资源、人类健康和环境。有关本产品的处置和回收等更多信息, 请与您当地的有关部门联系, 或与您购买此产品的零售商联系。



合规性和保证

欧盟符合性声明

北京特潮未加电子科技有限公司特此声明, 本无线电发射设备符合欧盟指令2014/53/EU。

你可以在互联网上的www.buttonsair.com找到欧盟符合性声明的全文。

产品名: BUTTONS CLIP PRO
产品类型: 夹耳式真无线蓝牙耳机
产品型号: CLIPBTN20
充电电压/电流: 5V=1A
FCC ID: 2A83I-CLIPBTN20

中国制造

制造商: 北京特潮未加电子科技有限公司
地址: 北京市朝阳区双桥中路1号院8幢二层2107



操控	敲击
扬声器	Φ12mm双磁喇叭
频响范围	20-20KHz
阻抗	16Ohm
通话Mic	2mic+VPU
射频通信范围	15m
防水等级	IP54
耳机电池	45mAh*2
充电盒电池	480mAh
蓝牙版本	5.4
重量	约 6.6g (每只耳机) 97.4g (2 只耳机 + 充电盒)
质保时间	1年

合格证
检验员:02

Made for
iPhone | iPad

保修说明

保修说明

BUTTONS 有限保修

重要声明：通过使用您的 BUTTONS 耳机(简称“产品”)，您同意接受本 BUTTONS 有限保修条款(简称“保修”)的约束。如果您不同意此份保修条款，请不要使用该产品，并在 BUTTONS 的退货政策中所规定的退货期限内将其退还。

谁会受到本保修的保障？

只有在最终用户所在地区或国家由 BUTTONS 授权经销商处购买本产品的最终用户(称“最终用户”)才有资格享受本有限保修。

有限保修：

根据本保修的条款及条件，BUTTONS 提供— (1) 年的保修期，从最终用户最初零售购买之日起— (1) 年(简称“保修期”)，该产品是在正常和惯常的消费者使用条件下，以及任何 BUTTONS 书面指南、规定或说明(包括如环境和存储要求)下，无设计、材料和工艺之重大缺陷的情况下运行。任何不合格品会以表格和 BUTTONS 合理要求的辅助信息报告给 BUTTONS，使其能够验证、诊断和修正不合格品。

保修条件及除外责任：

只有在下述情况下，本保修才有效：(i) 将 BUTTONS 授权经销商向原始最终用户开出的原始收据，上注有购买日期和序列号，连同本产品一起提交以进行修理或更换；(ii) 本产品表面上的密封签或序列号均未被篡改、移除或污损；以及 (iii) 本产品未被最终用户或使用者或任何其他以任何方式修改、变更、破坏、滥用或疏忽。

本保修不适用于(a)消耗性零件，如随时间推移而耗损的电池设计，除非由于材料或工艺上的缺陷而引起的故障；(b)外观损坏，包括但不限于刮痕、凹痕及端口塑料损坏，以及由于设备正常老化而导致的正常磨损或断裂；以及(c)将本产品与 BUTTONS 未提供或推荐的任何第三方设备或产品一起使用。

保修说明

如果BUTTONS在适当检查后自行决定认为该产品在保修期内未能符合本保修的要求，BUTTONS或其授权服务提供商将由BUTTONS决定，根据此规定条件修理或更换产品。

对于BUTTONS任何有关本产品的保修，本条款规定最终用户唯一和专门的补救措施，以及BUTTONS的唯一责任和专有赔偿责任。

如果BUTTONS或其授权服务提供商修理或更换本产品(这种修理或更换的产品，简称“更换品”),则更换品应在原保修期的剩余时间，或从修理或更换之日起的九十(90)天享有保修，以较长者为准。修理或更换可能涉及到使用功能相同之旧的、或先前安装或翻修的部件或零件。被更换的零件或部件会变成BUTTONS的财产。

所有保修退货必须邮递到公司指定售后地址(地址：中国北京市朝阳区新源南路8号启皓大厦西塔11层，电话(86-400-600-8802)

保修退货前，用户应向BUTTONS或授权服务提供商提供如下信息：

- 1、原始购买收据、包装及附件
- 2、型号、颜色和尺寸
- 3、序列号
- 4、您的联络信息(姓名和电话号码)

本产品必须以运费预付的方式退回。相关的退货会在最终用户的支出下退回其原始地。如果BUTTONS确定最终用户退回的产品不符合本文所述的保修条款，则最终用户还要承担BUTTONS将产品运回给最终用户的费用。

本保修除上述内容之外还有最终用户根据适用法律可能拥有的其他法定权利和补救措施，这是针对产品销售给位于中国大陆以外的最终用户。如要取得此类情况下的任何适用法律权利或相关保修信息或服务，请先联系您购买本产品的经销商或提供本产品的发行商。

包裝內包含以下物件



BUTTONS CLIP PRO
耳夾式耳機 (2 隻)



BUTTONS CLIP PRO
耳機專屬便攜式充電艙



USB充電線



產品手冊及保修卡



包裝布袋



耳機帽

注意：如果產品的任何部分缺失或損壞，請勿使用。請訪問BUTTONS官網www.buttonsair.com，瞭解故障排除文章、視頻以及產品維修或更換資訊。或聯絡客服郵箱地址service@buttonsair.com(Global)。