


USER MANUAL

Lingke Starry M5

PACKING LIST

- ① Lingke Starry M5
- ② Gloves
- ③ Envelope
- ④ Warranty Card
- ⑤ User Manual
- ⑥ Power Cord




SPECIFICATION

- Frequency response 38Hz-23KHz(-6dB)
- SNR 15W+15W=100dB(+A)+100dB(+A)(Mid and Treble)70W=110dB(+A)(BASS)
- Voltage 100-240V 50/60Hz
- Power handling 100W
- Impedance 4ohm
- Standby power consumption 0.5W
- Bluetooth available distance ≤15m

FUNCTION DESCRIPTION


- ① LED Light -- Red, White, Blue

- Solid white – AUX input
- Solid blue – Bluetooth input
- Fast flash blue – Bluetooth pairing mode
- Slow flash blue – Speaker Bluetooth is searching for last connected device



FUNCTION DESCRIPTION

- ② Power Button
 - Short press 3 second to power it on
 - Long press 3 seconds to power it off
- ③ Volume down
- ④ Bluetooth Play/Pause
- ⑤ Volume up
- ⑥ Bluetooth
 - Long press 3 seconds to disconnect current connection
- ⑦ Battery statu
 - 7 lights are fully charged, 2 lights indicates the need of timely charging
- ⑧ Pair button
 - If you want the speaker to be a master one
- ⑨ LED for pairing indication(white)
 - When two speaker are pairing, the white light of master speaker is slow flash, the slave one is fast flash
- ⑩ 3.5mm AUX input
- ⑪ DC Output: 5V/2.0A(charge for external devices)
- ⑫ Power input :AC 100-240V 50/60Hz




- Small Tips for Volume Control

If you still feel the volume is high even you've already adjusted it to the minimal volume level "1" on phone, you can continue to reduce the volume by another 3 level(0.3,0.2,0.1) on (master) speaker, at this time the mobile phone or APP still show volume level is "1".

TROUBLE SHOOTING

- Press power button, the LED light is not on

- Check whether the plug is powered on.
- Check whether the power plug is tightly inserted.
- The product may be out of power and needs to be charged in time.
- Check whether the power cord is properly inserted into the product.



1/4-20 insert for the purpose of mounting bracket

TROUBLESHOOTING

- The product(Lingke Starry M5) cannot be found by mobile phone Bluetooth

- Please check whether the Bluetooth on the mobile phone is turned on. if yes, turn off Bluetooth and turn it on again for searching.
- Long press the Bluetooth button for more than 3 seconds, when you see the blue light flashes, please use phone to search it again..

- The phone volume is out of sync with the product volume(Lingke Starry M5)

- Get into your phone's Bluetooth settings menu, find the product you've paired (Lingke Starry M5), and turn on the option of "Bluetooth device volume sync with your phone" .
- Get into your phone's Bluetooth settings menu and find the paired product (Lingke Starry M5), if there is no option of "Bluetooth device volume sync with your phone,", you may need to upgrade your phone's system version.

PRECAUTIONS

- The power plug should be placed in a convenient location.
- If the product is not used for a long time, please pull out the power plug from the AC power socket
- Do not scratch, bend, twist, stretch or heat the power cord, which will cause damage to the power cord, resulting in fire or electric shock. if the power cord is damaged please contact Lingke Audio for replacement
- Do not disassemble or modify the structure of this product without authorization otherwise it may cause fire or electric shock. If you need to repair, please contact Lingke Audio.
- Product waterproof rating is IPX3, can not be soaked in water or expose to rain for too long.
- Do not place exposed flame sources, such as lighted candles, on the product
- The disconnecting device of this product is an appliance coupler. The appliance coupler should be easy to operate and should not be blocked by other objects nearby.
- Please choose CCC certified wire to be used with speaker together.
- Items cannot be placed within 30mm around the product to avoid damage to the product during operation.

Warning

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

- If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- RF Exposure Statement

- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.