



中英文说明书尺寸：50x100mm (5折页) 材料：70双胶(双面印刷) 折叠线不要印刷

AQ-7 使用说明书 	基本参数: -无线规格：BT EDR V5.4 支持无线协议： 支持L2CAP/A2DP/AVRCP，用来接收 立体声音频信号，通过协议可以控制 音频发射端的上下曲操作； 支持HSP/HFP(Handsfree profile)，具 有免提功能，可以进行语音通讯； -无线传输范围：10M -音频性噪比：≥90db -电池容量：2400mAh -内置电压：3.7V -正常音量播放：关掉幻彩LED灯3H左 右（因音频内容和音量而异） -喇叭规格：Φ 66mm*2 -喇叭功率：15W * 2 -频率响应：120Hz-20KHz -尺寸：234.2x128.2x148.7mm -单机重量：约1044g -充电电压：5V/1A -充电时长：约3H 功能特点 1.采用先进的无线音频解码芯片，支持 无线设备连接。 2.支持FM收音，可直接搜索收听区域	的电台。 3.音色柔和清晰有动感，各层次分明。 4.直读TF卡和U盘。 5.无线接收距离远可长达10米。 6.无线模式无连接，半小时关机。 7.多种闪烁模式幻彩LED灯，灯光可随 音乐旋律闪动一键转换，音乐旋律不 止能听还能看。 8.支持TWS功能。 9.一键切换EQ音效。 功能指示	1.DC5V充电接口，(type-c USB 充电接 口)。 2.TF卡输入接口：TF卡插入时可解码 MP3格式的音频播放。 3.U盘输入接口：U盘插入时可解码 MP3格式的音频播放。 4.ON/OFF电源开关：ON为开机状态， OFF为关机状态。 5.播放键： -在音乐模式下（TF卡、U盘、无线） ，短按为播放/暂停”； -在FM模式下短按为自动搜索电台、在 搜台过程中短按一下为取消往后自动搜 索电台； -在无线模式并配手机情况下，有电 话接入时短按一下为免提接听，再短按 一下为挂断电话，双击为重拨电话。 6.在音乐的模式下，短按为“上一曲” 长按为“音量减”。 7.在音乐的模式下，短按为“下一曲” 长按为“音量加”。 8.模式键： -音乐模式下（TF卡、U盘、无线、 FM），短按为功能模式切换； -连接上手机时双击可断开手机连接； -TWS: 两台音箱同时在开机无线状	态,且都没有连接手机，长按其中一台音 箱的M键2-3S听到提示音即连TWS成 功，再连接手机即可；断开无线连接后 再长按M键取消TWS功能。 9.LED开关键：短按转换LED灯闪烁方 式，长按关闭LED灯、再长按或短按打 开LED灯。 10.户外EQ键，短按切换不同的EQ音 效。 备注： -在收音模式下，请插入充电线增加收音 信号强度，收音效果会更好，因幻彩 LED灯对收音信号干扰、进入收音模式 时会自动关闭幻彩LED灯提高收音效 果。 -U盘(32Gmax)和TF(32Gmax)卡用 (FAT32方式格式化)。 -TF卡/U盘请单独使用。 -不使用时请将拨动开关推到OFF。
---	---	---	---	---

AQ-7 USER MANUAL 	Product specifications: -Wireless: BT EDR V5.4 Support: L2CAP/A2DP/AVRCP, can receive AUDIO signal and control the AUDIO device. Support HSP/HFP(Handsfree profile), with HANDS-FREE functions. -Working distance:10M -SNR: ≥90db -Battery: 3.7V about 2400mAh -Normal volume playing time: about 3 hours with LED light off -Speaker driver: Φ66mm*2 -Speaker Power: 15W*2 -Frequency response:120Hz-20KHz -Unit size: 234.2x128.2x148.7mm -Unit weight: about 1044g (not includ accessories) -Charging:5V/1A -Charging time:about 3 H Product Feature: 1.International advanced wireless chip and circuit design techniques, support wireless devices. 2.With FM function, can search radio station broadcast automatically. 3.With Hi-Fi speaker, to make sure the clear and bright sound. 4.Support Micro SD card and USB card, play MP3 format audio.	5.The wireless working distance is 10 meters. 6.It will close automatically after 30 mins if disconnect Wireless . 7.A variety of flashing LED lights with different colors, color lights flash follow the melody. 8.Support TWS. 9.Support outdoor EQ audio modes. Key and slot function: 1.DC 5V slot: Use the standard USB TYPE-C charging cable for power charging.	2.TF slot: It can decode and play MP3 format audio when put TF card into the slot. 3.USB slot: It can decode and play MP3 format audio when put the USB card into the slot. 4.Power switch: ON indicates the power- on state, while OFF indicates the power- off state. 5.Play/Pause -When play music,(USB card/TF card/ Wireless), short press for "play/pause". -In FM mode, press short to search station automatically, press again to stop searching. -Under wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call. 6.When play music, Press short for last song, long press to turn down the volume. 7.When play music, press short for next song, long press to turn up the volume. 8.M switch: -When play music, Short press to switch model (USB card/TFcard/Wireless/FM). -When connected to a phone, double- click the button to disconnect the phone connection. -TWS:Keep the two speaker under	Wireless mode without pairing, press the key for 2-3 seconds either of the speaker until hear a hint , now it is TWS mode ,then can paire the mobile. Disconnect the wireless connection and then long press the button to cancel the TWS function. 9.LED on/off switch: Short press to change the flashing mode of the LED light, long press to turn off the LED light, and then long press or short press again to turn it on. 10.Outdoor EQ key, short press to switch different EQ sound effects. NOTE: -In the FM mode, put in charging cable to increase the FM radio signal . the LED flashling light will close auto when switch to FM model. -USB (32Gmax) /TF card (32Gmax) pls use FAT32 format. -Please use the TF card/USB flash drive separately. -Please push the toggle switch to OFF when not in use.
---	--	--	---	--

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.