





中英文说明书尺寸：50x100mm (5折页) 材料：70双胶(双面印刷) 折叠线不要印刷

TG-397 使用说明书 	基本参数 ●无线规格：V5.3 支持L2CAP/A2DP/AVRCP用来接收立体声音频信号，通过协议可以控制音频发射端的上下曲操作； 支持HSP/HFP(Handsfreeprofile)具有免提功能，可以进行语音通讯 ●无线传输范围：10M ●音频性噪比：≥90db ●电池容量：约3000mAh ●内置电压：7.4V ●正常音量播放：4H左右（因音频内容和音量而异） ●喇叭规格：75mm*2 ●喇叭功率：4Ω/20W*2 ●频率响应：120Hz-20KHz ●尺寸：318*136*137mm ●单机重量：约2017g(单机) ●充电电压：5V/2A ●充电时长：约4H 功能特点 1、采用先进的无线音频解码芯片，支持无线设备连接； 2、支持FM收音，可直接搜索收听区域的电台； 3、音色柔和清晰有动感，各层次分明 4、直读TF卡和U盘；	5、无线接收距离远可长达10米； 6、支持LINEIN音频输入，为你提供电脑音箱功能,可直接连接手机/平板电脑/及电视蓝牙配对播放音乐； 7、无线模式无连接，半小时关机； 8、多种闪烁模式幻彩LED灯，灯光可随音乐旋律闪动一键转换，音乐旋律不止能听还能看； 9、支持TWS； 10、支持户外EQ音频模式。 功能指示  ①DC5V充电接口，(type-cUSB充电接口)。 ②TF卡输入接口：TF卡插入时可解码MP3/WMA/WAV/FLAC/APE格式的音频播放。	③U盘输入接口：U盘插入时可解码MP3/WMA/WAV/FLAC/APE格式的音频播放。 ④LINEIN输入接口：3.5音频头外音输入。 ⑤电源开关：长按时为开机状态，再长按时为关机状态; -在音乐模式下（TF卡、LINEIN、U盘、无线），短按为播放/暂停"; -在FM模式下短按为自动搜索电台、在搜台过程中短按一下为取消往后自动搜索电台; -在无线模式并配手机情况下，有电话接入时短按一下为免提接听，再短按一下为挂断电话，双击为重拨电话。 ⑥在音乐的模式下，短按为“上一曲”长按为“音量减” ⑦在音乐的模式下，短按为“下一曲”长按为“音量加” ⑧LED开关键：短按转换LED灯闪烁方式，长按关闭LED灯光。 ⑨音乐模式下（LINE IN、TF卡、U盘、无线、Fm），短按为功能模式切换; TWS:两台音箱同时在开机无线状态且都没有连接手机，长按其中一台音箱的M键2-3S听到提示音即连TWS成功，再连接手机即可；断开无线连接	后再长按M键取消TWS功能。 ⑩EQ键:音乐模式下,短按切换EQ模式。 备注： -在收音模式下，请插入音频线增加收音信号强度，收音效果会更好，因幻彩LED灯对收音信号干扰、进入收音模式会自动关闭幻彩LED灯。 -使用中遇到死机现象可长按开机键8秒后会自动关机 -U盘（32Gmax）和TF(32Gmax)卡用（FAT32方式格式化）
---	--	---	---	--

TG-397 USER MANUAL 	PRODUCT SPECIFICATIONS: ●Wireless: V5.3 Support: L2CAP/A2DP/AVRCP, can receive AUDIO signal and control the AUDIO device. Support HSP//HFP(Handsfree profile), with HANDS-FREE functions. ●Working distance:10M ●SNR: ≥90db ●Battery: 3.7V about 3000mAh ●Normal volume playing time: about 4H ●Speaker driver: 75mm*2 ●Speaker Power: 4Ω/20W * 2 ●Frequency response:120Hz-20KHz ●Unit size: 318*136*137mm ●Unit weight: about 2017 g (not includ accessories) ●Charging:5V/2A ●Charging time:about 4H PRODUCT FEATURE: 1.International advanced wireless chip and circuit design techniques, support wireless devices. 2.With FM function, can search radio station broadcast automatically 3.With Hi-Fi speaker, to make sure the clear and bright sound. 4.Support Micro SD card and USB card, play MP3 format audio.	5.The wireless working distance is 10 meters. 6.With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones. 7.It will close automatically after 30 mins if disconnect Wireless . 8.A variety of flashing LED lights with different colors, color lights flash follow the melody. 9.Support TWS. 10.Support outdoor EQ audio modes; KEY AND SLOT FUNCTION:  1.DC 5V slot: Use the standard type-c USB charging cable for power charging. 2.TF slot: It can decode and play	MP3 format audio when put TF card into the slot, supportingMP3/WMA/WAV/FLAC/APE audio formatsc. 3.USB slot: It can decode and play MP3 format audio when put the USB card into the slot, supporting Mp3/WMA/WAV/FLAC/APE audio formats. 4.AUX line in slot: Use the Mini 3.5 head input through outside devices. 5.Power switch: Press long for power on /power off. -When play music,(USB card/TF card/Wireless/line in), short press for "play/pause". -In FM mode, press short to search station automatically, press again to stop searching. -Under wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call. 6.When play music, Press short for last song, long press to turn down the volume. 7.When play music, press short for next song, long press to turn up the volume. 8.Short press to switch LED light flashing mode, long press to turn on or off LED light.	9.When play music, short press to switch model (USB card/TF card/ Wireless/line in/FM). TWS:Keep the two speaker under Wireless mode without pairing, press the "M" key for 2-3 seconds either of the speaker until hear a hint and meantime the button light stop flashing, now it is TWS mode ,then can paire the mobile. Press the "M" key for 3 seconds either of the speaker to stop TWS after disconnect wireless. 10. Short press to switch EQ mode when playing music. NOTE: -In the FM mode, put in AUX cable to increase the FM radio signal ; the LED flashling light will close auto when switch to FM model -If this speaker crash during use, you can press and hold the power button for 8 seconds to reset and shut down. -USB(32Gmax)/TF(32Gmax) card pls use FAT32 format.
---	---	---	---	--

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.