

中英文说明书尺寸: 50x100mm (5折页) 材料: 70双胶(双面印刷) 折叠线不要印刷

TG-442 使用说明书	基本参数 ●无线规格: BT EDR V5.3 支持L2CAP/A2DP/AVRCP 用来接收立体声音频信号, 通过协议可以控制音频发射端的上下曲操作; ●无线传输范围: 10M ●音频性噪比: ≥90db ●电池容量: 约500mAh ●内置电压: 3.7V ●正常音量播放: 约2H (因音频内容和音量而异) ●喇叭规格: ∅ 45mm *1 ●喇叭功率: 4Ω/3W * 1 ●频率响应: 120Hz-20KHz ●尺寸: 90*90*48mm ●单机重量: 约174g ●充电电压: 5V/500mA ●充电时长: 约1.5H 功能特点 1、采用先进的无线音频解码芯片, 支持无线设备连接; 2、支持FM收音, 可直接搜索收听区域的电台; 3、音色柔和清晰有动感, 层次感分	明; 4、直读TF卡和U盘; 5、无线接收距离远可长达10米; 6、无线模式无连接, 半小时后关机; 7、支持TWS. 功能指示 ①DC 5V充电接口, (TYPE-C USB 充电接口); ②TF卡输入接口: TF卡插入时可解码MP3格式的音频播放; ③U盘输入接口: U盘插入时可解码MP3格式的音频播放;	④ 电源开关: 长按时为开机状态, 再长按时为关机状态 ⑤ 音乐的模式下 (TF卡、U盘、无线), 短按为播放/暂停"在FM模式下短按为自动搜索电台、在搜台; 过程中短按一下为取消往后自动搜索电台。 ⑥ 在音乐的模式下, 短按为"上一曲" 长按为"音量减" ⑦ 在音乐的模式下, 短按为"下一曲" 长按为"音量加" ⑧ 音乐模式下 (TF卡、U盘、无线、FM), 短按为功能模式切换: TWS.两台音箱同时在开机无线 状态且都没有连接手机, 长按其中一台音箱的M键2-3S听到提示音后即连 TWS成功, 再连接手机即可、断开无线连接后再长按M键取消TWS功能。 备注: -在收音模式下, 请插入充电线增加收音信号强度, 收音效果会更好。 -使用中遇到死机现象可长按开机键8秒后会自动关机。 -U盘和TF卡用 (FAT32方式格式化)	安装示意图
TG-442 USER MANUAL	PRODUCT SPECIFICATIONS: ●Wireless: BT EDR V5.3 Support: L2CAP/A2DP/AVRCP, can receive AUDIO signal and control the AUDIO device. ●Working distance:10M ●SNR:≥90db ●Battery: 3.7V 500mAh ●Normal volume playing time:2H ●Speaker driver: c45mm*1 ●Speaker Power: 4Ω/3W * 1 ●Frequency response:120Hz-20KHz ●Unit size: 90*90*48mm ●Unit weight: about 174 G (not includ accessories) ●Charging:5V/500mA ●Charging time:1.5H PRODUCT FEATURE: 1.International advanced wireless chip and circuit design techniques, support wireless devices. 2.With FM function, can search radio station broadcast automatically 3.With Hi-Fi speaker, to make sure the clear and bright sound. 4.Support Micro SD card and USB	card, play MP3 format audio. 5.The wireless working distance is 10 meters. 6.It will close automatically after 30 mins if disconnect Wireless. 7.Support TWS. KEY AND SLOT FUNCTION: 1.DC 5V slot: Use the standard Type-C charging cable for power charging. 2.TF slot: It can decode and play MP3 format audio when put TF card into the slot. 3.USB slot: It can decode and play MP3 format audio when put the USB card into the slot. 4.Press long for power on /power off.	5.When play music,(USB card/TF card/Wireless), short press for "play/pause". In FM mode, press short to search station automatically, press again to stop searching. 6.When play music, Press short for last song, long press to turn down the volume. 7. When play music, press short for next song, long press to turn up the volume. 8.Short press to switch model(USB card/TF card/Wireless/FM). TWS: Keep the two speaker under Wireless mode without pairing, press the "M" key for 3 seconds either of the speaker until hear a hint and meantime the button light stop flashing, now it is TWS mode, then can paire the mobile. NOTE: -In the FM mode, put in the charging cable to increase the radio signal. -If this speaker crash during use, you can press and hold the power	button for 8 seconds to reset and shut down. -USB/TF card pls use FAT 32 format. Installation Instruction

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.