

Automatic Litter Box Instruction Manual



Table of Contents

01	Safety Instructions
02	Packaging materials
03-11	Instructions
12	Product Specs

This device complies with part **15** of the FCC Rules. Operation is subject to the following two conditions:

- (1) The device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause unde operation.



Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part **15** of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device meets the FCC requirements for RF exposure. The device is designed for normal indoor use and complies with applicable FCC exposure limits.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Safety Instructions

- Please place the machine steadily in a cool, dry indoor area, and avoid storing it in direct sunlight, otherwise the product components may age easily.
- Do not let young children operate, touch, get close to, or climb on it. Children and people with intellectual disabilities should use it under the supervision of a guardian.
- Do not use gasoline or other organic solvents to wipe the body, and never wash or soak this product in water.
- To save electricity, turn off the relevant power switch when not using it for a long time, and clear out any leftover sand inside the machine.
- Please don't plug the step-up transformer into the power outlet.
- Do not use the machine in places where water sprays.
- Only use the machine after it is properly installed and secured. Make sure to place the product on a clean, flat, hard surface.
- When cutting off the power, do not pull the power cord directly to avoid breaking it.
- Please do not place flammable or volatile substances near this machine.
- During transportation and handling, it should be handled gently to prevent collisions and scratches on the products and accessories.
- Do not install the machine outdoors. It should be placed in a well-ventilated, dry environment with a temperature of 4-40°C, relative humidity no more than 90%, and no corrosive gases around.
- It's recommended to use bentonite cat litter. After turning off the machine, empty the litter tray and the waste box of any cat waste.
- Please keep the power plug clean and don't plug or unplug it with wet hands.
- When the sand hopper rotates, the whole machine will have slight vibrations and noise, which is perfectly normal.
- There are strong magnetic devices nearby, which could cause fires, product damage, or electrical malfunctions.
- When moving the product, handle it gently and avoid dragging it.
- Please don't place other items on top of the product, as it may affect its normal operation.
- The product should only be used with the special accessories provided by our company.
- When there are cats weighing less than 1 kg, pregnant cats, or nursing cats, please turn on Kitten Mode in the app (turn off auto-cleaning) and clean manually using the button.

Packaging materials



1. Base




2. sand tank



3. sand hopper cover



4. Trash can



5. Filter screen



6. Purification Stick



7. Fixed ring



8. Kitten playpen



9. Sand hopper cover latch



10. Adapter



11. Trash bag



12. Special Bag for Emptying
the Sand Hopper



13. Quick Guide Cover



14. Instruction
manual

Instructions



Scan the QR code to
view the product
video manual


Install

1 Checking accessories



Take out all the parts and pieces
of the cat litter box from the
packaging, then count and check
their names (a total of 12 pieces)

2 Install the sand hopper




Operate in an open area, and insert the sand hopper into the base.

Make sure the side of the sand hopper with
the small hole is facing up

Instructions

3 Install the mounting ring




A. Find the orange locking lever on the back of the base and pull it all the way up (fully open).



B. Pick up the orange retaining ring, with the gap facing up



C. Insert the orange locking ring into the hole in the middle of the sand chamber, pushing it all the way in.




D. Push the orange locking lever on the back of the base all the way down to complete the lock.

Instructions

4 Install the sand hopper cover




A. Find the protruding structure on the top of the sand hopper, align it with the notch on the top of the sand hopper, and insert it at an angle



B. Adjust the sand hopper cover so that it fully wraps around the edges of the sand hopper




C. Adjust the sand hopper cover so that it fully fits around the edges of the sand hopper
(You need to tap the entire sand hopper cover firmly)



D. Insert the sand container cover latch vertically into the top lock hole of the sand container, then rotate it clockwise to horizontal to lock it.

Instructions

5 Install the sand hopper filter




A. Pick up the filter mesh at the angle shown in the diagram, and gently align the two magnetic connectors so they snap together.



B. Gently place the entire filter into the sand compartment, insert the raised part of the filter from the inside out into the hole of the sand compartment cover, and you're done installing it.

Instructions

6 Install the waste box and purification rod




A. Put the trash bag over the waste bin and put the lid on (pay attention to the lid's direction)



B. Unwrap the purification stick from its plastic packaging, insert the waste box and purification stick into the base according to the directions shown, finish the installation, and close the waste box door.

Instructions

7 Moving the litter box correctly



Pick up and move the litter box from the sides at the bottom.
Do not lift the litter compartment directly, as it may cause the litter box to crack or break.


Instructions

Place the machine &
power it on

Place the machine

Move the machine to the spot where you want to place it (it's recommended to hold the bottom of the machine while moving), and plug it in once it's set.

Power on



Please place the machine on a flat surface, preferably at or next to the original litter box location. Do not place the machine outdoors. Once powered on, the machine will check the position of the sand compartment, and it will automatically move to the initial position. Do not manually rotate the sand compartment.

The round power port is located on the lower left at the back of the base. Note that the flat port is a USB debugging port, so don't use a USB cable to power the litter box.

Instructions

Add cat litter



Add cat litter up to the marked line, not less than 50% of the line or more than the MAX line.

▲ MAX

▼ 50%



Please use clumping bentonite cat litter; do not use pure tofu cat litter.

Also, avoid using large-particle cat litter (particle diameter no more than 3mm, length no more than 12mm), otherwise it may cause a lot of litter waste.

Smooth out the cat litter



After pouring in the cat litter, press the 'smooth' button to level it, or you can wait about a minute and the machine will automatically smooth it out.



Level

Instructions

Go online

Download the neakasa APP and follow the steps in the app to connect to the network.



Please turn on Bluetooth and enable location when connecting (you need to turn on precise location).

To ensure safe transportation and first-time use, the device comes with the auto-cleaning feature turned off by default. After your cat uses the litter box, the system will not clean automatically. If you want automatic cleaning, please follow the steps below to enable the auto-cleaning feature in the app once the device is connected to the network:

1. Open the Neakasa App and go to the device 'Settings' page;
2. Find the [Auto Clean] option and turn it on.

Once turned on, the system will automatically start cleaning 5 minutes after the cat leaves the litter box, and the device will also remind you to clean the litter bin and waste box every month.

Product Specs

Product Model: **PS0480**

Rated power: **12 W**

Rated Voltage: **12 V**

Maximum cat litter capacity: **7 L**

Trash bin capacity: **4.5 L**

Sand hopper inlet height from the
ground: **28cm / 11 inch**

Operating noise: **45 dBA**