

12:10 4G

蓝牙

蓝牙

现在可被发现为“iPhone”。

我的设备

EP032-Z 已连接 ⓘ

其他设备 +

若要將 Apple Watch 与 iPhone 配对, 请前往 Apple Watch app.


④ 语音助手功能	
IOS系统设备	长按2S任意一边耳机的多功能键“ ”一声后唤醒Siri
Android系统设备	长按2S任意一边耳机的多功能键“ ”一声后唤醒语音助手 (确保安卓系统自带语音助手方可召唤)

产品状态	指示灯状态
充电仓给耳机充电	左耳充电:绿灯闪烁
	右耳充电:白灯闪烁
	左右耳同时充电, 绿灯白灯交替慢闪
充电仓充电	白灯常亮
充电仓充满电	绿灯常亮
充电仓一共有2个LED灯	白色、绿色
绿灯常亮	100%-52%电量
白灯常亮	52%-13%电量
白灯闪	低于13%电量


提示项	提示音说明
关机	提示音：“嘟”升调
开机	提示音：“嘟”升调
连接设备成功	提示音：“嘟”升调
呼叫Siri/关闭Siri	提示音：“嘟”

断开设备	提示音：“嘟嘟”降调
电池低电量报警	提示音：“嘟嘟”

耳机入仓，未关盖，长按充电仓
按键8秒，充电仓绿灯闪烁3次，
耳机红灯闪烁3次。



1. 请遵循本说明书中的使用说明，勿以任何理由拆卸或改装设备，否则可能导致耳机发生故障或烧毁；
2. 请勿将产品浸入任何液体或用水冲洗产品；
3. 请勿使用超过耳机额定电流电压 (5V/1A) 以外的充电器给耳机充电，否则将容易造成耳机电池损坏 (请使用搭配的充电线给耳机充电)
4. 请在常温环境中使用和存放本产品，勿将设备置于温度过低或过高 (0°以下或者 45°以上) 的环境中；
5. 请勿堵塞耳机的开口处，如充电口、指示灯和麦克风等；
6. 请避免过大音量或者过长时间使用耳机，避免造成头晕或对听力造成伤害。
7. 请勿在雷暴天气下使用设备，雷暴可以导致设备工作不正常，信号中断等现象。



12:10

< Settings Bluetooth

Bluetooth ☒

Now discoverable as "iPhone".

MY DEVICES

EP032-Z Connected ⓘ

OTHER DEVICES +

To pair an Apple Watch with your iPhone, go to the Apple Watch app.


4 Voice Assistant Function	
iOS Devices	Long press the multifunction button on either earphone for 2.5 seconds, "Beep" sound followed by Siri activation
Android Devices	Long press the multifunction button on either earphone for 2.5 seconds, "Beep" sound followed by voice assistant activation (ensure that the Android device has a built-in voice assistant to summon)

Product Status	Indicator Light Status
Charging Case Charging Earphones	Left ear charging: Green light flashing
	Right ear charging: White light flashing
	Both ears charging simultaneously, green and white lights alternating slow flash
Charging Case Charging	White light on continuously
Charging Case Fully Charged	Green light on continuously
Charging Case has 2 LED lights	White, Green
Green light on continuously	100%-52% battery
White light on continuously	52%-13% battery
White light flashing	Below 13% battery

Prompt Item	Prompt Tone Description
Power Off	Prompt tone: "Beep" rising tone
Power On	Prompt tone: "Beep" rising tone
Device Connected Successfully	Prompt tone: "Beep" rising tone
Call Siri/End Siri	Prompt tone: "Beep"

Disconnect Device	Prompt tone: "Beep Beep" falling tone
Low Battery Alarm	Prompt tone: "Beep Beep"

Place the earphones in the case with the lid open, press and hold the charging case button for 8 seconds, the charging case green light flashes 3 times, and the earphone red light flashes 3 times.



1. **Please follow the instructions in this manual and do not disassemble or modify the device for any reason, as this may cause the headphones to malfunction or burn out;**
2. **Do not immerse the product in any liquid or rinse it with water;**
3. **Do not use a charger with a current/voltage exceeding the earphone's rated specifications (5V/1A) to charge the headphones, as this may easily damage the earphone battery (please use the included charging cable to charge the headphones);**
4. **Use and store the product in a normal temperature environment, and do not place the device in an environment with temperatures too low or too high (below 0°C or above 45°C);**
5. **Do not block the openings of the earphones, such as the charging port, indicator lights, and microphone;**
6. **Avoid using the headphones at high volumes or for extended periods to prevent dizziness or hearing damage.**
7. **Do not use the device during thunderstorms, as lightning can cause the device to work abnormally and interrupt signals.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.