Heart of Loulan
Myth Beast
O'Series

User Guide
Warranty terms

Heart of Loulan--Myth Beast-LT1

Please reading the TWS informations carefully and keep it properly before use

Packing list



Bluetooth pairing on/off

1. Connect to the IOS/ Android phone for the first time (make sure the Bluetooth connection function is enabled)

①Open the top cover of the Bluetooth earbuds



①Open the Bluetooth pairing list to find the pairing name of the product

②Click on the pairing name to connect

1. After there is a prompt, remove the top cover of the charging case and the earbuds will automatically connect to a second, and then to a third.
2. Put the earbuds back in the charging case and close the top cover of the charging case. The earbuds will be charged automatically. If the earbuds is connected, it will be disconnected automatically.2-1. When the connected device turns off Bluetooth or is beyond the range of earbuds connection, the earbuds enters the waiting state. If the device is not connected for more than 5 minutes, the earbuds will automatically shut down.

1. Due to the connection characteristics of the Bluetooth signal, in places where the electromagnetic signal and 2.4GHz interference dense, it may occasionally intermittently disconnect or no sound.
2. After use, please put the Earbuds back into the charging case in time to extend the service life and prevent loss.

Touch operation

1. Music playing



1 Skip back
Double-click the touch position on left earbuds

2 Skip Forward
Double-click the touch position on right earbuds

3 Play/Pause
Single press the touch position on left or right earbuds

2. Call operation

4 Answer
Single press the touch position on the left or right earbuds

5 Hang up
Single press the touch position onthe left or right earbuds

6 Reject
Long press the left or right earbuds touch position for 2 seconds

3. Basic operation

7 Power On
Long press the left or right earbuds touch position for 3 seconds

8 Power Off
Long press the left or right earbuds touch position for 5 seconds

9 Voice assistant
Double-click the touch position on the left or right earbuds

10 Left and right Earbuds pairing
Double-click the left/right earbuds touch position in pairing mode

11 Game/music mode switching
Long press the left or right earbuds touch position for 2 seconds

12 Disconnect and enter pairing mode
Five click left/right earbuds touch position

13 Factory data reset
Long press the left or right earbuds touch position for 10 seconds

Charging mode of charging case&Earbuds

Insert the TYPE-C cable into the charging port of the charging case. The charging case blinks red when it is charging, and the charging case is steady green when it is fully charged." When the charging case is low, the orange indicator of the charging case blinks. Charging is fully charged. Charging case indicator is steady green.

Place the earbuds in the charging case. The indicator of the charging case blinks red when it is charging. Put the earbuds in the charging case Close the top cover of the charging case, and the earbuds will automatically enter the charging state. The green indicator of the charging case will blink for 15 seconds. There is no indicator light during charging (Charge the charging case has power before charging).

If the charging case is not used for a long time, charge it at least once a month to avoid over-discharge or power loss of the charging case caused by a long time of unused use. As a result, the charging case may fail to be charged or not fully charged for a long time.

Specification

Product model	Heart of Loulan--Myth Beast-LT1
Operation mode	Touch operation
Speaker size	φ 13mm, 32 Ω
Charging port	TYPE-C
Bluetooth version	BlueTooth V5.3
Bluetooth protocol	A2DP/AVRCP/HFP/HSP/SPP
Earbuds battery capacity	3.7V / 45mAh
Charging case battery capacity	3.7V /400mAh
Noise Canceling	Dual microphone environment noise canceling (Dual ENC)
Low latency	<30mS
Earbuds charging time	< 1 hours
Charging case charging time	About 2 hours
Earbuds play time	About 6 hours(50%volume)
Standby time	About 24 hours
Bluetooth distance	≯10M(without any obstacle)
Rated input voltage/current of charging case	5V±0.5/1A
Rated output voltage/current of charging case	5V±0.5/1A
Working temperature	-10℃ ~ 60℃

The battery capacity, playing time, and charging time are obtained from standard charger tests at room temperature in the laboratory. The actual data may vary due to factors such as using environment and individual charger differences.Product specifications and parameters are laboratory test data, this manual is for reference only, specific functions and product pictures may be slightly different from the real object, please refer to the real object.

Problems caused by accidental operation errors or unknown reasons and solutions

Question 1	After the earbuds are connected to the mobile phone, one of the earbuds has a sound while the other one has no sound
Possible causes	1. The single earbuds no power 2. The single earbuds damaged 3. The left and right earbuds are not paired. Please repair them. 4. The earbuds and the charging case corresponding to the silent earbuds is not in good contact. As a result, the earbuds cannot be turned on
Processing method	A. For reasons 1, you can charge the earbuds; B. For reasons 4, you can check whether the tail plug of the earbuds and the spring pin of the charging case are dirty. C. For reasons 2 and 3, after-sales treatment should be carried out after testing and confirmation;
Question 2	Can't search the bluetooth pairing name.
Possible causes	1. The Hall effect sensor of the charging case is faulty. As a result, the earbuds cannot be turned on after the cover is opened 2. The charging case or earbuds are not connected, so the earbuds cannot be turned on 3. The earbuds is in poor contact with the metal spring pin in the charging case. As a result, the earbuds cannot be turned on after the cover is opened 4. The charging case or earbuds are damaged 5. The earbuds is unpaired, so that the earbuds is always in TWS pairing mode after the earbuds is opened.
Processing method	A. For reasons 3, you can detect whether the earbuds' tails and charging cases are dirty. B. For reasons 2, you can check whether the tail plug of the earbuds and the spring pin of the charging case are dirty.; C. For reasons and 4 need to be tested and confirmed; after -sales treatment

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Correct Disposal of This Product (Waste Electrical & Electronic True Wireless Stereo)(Applicable in countries with separate collection systems) This marking shown on the product accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Installation diagram

1. Place the flannel cloth under the main body before installation

2. Install ① and ② on the main body

3. Install ③ on the main body



4. Install ④ ⑤ socket head cap screws on the main body and fix them with a special socket head cap screwdriver

Installation diagram

5. Install ④ at the bottom of the body

6. Install ⑦⑧ on the left and right sides of the main body

7. Buckle the ⑤ upper cover onto the main body buckle (as shown in the above diagram), and then use the special hexagonal socket screwdriver to fix the ⑨ ⑩⑪ hexagonal socket screws on the back of ③

Installation diagram

8. The installation is complete

*⑨、⑩、⑪、⑫、⑬The above screws are quincunx type non removable screws. Do not remove them, which may cause damage to the product

After-sales Service Description

Dear users, thank you for using our products.
We will provide you with no less than the national three guarantees policy of after-sales service, service content is as follows:
1. Within 7 days from the date of purchase, if the product fails to meet the conditions listed in the list, the product can be returned or replaced free of charge upon detection and confirmation;
2. Within 8 to 30 days from the date of purchase, if the product fails to meet the conditions listed in the list, the product can be returned or replaced free of charge upon detection and confirmation;
3. Within 12 months from the date of purchase, if the product fails to meet the conditions listed in the list, it can enjoy free maintenance service after detection and confirmation;

Product performance Fault list	Charging case	1. The charging case cannot be charged
		2. The open cover does not work or the Hall effect sensor is faulty
	Earbuds	3. The button is stuck or no effect
		4.Damaged to charging interface (non-man-made)
		5.Main body damaged caused by structural or material factors.
		6. Speaker no sound.
		7.Microphone damaged
		8.The touch/pressure operation no effect
		4. The earbuds cannot be charged
		5. The functions listed in the manual fail
		6. Damaged of the main body caused by structural or material factors

In the process of user use, one of the following conditions is not within the scope of the warranty:
1. Beyond the warranty period;
2. There is a time limit for more than three packages;
3. Failure to meet the requirements listed in the Product Performance Fault List;
4. Performance faults listed in the "Product Performance Fault List" occur due to human causes;
5. Damage caused by irresistible factors (such as fire, earthquake, lightning strike, etc.);
6. Unauthorized maintenance, misuse, collision, negligence, abuse, liquid injection, accident, change, incorrect use of non-product parts, or tear down, alter label stickers, security marks, damaged bar codes, relevant vouchers;

Safety instructions

Safety instructions

Before using and operating the True Wireless Stereo, please read and observe the following safety instructions to ensure the best performance of the True Wireless Stereo and avoid dangerous or illegal situations.

Electronic True Wireless Stereo

Do not use this True Wireless Stereo in places where it is expressly prohibited to use wireless True Wireless Stereo, otherwise it will interfere with other electronic True Wireless Stereo or cause other dangers

Impact on medical True Wireless Stereo

In medical and health care places where the use of wireless devices is prohibited, please observe the regulations of the place and turn off the True Wireless Stereo.

The radio waves generated by the True Wireless Stereo may affect the normal operation of the implantable medical True Wireless Stereo or personal medical True Wireless Stereo, such as the arm puller, cochlear implant, hearing aid, etc. If you use these medical devices, please consult their manufacturers for restrictions on using this device.

Hearing protection

When you listen to music or call with headphones, it is recommended to use the minimum volume required for music or communication to avoid hearing damage.

Prolonged exposure to high volume may cause permanent hearing loss.

Exposure to high volume while driving may distract attention and cause accidents.

traffic safety

Please observe the relevant regulations of your country or region, and do not use this product when driving.

Remember that safe driving is your primary responsibility. Do not engage in activities that may distract your attention

The electronic True Wireless Stereo of the car may fail due to the radio interference of the True Wireless Stereo. Please contact the manufacturer for details.

Wireless True Wireless Stereo may interfere with the flight system of the aircraft. Please comply with the relevant provisions of the airline. Do not use wireless True Wireless Stereo where it is prohibited.

Operating environment

Do not use the True Wireless Stereo in a damp place or near the magnetic field, so as to avoid internal circuit failure of the True Wireless Stereo.

Do not use this True Wireless Stereo in thunderstorm weather, which may cause True Wireless Stereo failure or electric shock to the face.

Please use the True Wireless Stereo within the temperature range of 2 ℃~45 ℃, and store the True Wireless Stereo and its accessories within the temperature range of -10 ℃~50 ℃.

When the ambient temperature is too high or too low, it may cause device failure. When the temperature is lower than 5 ℃, the battery performance will be limited.

Do not place the True Wireless Stereo in direct sunlight, such as the dashboard or window sill.

Do not place the True Wireless Stereo near heat source or exposed fire source, such as electric heater, microwave oven, oven, water heater, furnace fire, candle or other places that may generate high temperature.

Do not place sharp metal objects, such as pins, near the earpiece or loudspeaker of the device to prevent metal objects from attaching and causing harm to you.

Child health

This device and its accessories may contain some small parts. Please keep the device and its accessories out of the reach of children.

Children may unintentionally damage this True Wireless Stereo and its accessories, or swallow small parts to cause asphyxiation or other hazards.

This device is not a toy. Children should use the device under the supervision of adults.

Requirements for accessories

Only use the accessories approved by this True Wireless Stereo manufacturer and matched with this True Wireless Stereo. The use of any other accessories may violate the warranty of the warranty terms of the True Wireless Stereo and the relevant regulations of the country where the True Wireless Stereo is located, and may lead to safety accidents. For approved accessories, please contact the authorized service center.

Battery safety

Do not disassemble or modify the battery, insert foreign matters, or immerse in water or other liquids to avoid battery leakage, overheating, fire or explosion. Do not drop, squeeze or puncture the battery. Avoid exposing the battery to external pressure, which may cause internal short circuit and overheating of the battery.

The device is equipped with a non-removable built-in battery. Do not replace the battery.True Wireless Stereo with non removable built-in battery, Do not replace or remove the battery Dispose of used batteries according to local instructions.

Maintenance

When the earbuds is not in use, please put it back into the charging case to prevent loss and charge the earbuds in time.

Please keep the True Wireless Stereo and its accessories dry. Do not use external heating True Wireless Stereo such as microwave oven or hair dryer to dry them.

Do not place the True Wireless Stereo and its accessories in areas where the temperature is too high or too low, otherwise the True Wireless Stereo may malfunction, catch fire or explode.

Before cleaning and maintenance, please stop using this device, close all applications, and disconnect all connections or cables with other devices.

Do not use strong chemicals, cleaning agents or strong detergents to clean the True Wireless Stereo or its accessories. Please use a clean, dry soft cloth to wipe the True Wireless Stereo or its accessories.

Do not touch the magnetic stripe card (such as bank card, telephone card, traffic card, etc.) with the device for a long time, or the magnetic stripe card may be damaged by the magnetic field. Do not disassemble or modify the True Wireless Stereo and its accessories without authorization, otherwise the True Wireless Stereo and accessories will not be covered by our warranty.

In case of True Wireless Stereo failure, please contact the authorized service center.

be careful

Do not swallow headphones. Children and minors should use this device under the supervision of their guardians to prevent swallowing.

environmental protection

Do not treat this True Wireless Stereo and its accessories as ordinary household garbage.

Please comply with the local regulations on the disposal of this True Wireless Stereo and its accessories, and support the recycling action.

True Wireless Stereo Warranty Card

Customer information — Name/contact phone/address/email/QQ/WeChat

Product Information — Model/SN code/purchase date/purchase address /contact number/invoice information

Please ensure that the above information can help us quickly understand the product related information and timely contact you in the follow-up service.

Contents of product warranty

Part Name	Poisonous or harmful substance or element					
	Pb	Hg	Cd	Cr6+	PBBs	PBDEs
Plastic subject	O	O	O	O	O	O
Silica gel	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Battery	X	O	O	O	O	O
Trumpet	O	O	O	O	O	O

O Indicates that the content of toxic and hazardous substance in all homogeneous materials of the part is below the limit requirements stipulated in SJ/T11363-2006 (Limit Requirements for toxic and Hazardous Substances in electronic Sink Information Products).

X Indicates that the content of the toxic or hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in SJ/T11363-2006.

The environmental protection use period under the condition of normal use, bluetooth earbuds (excluding conductor) and its accessories products contain toxic and harmful substances or elements will not leak or mutation, electronic information products users use the electronic information products will not cause serious pollution to the environment or cause serious damage to other people and property.

This product contains batteries. It is forbidden to disassemble, squeeze or put into fire. In case of battery leakage, deformation and other abnormal conditions, please stop using. Do not use in high temperature environment.

MADE IN CHINA

Company Name: BETWEEX COSMETIC CO., LTD
Address: B01, 3rd Floor, Makerspace, No. 368, South Jiangnan Avenue, Haizhu District, Guangzhou City, Guangdong Province, China
Email: topbeauty@life-top.cn Website: www.hearttoloulan.com Official Tmall Store: Louland'sm Digital Flagship Store
Tel.: 17328314605