

QCY Melobuds ANC
真無線降噪耳機



使用前，請下載安裝QCY手機APP客户端
以獲得更便捷的耳機操控體驗

認識耳機

選擇並組裝耳套
中耳套適用于大多數人群，建議從中耳套開始試戴。




本説明書中的圖片均爲示意圖，可能與實物有偏差，請以實物爲準。

耳機配對


首次配對方法：
1、取出兩只耳機，再將兩只耳機放回充電盒中。(此步驟爲新機激活)
2、開蓋，取出耳機會自動開機，打開手機藍牙搜索“QCY Melobuds ANC”并點擊連接，完成配對。

一鍵切換配對設備：（此步驟A設備切換B設備）
打開蓋子，左右耳機在充電盒中，長按盒子按鍵約3秒後耳機閃白燈一下後取出耳機，在設備上搜索耳機，點擊連接。
*不支持同時連接兩臺設備，下次開機默認回連上次配對的設備



恢復出廠設置

1、左右耳機在充電盒中，打開蓋子，長按盒子按鍵約10秒；
2、耳機閃白燈5次，指示耳機正在恢復出廠設置。恢復出廠設置完成後，耳機取出雙耳靠近自動TWS組隊後進入和手機配對模式。




耳機充電
充電中：紅色指示燈長亮
充滿電：白色指示燈長亮30秒後熄滅

充電盒充電
充電中：紅色指示燈長亮
充滿電：白色指示燈長亮

佩戴耳機




1.適正確佩戴左右耳機，戴上耳機後可微微轉動調整，找到個人舒適且聽固的位置。
2.麥克風口往下，朝嘴巴方向。
3.錯誤佩戴耳機會導致通話，聽覺都受到不同程度的影響。



充電盒亮燈提示
白燈：充電盒電量高：≥20%
紅燈：充電盒電量低：＜20%

功能操作



- 開　機：長按觸控面板約1.5秒
- 關　機：耳機放入充電盒
- 接聽/挂斷：雙擊觸控面板
- 拒接電話：長按觸控面板約1.5秒
- 下 一 曲：三擊右耳觸控面板
- 語音助手：三擊左耳觸控面板
- 播放/暫停：雙擊左/右耳觸控面板播放/暫停
- 游戲模式：長按左耳觸控面板約1.5秒
- ANC模式：長按右耳觸控面板約1.5秒，耳機在降噪/關閉降噪/通透模式下循環切換

QCY藍牙耳機售後服務

QCY藍牙耳機售後服務承諾，責任售後三包服務，服務內容如下：
在三包有效期內，您可憑購物憑證依照本規定享受免費的維理、更換、退貨的權利。
1、自您購買之日起7日內，本產品出現故障，經由QCY售後服務中心確定爲產品質量問題，可享受修理、更換、退貨的服務。
2、自您購買之日起15日內，本產品出現故障，經由QCY售後服務中心確定爲產品質量問題，可享受維理或更換的服務。
3、自您購買之日起12個月內，本產品出現故障，經由QCY售後服務中心確定爲產品質量問題，可享受修理的服務。

售後服務與支持
保修期：
自產品購買之日起12個月(請妥善保管購買憑證)。
免費服務：
在產品保修期內，凡屬產品本身質量引起的故障，請用戶憑購買憑證與經銷商取得聯系以享受售後服務。
如有任何產品指導或規定非可歸責于產品質量本身，則不在保修範圍內。有下列情形者不屬于保修範圍內：
1、因天災、地震、雷擊、霉常電壓、環境因素而發生之故障或毀損的。
2、自行或委托未經原廠授權維修之廠商拆卸、改裝或更換非原廠零件。
3、未按使用手册操作或投入爲使用不當而造成損壞者，如產品受水、腐蝕、摔落、刺壓或置在異常溫濕度環境下。

三包憑證

產品信息：
產品型號 _____
訂單編號 _____
用户信息：
用户姓名 _____
聯系電話 _____
用户地址 _____
退換貨原因 _____
購買信息：
銷售單位 _____

FAQ

1.Q：怎麼只能聽一個？
A：將兩只耳機放回充電艙，重新取出查看是否恢復雙耳模式，如未恢復重置耳機即可解決。

2.Q：手機提示無法連接怎麼解決？
A：將手機上的配對記錄刪除，删除後重新進行搜索信號連接即可。

3.Q：怎麼聽歌/通話沒聲音？
A：安卓在手機連接記錄的右邊有個設置圖標，點擊進入，將兩個音頻選項取消勾選重新選擇，蘋果在設置通用輔助功能進入音頻通話方式，選擇自動，如本來就是自動，就換其他選項，然後選擇自動，如未恢復，删除配對記錄重新嘗試。

4.Q：怎麼視頻/游戲有延遲？
A：受使用環境、網絡、手機編解碼速度的影響，會造成手機傳送音頻數據到耳機時造成不同程度的延遲。

5.Q：怎麼卡頓/斷續？
A：躯，如果使用時有大量的 Wi-Fi 連接、4G 信號、大功率電器等等産生幹擾，可能會出現卡頓、斷續的情況，換個環境或者重新配對連接下就可以解決了。

若有售後服務需求，請聯系客服
電話：4008-306-708
網址：www.qcy.com
制造商：東莞市和樂電子有限公司
地址：東莞市這滘鎮粵庫路325號

産品中有害物質的名稱及含量

部件名稱	有害物質									
	鉛 pb	汞 Hg	鎘 Cd	六價鉻 Cr（VI）	多溴聯苯 PBB	多溴二苯醚 PBDE	鄰苯二甲酸二丁酯 DBP	鄰苯二甲酸二(2-乙基)己酯 DEHP	鄰苯二甲酸丁苄酯 DBP	鄰苯二甲酸二異丁酯 BBP
耳機主體	X	O	O	O	O	O	O	O	O	O
電　池	O	O	O	O	O	O	O	O	O	O
耳　套	O	O	O	O	O	O	O	O	O	O
配　件	O	O	O	O	O	O	O	O	O	O
充 電 線	X	O	O	O	O	O	O	O	O	O

本表格依據SJ/T 11364的規定編制
O:表示該有害物質在部件所有均勻材質中的含量均在(EU)2015/863規定的限量要求以下。
X:表示該有害物質至少在該部件的某一均質材料中的含量超出(EU)2015/863規定的限量要求，但目前行業無成熟的替代方案，在豁免範圍仍符合歐盟ROHS指令的環保要求。

使用年限
如本手册所述，在正常使用條件下，本産品的環保使用期限爲10年。在此期間，産品不會泄露任何危險物質，本産品可以回收，必須按照當地法規處理。



提示


1. 使用産品前請仔細閱讀本使用説明書並請妥善保管；
2. 首次使用時，請先將本産品充滿電；
3. 如果産品長期(超過2個星期)不用，請對其充電；
– 請勿以任何理由拆除或維修改裝耳機，否則可能會導致起火，電子摯穿甚至徹底損壞本品；
– 請勿將産品置于温度過低或過高(0° C以下或45° C以上的環境下)；
– 請避免靠近兒童或動物的眼睛使用産品指示燈；
– 請勿在雷暴天氣下使用該産品，雷暴可導致本産品工作不正常，並增加觸電的危險；
– 請勿用油及其他揮發性液體擦拭本産品；
注意：長時間使用耳機可能會造成聽力損害，請合理安排使用時間。

警示語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及幹擾合法通信；經發現有幹擾現象時，應立即停用，並改善至無幹擾時方得繼續使用。
前述合法通信，指依電信管理法規定作業之無線電通信。
低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之幹擾。

275.00 mm


QCY Melobuds ANC
Truly Wireless Earbuds



For better use experience,please scan
to download QCY APP before start-up.

Overview

Choose Eartips
Please try medium eartips first as they fit most people.




Above pictures are for reference only and practical items may vary.

How to Connect

First Time Connection:
1. Pick up both earbuds, pop them back in case then close lid to activate them,
2. Open lid, pick up earbuds and they will auto power on. On phone, search QCY Melobuds ANC and tap to connect.


How to Switch Connection Between Two Devices
Push earbuds into case, open lid and keep pressing charging case button for 3s or until LEDs on earbuds blink white. Then pick up earbuds. On device, search QCY-HT05 and tap to connect.

* Earbuds cannot get connected with two phones at the same time,They will auto reconnect to the last phone in connectivity record, if any.



Factory Setting

1. Push earbuds into case, open lid and keep pressing charging case button for 10s to set earbuds to factory(LEDs on earbuds blink white 5 times).
2. After factory setting, earbuds will auto pair with each other and turn connectable to phone when picked up.




Charging Earbuds
LED will glow solid red when earbuds are charged and turn white for 30s when topped up.

Charging Case
LED will glow solid red when case is charged and turn solid white when topped up.

How to Wear




1.Please put on earbuds properly then adjust them to fit yourself.
2. Set microphone towards your mouth.
3. It will cause a bad calling or listening experience to wear them in a wrong way.



LED on Case
Battery level of case ≥ 20%（white）
Battery level of case ＜ 20%（Red）

Functions



- Power-on: Keep pressing touch panel for 1.5s
- Power-off: Push earbuds into case
- Answer/end call: Double press touch panel
- Ignore call: Keep pressing touch panel for 1.5s
- Skip track forward: Triple press right touch panel
- Voice assistant: Triple press left touch panel
- Playback/pause: Double press left/right touch panel to play/pause
- Gaming mode: Keep pressing left touch panel for 1.5s
- ANC mode: Keep pressing right touch panel for 1.5s to switch among ANC, Normal and Transparency modes

Warranty Card

Warranty Period
12 months after you purchase this item (or you may inquire your local shopper for more details).
Free Service:
Supposing any defects caused by quality issues occur within the warranty period , please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number:
Date of Purchasing:
User's Name:
User's Phone:
User's Address:
Shop's Name:
Shop's Address:
Comments:

Free exchange service will not be accessed under following circumstances:
1. Damages caused unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages by act of God. Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

FCC Statement

This equipment has been tested and found to comply with the imits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

Hazardous substances and their contents in the item

Part Name	Hazardous Substances								
	Pb	Hg	Cd	Cr (VI)	PBB	PBDE	DBP	DEHP	DBP	BBP
Main body	X	O	O	O	O	O	O	O	O	O
Battery	O	O	O	O	O	O	O	O	O	O
Ear tips	O	O	O	O	O	O	O	O	O	O
Accessories	O	O	O	O	O	O	O	O	O	O
Charging cable	X	O	O	O	O	O	O	O	O	O

This form is made by SJ/T 11364 regulation.
O : means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation.
X : means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of exemption.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time.
Manufacturer: Dongguan Hele Electronics Co., Ltd.
Address: No. 325 Yuehui Rd. Daojiao Town Dongguan City Guangdong Province China



Tips

1. Before using the earbuds, please read the manual carefully and keep it for future references.
2. The earbuds need to be fully charged prior to first-time use.
3. If the earbuds are left unused for over two weeks, please recharge.
4. Please use the chargers made by qualified manufacturer.
5. If the earbuds cannot be found by your phone, please check whether they are in pairing mode; if left unconnected for a long while, the earbuds will exit pairing mode, please re-enter the mode; if a procedure error of your phone occurs, reboot it; if a procedure error of the earbuds occurs, reboot or reset it.

Caveats

1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
2. Do not store the earbuds in extreme temperatures (under 0°C or over 45°C).
3. Avoid using the indicator close to the eyes of children or animals.
4. Do not use the earbuds during a thunderstorm to avoid dysfunction and increasing risk of electricshock.
5. Do not use harsh chemicals or strong detergents to clean the earbuds.

Note: please do not use earbuds for a long time as may damage your hearing.