

英文

Overview

Earbuds (M size)
Ear Hook
MFB
Earbud
MIC/LED light

Functions

Power-on
Method 1: Take out both earbuds and they will auto power on. (LED lights flash blue and red)
Method 2: Press MFB for 2s to Power on (LED lights flash blue and red)

Power-off
Method 1: Put the earbuds into the Charging case, then the earbuds will turn off automatically for charging, the red indicator is on until fully charged.
Method 2: Press MFB for 5 seconds to power off, red indicator turns on for 1 second.

Answer Call
Press 1 time MFB to answer incoming call.

Hang off
Double Press MFB to hang off.

Playback/Pause
When playing music, press MFB to pause it and press again to play it.

Reject Call
Press MFB for 2s to reject incoming call.

Next Song/Previous Song
When playing music, double press MFB on left earbud to skip track backward (previous song), double press MFB on right earbud to skip forward (next song).

V-/V+
When playing music, Press three times MFB on left earbud to turn volume down (V-) and press MFB on right earbud to turn volume up (V+).

Voice Assistant
When standby, press and hold MFB on left earphone for Long press 1s until the "beep" sound happens to activate voice assistant (Like: Siri).

Wearing Earbuds

Table of Contents

Overview	1
Functions	2
Power-on	2
Power-off	3
Answer Call	4
Hang off	5
Playback/Pause	6
Reject Call	7
Next Song/Previous Song	8
V-/V+	9
Voice Assistant	10
Wearing Earbuds	11