

风琴折 正面

Wireless UHF Transmitter  
Receiver User Manual





1

Transmitter

Micro USB Charging Port

LED indicator light LED

Power On/Off button

Volume/Frequency Up

Volume/Frequency Down

LED indicator light LED

Receiver

Micro USB Charging Port USB

LED indicator light LED

Power On/Off button

Packaging Contents

1x UHF Wireless Receiver/Transmitter

1x Micro USB Charging Cable

1x 3.5mm to 6.35mm adapter

2

Wireless UHF transmitter/receiver

When the blue LED light is flashing, it requires for charging. the red LED light will be long time on during charging and then off when full charge the battery.( around 2-4hours)

Pairing:  
The wireless Microphone has been paired before putting in the box.  
If the UHF receiver and transmitter are not paired , please follow the instructions below:

1. Turn off the UHF transmitter and receiver first and turn on the transmitter again and press and hold the power button for around 3 seconds, and then press and hold + - button immediately until the LED screen runs quickly (it goes into the pairing mode)

2. Turn on the UHF receiver, when you see the blue LED light long time on, the pairing is complete.

3. If you have more than one sets of wireless UHF headset microphones, please turn off the paired transmitter/receiver and continue to pair the next set according to the above operation method.

4. To pair multiple sets of equipment to avoid the same frequency, you can choose from the frequency of C00-C49

3

Attention:

Please make sure the devices are powered off before manual pairing

风琴折 背面

ワイヤレスUHF送信機  
レシーバーユーザーマニュアル





1

送信機

マイクUSB 充電ポート

LEDインジケータライト

電源オン/オフボタン

ワイヤレスマイクレシーバー

音量/周波数アップ

LEDインジケータライト

音量/周波数アップ

マイクUSB 充電ポート

LEDインジケータライト

電源オン/オフボタン

包装内容

1xUHFワイヤレスレシーバートランスミッター

1xマイクUSB充電ケーブル

1x 3.5mm～6.35mmアダプター

2

ワイヤレスUHF送信機/受信機

青色のLEDライトが点滅しているときは充電が必要です赤色のLEDライトは充電中は長時間点灯し、バッテリーが完全に充電されると消灯します(約2～4時間)。

ペアリング:  
ワイヤレスマイクは箱に入れる前にペアリングされています。  
UHF受信機と送信機がペアリングされていない場合は以下の手順に従ってください。

1.最初にUHF送信機と受信機の電源を切り送信機の電源を入れ直し電源ボタンを約3秒間押し続けてからLED画面がすばやく表示されるまですぐに+-ボタンを押し続けます。  
(ペアリングモードになります)

2. UHF受信機の電源を入れます。青色のLEDライトが長時間点灯している場合はペアリングが完了しています。

3.ワイヤレスUHFハットセットマイクを複数セットお持ちの場合はペアリングした送信機/受信機の電源を切り上記の操作方法で次のセットのペアリングを続けてください。

4.同じ周波数を回避するために複数の機器セットをペアリングするにはC00～C49の周波数から選択できます

3

注意:

確認してください  
手動ペアリングの前にデバイスの電源がオフになります

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF Exposure Information**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.