


Export as PDF




1. Click on "Select", choose multiple files.
2. Click on "Export" to PDF.
3. Export path is: Internal storage/Documents/.

Image Editing




Click on "Edit" to make changes to the image, crop, insert text, etc.

OCR Recognition




1. Click on "OCR" to recognize text in the image.
2. Share or export the recognized results as a TXT file.
3. Path is: Internal storage/Pictures/OCR/.

13. Document Scanning




1. Scan documents by taking a photo with the camera.
2. Select files for recognition from "My Gallery".
3. Scan results can be exported as PDF or TXT files.
4. Export path is: Internal storage/OCR/.


14. App Center



1. Long press app: Uninstall, manage (open, set app permissions, force stop, etc.), add to group.




2. Long press app group: Rename, disband group.



3. Sort: Sort apps by name or installation time in ascending or descending order.

15. E Ink Center

E Ink Center



Operation: Pull down the status bar, select E Ink Center.

Refresh Mode: Set the refresh mode for the current app.

1. HD 256: Clearer details, suitable for viewing images and text.

2. HD Mode: Clear display, suitable for general text reading.

3. Normal Mode: Slightly faster refresh, suitable for quickly flipping through images and text.
4. Speed Mode: Fast refresh, some detail loss, suitable for browsing web pages, videos, etc.
5. Regal Mode: Least ghosting, clearer display of text and images, suitable for reading.
6. Full Refresh Frequency: Refresh the entire screen according to the set number of operations (for example, if set to 10, the screen will fully refresh after 10 operations).
7. Deep Color Enhancement: Adjust the browsing page to display colors more deeply.
8. Vivid Enhancement: Adjust the color saturation of the browsing page to display colors more vividly.
9. Color Brightness: Adjust the brightness of the browsing page.

App Optimization

×	OneNote	Eink Center App optimization
DPI setting(font size)		⌂ Recommend
⊖	410	⊕
Contrast setting		⌂ Recommend
⊖	0	⊕
Apply bleach		
☐ Text enhancement		
Icon color		
⊖	0	⊕
Background color		
⊖	0	⊕

1. DPI setting: Adjust the overall page and font size of third-party apps;
2. Contrast Setting: Deepen the color of the third-party app fonts;
3. Text Enhancement: Bold the titles, menus, and text fonts of the third-party app.

16. Global Handwriting

Global handwriting ☒

Mode

Handwriting mode Used to optimize the handwriting speed of third-party applications, such as wps, oneNote, Evernote, etc.

Read mode Used for Kindle, WeChat and other applications that do not support handwriting function, to save handwritten notes (Stylus-Buttons are disabled, does not support rotation)

Picture mode For global handwriting input, like in menus, images, apps etc. Save handwritten images through top status bar->Settings->Super screenshot (stylus buttons disabled).

Type

Pen Pencil Brush BallPen


Erase

Range Clear All

Color



Line width




Operation: Pull down the status bar, select Global Handwriting.

1. Handwriting Mode: Effectively improves the handwriting speed of third-party handwriting apps, such as Youdao Cloud Notes, WPS, OneNote, etc. Features: Converts handwriting strokes into third-party app strokes, third-party notes disappear after being converted into global handwriting content.

2. Reading Mode: Supports handwriting annotations in third-party reading apps like WeChat Reading, Kindle Reading, etc., and can be saved as PDF format for cloud storage.


3. Image Mode: Allows handwriting on any app interface and saves and shares images. Features: Does not make apps that do not support handwriting support handwriting, allows you to handwrite on any interface, and handwriting can be saved through screenshots.

Reading Mode – Reading Notes



1. Click [

17. App Split Screen



Operation

1. Pull down the status bar.
2. Select App Split Screen.

Dual Function


1. Dual Notes: Read and take notes at the same time.
2. Dual Meeting Records: Video and voice transcription at the same time.
3. Dual Apps: Open two apps at the same time.

After Opening Dual Apps

1. Swap Positions: Pull down the menu, select App Split Screen, swap positions.
2. Exit Split Screen: Pull down the menu, select App Split Screen, exit split screen


18. Input Method Management

Changing the Input Method



1. Click on [App Center] > [Settings] > [Input Method Management]
2. Select the input method you want to change

Bigme Input Method



1. Clicking on [Chinese/English] allows you to switch between Chinese and English input
2. Clicking on the [] icon allows you to use handwriting input, the content written by hand can be automatically recognized as standard characters, for example, if the system language default selection is "Simplified Chinese", handwriting input will be automatically recognized as "Simplified Chinese input", if the system language default selection is "English", handwriting input will be automatically recognized as "English input"
3. Clicking on [] allows you to enter voice input

Handwriting Input

< 语言选择

中文简体

English

中文繁體

Deutsch

日本

한국인

Русский

Français

总计: 41

✓

↓

↓

↓

↓

↓

↓


1/6

0	1	2	3	4	5	6	7	8	9	< x	关闭
,	°										
?	@										
—	↩										

In the handwriting interface, clicking on the [🌐] icon – the language switch icon allows you to choose different languages, the content written by hand can be automatically recognized as the corresponding selected language text

19. File Download and Transfer

Cloud Reading and Writing - Download




Through [Cloud Reading and Writing] can transfer files to each other



Scan the code to download or enter the address
<http://ereader.xrztech.com/BigmeCloud.html>

1. Smart office notebook and mobile phone or computer can transfer files, notes, and meeting records to each other
2. The login account for cloud reading and writing is the same as the registration login account for the Guoyue smart notebook

Cloud Reading and Writing – Introduction



Upload:

1. Android/Harmony: Click on the upload icon, select the file to upload to Cloud Reading and Writing
2. iOS: Transfer the file to iCloud, then transfer it to Cloud Reading and Writing through iCloud



Meeting
records



Random
notes



Reading
notes



Cloud
synchronization

Others:

1. Meeting records: Meeting records uploaded to the cloud through the [Meeting Records] application on the office notebook

2. Random notes: Random notes uploaded to the cloud through the [Random Notes] application on the office notebook


3. Reading notes: Bookmarks, annotations, handwritten notes, etc., added when opening books in the bookshelf or bookstore, uploaded to the cloud as reading notes

4. Document synchronization:

a. Files transferred to Cloud Reading and Writing from the mobile phone

b. Files uploaded to the cloud from the office notebook can all be viewed in the document view

Cloud Files



1 [Refresh] will synchronize the files uploaded to the cloud in the cloud file view

2 [Download] will download the files uploaded to the cloud to the local storage, the files will be saved in the local storage Download directory

3 [Delete] will delete the files uploaded to the cloud, once the files are deleted, they cannot be recovered, please operate with caution


Transfer books over WiFi

1. Enter the application "Bookshelf" – click on "Import" in the upper right corner of the page – select WIFI Import
2. Connect the smart office book and the computer to the same WiFi hotspot, enter the pop-up website address of the first step smart office book in the computer browser
3. Select a local file to import and upload the file


USB Transfer – Windows

Connect the device to the computer using a USB data cable, after the computer recognizes it, you can transfer files.


If the computer fails to recognize it, please perform the following operations:




1. After the device is connected to the computer, right-click on the computer desktop [This PC], select [Manage] > [Device Manager] > [Portable Device-Bigme]



2. Right-click on [Bigme], select [Update Driver Software] > [Manual Search]




3. Select [Let me pick from a list of device drivers on my computer]



4. As shown in the figure, select [MTP USB Device], click [Next], wait for the update to complete, click [Close] to finish.

USB Transfer – Mac



1. Install the [androidfiletransfer.dmg] file
2. Double-click on [Android File Transfer], you can transfer files after the folder window pops up

20. Floating Ball

Tue 10:31

99%

<

Navigation Ball Set

Open the floating ball

on

Volume key to turn page

on

The size of the floating ball

>

Button customization

Reset

Key 1

Homepage

Key 2

Back

Key 3

Multi-task switching

Key 4

Full refresh

Key 5

Screenshot

Key 6

Page key

Key 7

Navigation Ball Set

Key 8

Rotation

Key 9

Shut down and restart

1. A control menu that floats on the top layer of the interface, you can customize the settings for 9 button functions
2. Clicking the center button can expand or collapse the floating menu
3. After modifying the options in the floating ball, you need to reopen the enable switch;

Button Settings



Tue 10:31

 99%

< Key 1

 None

 Back

 Homepage

 Open application

None

 Shut down and restart

 Wi-Fi

 Bluetooth

 Screenshot

☐

☐

☒

☐

☐

☒

☐

☐

The 9 expanded buttons support customizing various common functions, including some of the system's own operations, application switching, etc.

21. Settings

About This Machine

 Shutdown

Never >

 Low power mode

>

 Home screen Style

>

 Menu manage

>

 Language

>

 System font size

>

 Date and time

>

 Input method

>

 Rotation

OFF

 Gesture settings

>

 Device password

>

 Google service

>

 Account Manage

>

 System update

>

 Log report

>

 After-sales service

>

 About the device

>

About the device

Device name

AINote

Product model

inkNote Color+

System version:

INKNOTE_COLOR_L_R_3.9.0_20230610

Serial number

WLAN MAC address

7C:99:3A:BB:A0:78

Bluetooth address

7C:99:2A:BB:9E:92

Android version

11

Processor

Octa-core 2.3GHz

RAM

4G

Storage capacity

Available51.58GB/Total64GB

Screen resolution

1860x2480

User manual

>

User guide

>

FAQs

>

Factory reset

1. You can query device model, version number and other device information, and make global settings for the system in the settings interface;
2. You can download the user manual for the corresponding model
3. You can view the user guide
4. You can view common problems
5. You can restore factory settings

Note: Restoring factory settings will clear all user data, please back up your data in advance, operate with caution

WIFI Settings

1. Select "Turn on WIFI", the device will automatically search for available WIFI hotspots, select the corresponding hotspot from the displayed WLAN network list, enter the password and other required information, connect to the WIFI hotspot. After successful connection, the system bar will show WIFI connection successful and the WIFI signal icon will appear.

2. After the WLAN hotspot is successfully set up for the first time, it will automatically record the information of the hotspot, and the next time you connect, you only need to select the WLAN switch in the drop-down status bar to automatically connect to the valid WIFI hotspot.

Bluetooth Settings

 WIFI network >  Bluetooth  Stylus >  Sleep time 5 mins >	Bluetooth Bluetooth ON Bluetooth List Searching Tip: Files received via Bluetooth are stored in the /Download directory realme Q2 Pro 5G A4:CC:B9:CE:90:96
--	---

1. Turn on the Bluetooth switch, you can search for available Bluetooth devices nearby, send connection requests
2. Bluetooth needs to be paired on both ends of the device before it can be used

Power Management

WIFI network

>

Bluetooth

>

Stylus

>

Sleep time

5 mins

>

Shutdown

Never

>

Low power mode

Low power mode

Performance mode

It can improve device performance, but will increase power consumption

☐

Power save mode

The battery life can be extended significantly. Some scenes may be updated abnormally. Tapping the screen or full screen refresh can restore the normal mode.

☒

Super power save mode

In this mode, the flight mode is turned on, which significantly extends the battery life. Some scenes may be updated abnormally. Tapping the screen or full screen refresh can restore the normal mode.

☐

You can set sleep time, shutdown delay, low power mode, etc.

Language

WIFI network

>

Bluetooth

>

Stylus

>

Sleep time

5 mins

>

Shutdown

Never

>

Low power mode

>

Home screen Style

>

Menu manage

>

Language

>

System font size

>

Date and time

>

Input method

>

Rotation

OFF

>

Language

English

Using

Language List

Simplified Chinese/中文简体

Traditional Chinese/中文繁體

English

Arabic/عربي

Belarusian/беларускі

Bulgarian/български

Catalan/Catalana

Czech/čeština

Danish/Dansk

German/Deutsch

The language settings interface allows for the configuration of the system's language.

Date and Time

< Date and time	
Use the 24 hour system	☒
Automatically sets the date and time	☒
Set timezone	GMT+08:00 BeiJing/China >
Note: Modifying the system date and time may cause some applications to fail to connect to the Internet	

1. You can choose to set the time automatically or manually. When connected to the internet, the automatic setting will match the device time according to the network time.
2. For manual setting, you need to set the date, time zone, and time yourself.
3. You can set the time to be displayed in 12-hour or 24-hour format, as well as the date display method, according to your usage habits.

Device Password

 Shutdown

Never >

 Low power mode

>

 Home screen Style

>

 Menu manage

>

 Language

>

 System font size

>

 Date and time

>

 Input method

>

 Rotation

OFF

 Gesture settings

>

 Device password

>

Device password

Please make sure to set up a device password when logged into your account, otherwise it cannot be retrieved if forgotten.

Password >

Fingerprint >

1. You can set a numerical password for the device.
2. With a numerical password set, you can also set a fingerprint password for unlocking the device.

Account Management

The accounts needed for data synchronization during device usage are managed uniformly.

Gesture Settings

 Shutdown

Never >

 Low power mode

>

 Home screen Style

>

 Menu manage

>

EN

Language

>

T

System font size

>

 Date and time

>

 Input method

>

 Rotation

OFF

 Gesture settings

>

 Device password

>


 Google service

>


Gesture settings

Swipe upwards from the bottom edge of the display


ON



Back >




Back Home Screen >




Full refresh >

Side(swipe up and down to adjust)

OFF




None >



None >

Side(swipe left and right to adjust)

ON



Back

1. By default, upward swipes from the bottom and left-right swipes from the sides are enabled, while up-down swipes from the sides are disabled.
2. Upward swipes from the bottom can be customized for various functions such as returning to the home page, going back, taking screenshots, switching tasks, clearing cache, full refresh, E ink center, etc.
3. Up-down swipes from the sides need to be enabled for custom functions, which can be set for volume, warm light, and cold light.

22. Disclaimer

Bigme Cloud Literacy Technology Co., Ltd. reserves the right to make changes to the product specifications and content in the “User Manual” without further notice.

1. All book interfaces in this manual are for display purposes only and are not pre-installed books.

2. Due to different software versions, some functions or interfaces may not be consistent with the manual, and the actual product shall prevail.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.