


Label Location On EUT



Label

Model:
LAUNCH CONTROLLER 3.3-4.2V
FCC-ID:
2A8GI-LAUNCHCONTROL

