

Instruction Manual

- Vibration dildo remote control
- FCC ID: 2A8IX-QYGJ195



USB charging

The lights flicker when charging, and the lights are always bright when full of electricity.



Power button



Mode button

open the vibrating mode, per click then change one kind of the mode, each of the indicator light included 10 kinds of vibrating mode.



- Working time: 2 hour.
- Material: ABS+Silicone.
- 10 frequencies vibrator wand, Product net weight 31.5g.
- The vibrator designed for fully sealed waterproof.
- The vibrator uses the polymer lithium battery with 300 MAH capacity and general USB 5V input.
- Use with lubricant and disinfectant to be comfortable, safe and healthy.
- Please clean and sanitize after use, the dry and save.
- More than 10m wireless remote control.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.