


USER USE INSTRUCTIONS



FOLDABLE PORTABLE

CONTENTS

Disclaimer of warranties and safety must be known	1 ~ 3
Components column table	4
Introduction to Flyer / Remote Controller	5
Pretend to be a guide	6 ~ 9
1. Spin the paddle	6
2. Photography	7
3. Mobile phone support	8
4. The flying machine battery	9
5. Remote control battery	9
Battery charging instructions	10
Flying exercises are guided	11 ~ 14
1. Placement before flying	11 ~ 12
2. One key to fly / drop / light drop	13
3. Hand movements fall	13
4. Flight control	14
Product function analysis	15 ~ 19
1. Forward / Backward Fine-tuning	15
2. Fly left / Fly right fine-tune	16
3. Speed cut	16
4. Circle in place	17
5. Ring around flying	17
6. Headless	18 ~ 19
A/P Installation and operation	20
Basic parameter information	21

TSRC

▲ A WARNING DESCRIPTION

In order to ensure the requirements of the air-to-air wireless radio station electromagnetic environment, it is prohibited on the runway of the airport. A variety of modal remote controllers are used in areas with a center point of 5000 meters in diameter. In the country there is during the period and within the region of the wireless pipe system issued by the customs department, the mode should be stopped as required remote instrument.

DISCLAIMER OF WARRANTIES AND SAFETY MUST BE KNOWN

To make your use of this product more expeditious and safe, please do so before using it carefully read all the contents of this handbook and keep it for later reading.

DISCLAIMER OF WARRANTIES AND SAFETY MUST BE KNOWN

1. In order to protect the legitimate rights of users, please read me carefully before using this product we attach an instruction manual, disclaimer and safety instructions provided by this product.
2. This product is not suitable for use by people under 14 weeks of age, and must be used by people under 14 weeks of age it is used under the guidance of adult supervisors with or without main-machine flight experience.
3. Once you start using this product, and deemed that you have read, understood, recognized and accepted this product full text and content of the explanatory note, disclaimer and safety must be known.
4. In the process of using this product, please strictly abide by and implement the included but unlimited in the Explanatory book and in Safety, you must know the requirements. For violations of security, it is necessary to know the use of the instructions Acts or acts may not be resistant to all human injuries, accidents, loss of property, and legal corrections caused by factors. The user is responsible for the conflict and other undesirable matters that create a conflict of interests. Ren and loss, our company and the agent do not live up to any of your responsibilities.
5. The user uses the product to produce hundreds of or indirect occurrences in violation of the provisions of the law, our company and the agency are not responsible for any responsibility.

TSRC

SAFETY MUST BE KNOWN

1. This product is not suitable for people under the age of 14 and others who are not competent for the full capacity of civil affairs soldiers.
2. This product has a high-speed rotating propeller and a strong flying force, which is used in operation. There is a certain degree of danger. Do not approach and touch the product while it is being transported.
3. When using this product, please stay away from the airport, railway, high-speed bus, high-rise building, power line, etc dangerous environment.
4. When using this product, please stay away from the mobile phone base station, high magnetic interference such as high power transmission equipment the environment.
5. When using this product, please stay away from various manned flyers.
6. Please do not use it in bad environments such as rain, lightning, sand, fog, snow, wind, and low temperature this product.
7. This product is not a water-proof design, please do not attach this product to the water area.
8. When operating this product, please always maintain the left and right of 10 meters between man-machine and human or animal safe distance away.
9. Please always keep no manned machine flying within the scope of the operator's vision.
10. Do not hover or leap over the crowd of people, please do not take pleasure in frightening others.
11. Please do not make this product in the field where a few children play.
12. Please do not use this product to pursue the normal operation of traffic tools or influence communication tools.
13. In non-urgent situations, please do not turn off the power-off machine when the product is flying in the air.
14. This product should not be used under conditions such as tobacco and alcohol, fatigue, taking medicines, and physical discomfort. Please inspect this product before each use, including but not limited to the firmness of spare parts.
15. Solidity, cracks and wear on the body and propeller, battery capacity, effectiveness of the indicator light, etc. When you find abnormalities, stop using them immediately and swap them.
16. Abnormal work conditions of no human machine may be unexpected, do not start spinning strong flying line.


TSRC

SAFETY MUST BE KNOWN

17. Please do not try to stop any of the operational parts in the work of this product.
18. Please do not modify this product, or use this product for non-original purposes.
19. Please do not operate this product in the no-fly zone of laws and regulations.
20. Due to the large number of materials used in the aircraft, high temperature will damage the internal structure of no man machine. And lead to unpredictable consequences, so please keep unmanned equipment away from heat sources and avoid unmanned machines for a long time, it was exposed to direct sunlight.
21. Please follow the product description to conduct the operation.
22. Please use the original parts for maintenance and replacement.
23. To transfer the past to others, please ensure that the operator understands and abides by the safety of the people.
24. can not be mixed with different types of batteries.
25. Do not use swollen, exposed or damaged batteries.
26. When the battery is charged, please do not approach flammable objects (such as carpets, solid wood furniture and wooden floors, etc.)
27. Please use the original charging line to charge, please do not use other brands and damaged charging lines charge.
28. Please keep a safe distance from the high-speed rotating screw rotor to avoid the risk of strangulation and cut.
29. The model should not be used close to the ear! Misuse of the possibility can lead to hearing impairment.
30. The flying machine should be used as far away as possible from other electrical equipment and magnetic objects, they can create mutual interference.
31. Please do not short circuit, squeeze the battery, to avoid explosion.
32. The electric machine is a heating part, please do not touch it, so as to avoid the danger of permation.


TSRC

INCLUDED IN PACKAGE




TSRC

INTRODUCTION TO FLYERS




REMOTE CONTROLLER INTRODUCTION



TSRC

FLIGHT INFORMATION


1 Propeller



Please, according to the diagram, ensure that all the propellers are installed in the correct position, and if the installation is wrong, the flyer will not be able to fly normally.

TSRC

2 Camera head




1. Tap the button on the remote control, or click the button on the APP interface. When you hear a voice prompt, the APP makes a "click" sound, indicating that the camera takes a photo.
2. Long press the button on the remote control, or click the button on the APP; you will hear a voice prompt, and the recording time will be displayed on the APP, indicating that the camera is recording.
3. Long press on the remote control again or click on the APP to stop recording and save the video to the APP and TF card.
Notes:
When using the "TSRC" APP, the camera captures the original image and video are compacted and saved on the phone.

4. The original pictures and videos captured by the camera will be saved on the TF card.
Tap the TF card on the camera to remove the TF card. After loading the TF card into the card reader, connect the card reader to the USB port on the computer to read the data on the TF card. You can click the button on the APP to read the captured pictures and videos.


TSRC

3 Mobile phone support




TSRC

4 Installation battery



As shown in the figure above, the flying cell is loaded into the battery compartment at the rear of the fuselage.


5 Remote control battery



1. As shown in the figure above, the USB charging cable and the charging socket of the flying machine can be connected together.
2. When the battery is charged, the indicator light on the battery is red; When the battery is full, the indicator light is always on.
3. The charging time of the flying machine battery is about 3 hours, depending on the charging source.
▲ Note:
When the drone is at low power, the APP mentions "drop", "drop", "drop", please stop the flight as soon as possible, and charge the drone call. Before charging, please read the relevant provisions that you need to know about safety!

TSRC

BATTERY CHARGING INSTRUCTIONS






1. As shown in the figure above, the USB charging cable and the charging socket of the flying machine can be connected together.
2. When the battery is charged, the indicator light on the battery is red; When the battery is full, the indicator light is always on.
3. The charging time of the flying machine battery is about 3 hours, depending on the charging source.
▲ Note:
When the drone is at low power, the APP mentions "drop", "drop", "drop", please stop the flight as soon as possible, and charge the drone call. Before charging, please read the relevant provisions that you need to know about safety!

TSRC





FLYING EXERCISES ARE GUIDED

1 Pre-flight settings






TSRC

2 One-key takeoff/landing/emergency landing






TSRC

3 Manual landing







TSRC

4 Forward/backward fine-tuning





TSRC

5 Speed switch






TSRC

6 Turn around






TSRC

7 headless mode




TSRC

8 fly around





TSRC

9 APP installation and operation APP







TSRC

BASIC PARAMETER INFORMATION



TSRC

APP/real-time image transmission



TSRC

10 USB charging cable

