

Walkie Talkie User Manual




Before using this product,
please read the user manual carefully.

The manual is for reference only;
actual operation shall be based on the physical product.

1. Product structure

Product description



- 1) ON/OFF
- 2) Vol./Next functional menu.
- 3) Vol.+/Previous functional menu.
- 4) 180° Rotation of the lens.
- 5) Shortly press "return to the previous menu". During Video Talking, keep pressing it to enter "Tone-changing Mode".
- 6) Microphone.
- 7) Tether.
- 8) Shortly press "Confirm", keep pressing "Walkie-Talkie".
- 9) Type-C charging port.
- 10) Charging indicator light.

2. CSwitch-ON/OFF function

1. When this product leaves the factory, the ON/OFF power switch is under the "OFF" position.
2. Turn the power switch to "ON" to switch on.
3. When using this product for the first time, please do fully charge it.

3. Charging indication

1. Use the charging cable included in this product, connect it to the charger and the power indicator "red light" will be "ON". When fully charged, the charging indicator light will automatically turn off.
2. Specification adaptable to this charger: DC 5V/1.0A.

4. Introduction to basic operation of the keys and functions

1. Turn the power switch to the "ON" position and this product will automatically switch on and enter the Main Interface.



- ① Video-talking
- ② Game
- ③ Camera
- ④ Photo album

2. When the other player's Walkie-talkie is under the "ON" state, Video Talking is defaulted. One player presses the Key 8 to make a call and the other player also presses the Key 8 to answer. Both players will automatically connect and display the images of each other.
3. After connecting the Video-talking, please keep pressing it to initiate voice talking function, keep pressing it for talking while release to finish talking and send out tone message.
4. Short press the 5 key to return to the main interface, long press the 5 key to enter voice changing mode, long press the 8 key to apply voice changing, and press the 5 key again to switch to the next tone color and there are three modes to choose from.
5. Keep pressing Key 8 to conduct voice talking. This product Talking Party ends the conversation by releasing the Walkie-talkie key can the Receiving Party press the Walkie-talkie key to send out the voice messages.
6. Long press the 3 key to switch the video window display, and you can adjust four display modes.
7. Volume Adjustment, Vol.+/-:
 - 1) Shortly press the Key "2" to turn down the volume.
 - 2) Short press the Key "3" to turn up the volume.
8. Switch-off of the product:

When this product is not used, please pull the toggle switch to the "OFF" position.
9. Decoding and connecting methods of the products:

2.4G transmission and reception method are applied on this product.

2 pieces of Walkie-Talkies are included in each package.
10. Game mode:

Press the Volume +/- key to select and move to 2). Press the Confirm/ Walkie-talkie Key to enter the Game Mode.

- 1) Shortly press the Vol.+/- key to move up and down.
- 2) Shortly press Key 5 to return to the Main Interface.

11. Camera Mode:

Shortly press the Volume+/- key to move to 3). Press the Confirm/Walkie Talkie key to enter Camera Mode.

- 1) Shortly press the Confirm/Walkie-talkie key to take a photo.
- 2) Shortly press the Key 5 to return to the Main Interface.

12. Album Mode

Shortly press the Volume +/- key to move to 4). Shortly press Confirm/ Tone-changing key to enter Album Mode.

- 1) Shortly press Volume +/- key to move left or right to select an image.
- 2) Keep pressing the Confirm/Tone-changing key to appear the Delete Menu, shortly press the Volume +/- key to choose whether to delete one or all pictures.
- 3) Shortly press the Key 5 to return to the Main Interface.

5. Product Specifications

Function	Parameter Specification
Screen	2.0 Inch
Connect	2.4G transmission and reception
Lens	SP0A39 pixel: 30W
Battery capability	3.7V 500mAH
language	English
Operating temperature	-20°C ~ 60°C
Storage temperature	-0°C ~ 40°C
Effective transmission distance	About 100-300 meters(Under barrier-free conditions.)
Product size	109*55*27.5mm
Net weight	58.3 g
Charging time	About 120 minutes
Battery life	150 min

Caution: We reserves every right to change its design and specifications with or without prior notice.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.