



正面



背面



After logging into the settings interface, it is recommended to change the administrator password to "Quick Setting" and remember it. The new administrator password cannot be the same as "admin". When logging in a please use the administrator password you set yourself, which is the password entered in the settings page, not the WiFi password.