

User manual



Enjoy it.

Safety Precautions

Read these safety instructions before using your device and store them for possible future reference.

- The device should not be exposed to dripping or splashing water.
- CAUTION: Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent.
- The battery should not be exposed to excessive heat such as sunshine, fire or similar.
- Different types of batteries, new and used batteries should not be mixed.
- The battery must be installed according to the polarity.
- If the battery is worn, it must be removed from the product.
- The battery must be disposed of safely. Always use the collection bins provided (check with your dealer) to protect the environment.
- The battery can't be replaced by the user, but only by the maker of this product, the after sales department or a qualified person.

Specifications

Modelo :H21T
Bluetooth Version: V 5.1
Bluetooth Range: 10meters
Playback time: 2-3 hours
Charging time: 1 hour
Standby time: 100 hours

Accessories:

- 1*user manual
- 1*type-c charging cable

Turning on/off /pairing

The headset is automatically turned on after it is removed from the charging box. At the same time, the voice prompts "turn on" (or press both headphones for 1.5 seconds). The lights are red and blue. Put the earplug into the charging box and close it (or press the two earplugs for 6 seconds). The right "L" alternately flashes red and blue rapidly, and the "R" flashes blue every 5 seconds.

- 1) when two earplugs are removed from the charging case, they are automatically paired and the sound information is "connected" between the two earplugs.
- 2) open the bluetooth of the mobile phone, search for (H21T), and click connect. After successful connection, the voice message "connected" will be displayed, and the indicator light will flash blue every 5 seconds.
- 3) when the two earplugs are removed again, they are automatically connected to the phone.

Ear pod touch function

press	Left ear pod	Right ear pod
Long press	Power on/off	Power on/off
Single press	Play/pause answer/End a call	Play/pause answer/End a call
Medium press(2 seconds)	Next track	Previous track

function	press
reject a call	Call status Double press
Redial last number	Double press

Charging

when earbuds in low in power ,sound message "lower battery please change", The light will flash red every 5 seconds. At this time, please put earbuds into the charging box to charge. The LED of earbuds lighting red, and lighting blue after full charged, the led light of charging box lighting blue, and light off when earbuds full charged.

when the power is lower of the charging box, the led light and flash with blue. At this time, please use the micro USB cable, connect the charging box and the other end connect to computer or other charger for charging. When charging, the blue light flashes and the fully charged indicator light is always on.

Made in China



尺寸：200x85MM 80克双铜纸 4C单面印刷 风琴折

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.