



Product Warranty Certificate

Product	Around View(3D AVM)	Model	IV-300 / 360
Manufacturer	ACEVIEW Co. Ltd.		
Installation Date	20 YY MM DD		
Customer Information	Name :		
	Phone Number :		
Place of Purchase			

 Authentication Number : MOV-19-EMC-K096

● Service regulation & Technical support

1. Grant Warranty

▶ On occasion of malfunction under normal use within 1 year of product purchase date.

▶ Every component except Camera and main ECU body is consumables, and the warranty period of those is 6 months.

▶ Data saved on the storage is not under warranty. Make sure to back up all the important data.

※ There may be difference on warranty period modified but negotiation when signing a contract.

2. Paid Service

▶ When warranty period has passed.

▶ On occasion of malfunction caused by customer's carelessness (fall, shock, damage, excessive manipulation, move, etc.)

▶ Malfunction caused by natural disaster (fire, gas, earthquake, thunderstorm, hurricane, etc.)

▶ Malfunction caused by the power source

▶ Malfunction happened by other external cause, not by the product's quality or performance defect

▶ Malfunction caused by disassembling, fixing, or renovating the product without using the company's service window

▶ When losing the warranty card or certificate

▶ Malfunction caused by not correctly following instruction and precaution guide

▶ When requesting service that is not due to malfunction of the device

● Customer Service

ACEVIEW Co. Ltd. guarantees our products in accordance with the Consumer Damage Compensation Regulations. In case of service requests, customer service center would be supporting the consumer. Updates are available when necessary to improve product performance and quality.

Postal Code : 14952

Address : #607, 25, Podowon-ro 116beon-gil Siheung-si, Gyeonggi-do, Republic of Korea

service@aceview.kr

Phone No.: 1544 - 7346

Caution

- Please park (stop) at a safe place before operating or controlling the device.
- When **restarting** the vehicle, **be sure to turn on the key after at least 30 seconds have elapsed to prevent the possibility of 'No signal'.**
- The video input method of the **monitor must be HDMI to display the screen.**
- If 'REC' at the top right of the monitor screen is not visible, try formatting the SD card or external HDD before use.
- If the video not display on the screen, check the connection status of the **HDMI cable between the monitor and the ECU body.**
- This product is a **driving assistance video device for safe driving**, and since the lens has a wide angle of view, the quality of the recorded video may change depending on the ambient brightness of the camera and the surrounding environment.
(Keep the camera lens clean at all time.)
- We are not responsible for the quality, recording, and management of the recorded video; either civil or criminal.
- Memory SD card and external HDD are subject to the quality and warranty policy of the component supplier.

Caution on Memory

- Since memory cards are consumable products, they have a read/write lifespan due to the nature of the memory.
- Please note that we are not responsible for any recording errors caused by outdated memory.
- In case of memory, SD card can support up to 256GB, and external SSD/HDD can support up to 2TB.
- We recommend that you purchase and use an MLC / Class 10 memory card. Compatibility problems may occur.



Quick User Manual

www.aceview.kr

Screen Icon(UI)

	Exit (off)
	Play Recorded Video
	Switch Monitor Screen
	Device Setting (A/S expert only)
	Date / Time Format

Remote Control

	Open icon
	Select / Start
	Left / Right Key
	Up / Down Key


※ When the remote control battery replacement cycle is over., the remote control may not work (CR-2025 1ea)

1. How to format SSD card or external HDD


Press  button and choose the UI of the following



→ Select far right button.



→ Select "Format" at the very bottom of the menu options.



→ Select "YES".

→ After "Format Complete" ECU will reboot.

→ After the restart, if you can see "REC" on the far top right corner of the monitor, it means it's properly working.

2. How to switch view mode

Press  button and choose the UI of the following



→ Select the third icon from the left.



→ Select monitor screen by using(◀/▶) key.



→ Use "OK" key to select, and press  button to exit.

3. How to change Time / Date

Press  button and choose the UI of the following



→ Select the far right option

→ Select "Date&Time Setting"

→ Use up / down / left / right key to modify the time and date.

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.