




ENGLISH
INSTRUCTION MANUAL

***IMPORTANT:** PLEASE DO NOT RETURN TO STORE
For more information please contact Customer Services: help@hypertoys.com




- Always store batteries in a safe place. Keep out of reach of children who are under the recommended age.
- Ask parents/guardians for help when replacing the batteries.
- ① Turn off the switch, open the battery cover.
- ② Install batteries accurately in the battery compartment and ensure to place batteries as marked with / .



CAUTIONS:
Any improper use of batteries might lead to liquid leakage, heat and splits. Pay attention to the following items:

- (1) Do not use new batteries and old ones at the same time.
- (2) Do not use batteries of different brands at the same time.
- (3) Do not install batteries to wrong+ or - poles.
- (4) When installing the battery, gently push it upward at an angle of 30 degrees with the tip of one finger.

- Always store batteries in a safe place. Keep out of reach of children who are under the recommended age.
- Ask parents/guardians for help when replacing the batteries.
- ① Turn off the switch, open the battery cover.
- ② Install batteries accurately in the battery compartment and ensure to place batteries as marked with / .



When the battery is low, the car will slow down, please replace the battery promptly.

THE USAGE INSTRUCTIONS AND PRECAUTIONS:

1. Make sure children play under adult supervision. Do not put small parts in the mouth to avoid swallowing them.
2. Do not expose it to fire. It does not have an ultraviolet radiation function.
3. This product contains small parts and is not suitable for children under 3 years.
4. Keep away from fire and avoid direct ultraviolet radiation.
5. Non-rechargeable batteries are not to be recharged.
6. Rechargeable batteries are only to be charged under adult supervision.
7. Exhausted batteries are to be removed from the toy.
8. The supply terminals are not to be short-circuited.




This device complies with the Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

Safety Precautions:

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Adult supervision is recommended when operating this car.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your car in a confined or crowded area and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight.
- Dampness is harmful to interior components.



WARNING: This toy produces flashes that may trigger epilepsy in sensitized individuals.

This product contains a battery that is non-replaceable.

CALIFORNIA PROPOSITION 65 WARNING:
This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



WARNING:
CHOKING HAZARD-Small parts.
Not for children under 3 years.

DISTRIBUTED BY:
HYPER TOY COMPANY
1-866-204-9737 Toll Free
177 Malaga Park Dr. Malaga, NJ 08328

HYPER TOY CO.
help@hypertoys.com

© Copyright 2025. HyperToys

MADE IN CHINA

