

ENGLISH
INSTRUCTION MANUALROLLER WHEEL
DRIFT CAR

***IMPORTANT:** PLEASE DO NOT RETURN TO STORE
For more information please contact Customer Services: help@hypertoys.com



This device complies with the Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

CALIFORNIA PROPOSITION 65 WARNING:
This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.



DISTRIBUTED BY:
HYPER TOY COMPANY
1-866-204-4737 Toll Free
177 Malaga Park Dr. Malaga, NJ 08228
HYPER TOY
help@hypertoys.com

© Copyright 2025. HyperToys

MADE IN CHINA




BATTERY SAFETY



- (1) The placement or replacement of batteries is to be performed by an adult.
- (2) Remove the rechargeable battery from the chassis before charging.
- (3) Always remove exhausted batteries from the car and the transmitter.
- (4) Make sure the main switch is set to OFF before installing the battery pack into the car body.
- (5) Batteries must be inserted with the correct polarity.
- (6) Non-chargeable batteries shall not be recharged.
- (7) Do not short-circuit the batteries.
- (8) Always remove the batteries from the car and the transmitter after playing.
- (9) Never throw the batteries into fire to avoid explosion or leakage.
- (10) Do not mix batteries from different producers or new and old batteries.
- (11) You should only use batteries of the same or equivalent types as recommended.
- (12) Check the batteries on a regular basis to avoid leakage.
- (13) Keep this manual well for future reference as it contains important information about this product.



Battery installation



Replace the battery
Remote control unit




Product Operation Manual

Thank you for choosing our product! Please read this instruction manual carefully before using, as it contains all the information you need to know about how to use this product correctly with fun.





1. Open the battery cover on the car, install 1* 7.4V rechargeable battery pack, fasten the cover and turn the switch to "On".
2. Open the battery cover on the controller, install 2* 1.5V AA battery, fasten the cover and turn the switch to "On".

Colors And Contents May Vary From Illustration.



MADE IN CHINA

Basic Product Operations



USB charging: about 3.5 hours;
Running time: about 20 minutes;
Control distance: about 25M;
Current and voltage :500MAH, 7.4V;

WARNING
When the car does not respond to control, please turn off the power first, and then pair again according to the previous steps.

