

中

Monster Airmars XK013
真无线蓝牙耳机
使用说明书

产品参数

- 蓝牙版本-----V5.4
- 传输距离----->10m
- 喇叭直径-----Φ13mm
- 喇叭阻抗-----16Ω±15%
- 灵敏度-----117±3dB
- 频率范围-----50Hz-20KHz
- 电池容量(充电盒)-----400mAh 3.7V
- 充电容量(耳机)-----45mAh 3.7V
- 充电时间(充电盒)-----≈2小时
- 播放时间(耳机)-----≈5小时
- 配合充电盒播放时间-----≈25小时

包装清单

耳机*2

使用说明书*1

充电盒*1

Type-C充电线*1

产品示意图

指示灯

功能触摸键(MPB)

耳机

充电触点

充电盒

Type-C

给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。

额定输入: 5V=45mA(耳机) 额定输入: 5V=400mA(充电盒)

温馨提示: 当关闭充电盒盖, 充电盒指示灯呈蓝灯闪烁, 请给充电盒充电。

指示灯指南

模式	描述	语音提示
开机	耳机冰蓝指示灯闪烁3次	"Power on"
关机	耳机红灯指示灯长亮3秒熄灭	"Power off"
配对	耳机冰蓝红灯灯交替闪烁	"Pairing"
连接	耳机指示灯熄灭	"Connected"
断开	耳机冰蓝指示灯交替闪烁, 蓝灯熄灭	"Disconnected"
耳机低电	耳机红色指示灯闪烁	"Battery low"
充电盒低电	充电盒冰蓝指示灯长亮	---
耳机充电	充电盒冰蓝指示灯闪烁	---
充电盒低电	充电盒黄色指示灯闪烁	---
充电盒充电	充电盒红色指示灯闪烁	---
充电盒充满	充电盒红色指示灯长亮	---

产品操作说明

1. 开机
方式一: 打开充电盒上盖, 耳机自动开机;
方式二: 长按左/右耳机的MPB按键约3秒, 耳机开机。
2. 关机
方式一: 将耳机放回充电盒中, 合上充电盒上盖, 耳机自动关机;
方式二: 与蓝牙设备断开连接约3秒后, 自动关机。
3. 配对
步骤一: 打开充电盒上盖, 耳机自动开机;
步骤二: 打开智能设备的蓝牙列表, 搜索 "Monster Airmars XK013" 进行配对, 连接成功后, 你会听到语音提示 "Connected"

* 超出距离, 在断开连接3分钟后, 回到有效距离, 自动连接设备。

注意:
* 如果产品长时间不使用, 应先充满电, 并确保设备处于关机状态。
* 充电完成后, 请将充电线拔出, 避免长时间的充电造成设备损坏。

触控操作

常闭模式

语音助手: 长按2秒左耳机MPB
音量加: 单击右耳机MPB
音量减: 单击左耳机MPB

音乐播放模式

暂停/播放: 双击左/右耳机MPB
上一曲: 三击左耳机MPB
下一曲: 三击右耳机MPB

电话免提

接听: 双击左/右耳机MPB
挂断: 双击左/右耳机MPB
拒接: 长按2秒/右耳机MPB

游戏模式/音乐模式切换: 已连接设备

游戏模式: 长按2秒右耳机MPB进入游戏模式
音乐模式: 长按2秒右耳机MPB进入游戏模式

恢复出厂设置

耳机启动后与蓝牙设备配对状态下, 左/右耳机配对成功, 连接左/右耳机5次左左/右耳机关机 (清除配对和连接的所有信息)

注意

- 1.从充电盒取出耳机, 不要任何触摸, 耳机自动开机, 连接或配对, 耳机插入充电盒,充电盒将自动关机并充电, 耳机关机。
- 2.请远离: 磁场, 强电, 强磁环境, 建议15天内充电1次, 延长电池寿命, 耳机需充电部分使用请避免潮湿环境, 避免液体接触耳机, 避免接触金属, 影响使用体验。
- 3.请勿将耳机或充电盒放在高温处暴晒, 长时间使用或长时间存放, 请取出耳机, 防止过热, 防止造成火灾, 4.由于本产品采用无线充电方式, 在日常使用过程中, 充电器端、手机端、使用行为等因素影响, 可能导致充电效率下降, 会出现发热, 轻微的充电卡顿了属正常现象。

警告

- 1.避免将耳机或充电盒长时间暴露在阳光下, 建议只将充电盒放在阴凉处, 避免阳光直射。
- 2.请勿将耳机或充电盒放入水中, 以免造成损坏。
- 3.不要自行拆卸产品及其附件, 以免导致损坏及保修失效。
- 4.请勿将产品暴露在明火或高温环境中使用。
- 5.请勿将化学溶剂或清洁剂喷洒在产品上。

Hazardous Substances

Name of the Parts	Fluorine	Lead	Cd	Cu	Pb	Pb	Pb
Housing	0	0	0	0	0	0	0
Speaker	0	0	0	0	0	0	0
Microphone	0	0	0	0	0	0	0
PCBA	0	0	0	0	0	0	0
Accessories	0	0	0	0	0	0	0

This table is compiled according to SJ/T 11364.
0: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
Note: The hazardous substance is not contained in the product, but it is contained in the packaging materials.

FCC 声明

根据FCC规则第15部分, 本设备经过测试, 符合B类数字设备的限制。这些限制旨在提供合理的住宅设备中的有害干扰防护。该设备产生使用并可能发射射频能量, 如果未按指定安装和使用该设备可能会对无线电通信造成有害干扰。然而, 有不能保证在特定安装中不会发生干扰。如果这个设备对无线电通信接收造成有害干扰, 可通过以下措施来避免: 重新定位或重新安装接收天线。
-避免将设备与接收天线之间的物理距离。
-将设备连接到与接收器不同的电路上的插座以获得帮助。
-请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。
此设备符合FCC规则的第15部分, 操作受以下两个条件限制:
(1) 本装置不得引起有害干扰。
(2) 本装置必须接受任何接收到的干扰, 包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用户对设备的操作失效。
FCCID: 2ABPV-QSMXX013
Environment Friendly Use Period (EFUP)
This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these (substances) will not result in any severe environmental pollution, any bodily injury or damage to any assets.
这标志指的是期间 (10年) 是电子电气产品中有毒物质在正常使用的条件下不会发生泄漏或突变, 电子电气产品用户使用该电子电气产品不会对环境污染或严重污染或对其人身、财产造成严重损害。

保修卡

尊敬的客户, 本保修卡是您购买本产品的凭证, 请妥善保管并作为保修依据!

用户信息

用户名

电子邮箱

联系电话

联系地址

产品信息

产品名称

产品型号

产品条码/编号/批号

销售信息

名称

地址

联系电话

销售日期

备注

合格证

产品型号: _____
生产日期: _____
合格证号: _____

英

Monster Airmars XK013
True wireless Bluetooth headphone
instruction manual

Product parameters

- Bluetooth version-----V5.4
- Transmission distance----->10m
- Driver diameter-----Φ13mm
- Driver impedance-----16Ω±15%
- sensitivity-----117±3dB
- Frequency response-----50Hz-20KHz
- Battery capacity(Charging case)-----400mAh 3.7V
- Battery capacity(Headphone)-----45mAh 3.7V
- Charging time(Charging case)-----≈2 hours
- Music playtime(Headphone)-----≈5 hours
- Music playtime with charging case-----≈25 hours

Product Schematic Description

Headphone*2

Instructions Manual*1

Charging case*1

Type-C Charging cable*1

Product Schematic Description

Indicator

Multi-function buttons(MPB)

Headphones placed in charging case

Charging case low power

Charging case charged

Charging case fully charged

Type-C

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.

Rated input: 5V=45mA(Headphone) Rated input: 5V=400mA(Charging case)

TPPS: When the cover of the charging box is closed, the indicator light of the charging box flashes for 3s, please charge the charging box.

Indicator guide

Mode	Describe	Sound prompt
Power On	Ice blue light of the headset blinks three times	"Power on"
Power Off	Red indicator light on the headphones remains on for 1 second and goes off	"Power off"
Pairing	Ice blue and red lights of the headset flash alternately	"Pairing"
Connected	Headphones LED indicator is off.	"Connected"
Disconnected	Ice blue and red light flashes alternately in the main ear, and the secondary ear is extinguished	"Disconnected"
Low Battery	Headphones placed in charging case	Red indicator on the headset blinks
Headphones placed in charging case	Blue indicator of the charging case blinks	"Battery low"
Charging case low power	Red indicator of the charging case blinks	---
Charging case charged	Red light of the charging case is bright	---
Charging case fully charged	Red light of the charging case is bright	---

Product operating instructions

1. Power on
Method 1: Open the top cover of the charging case, and the headset will turn on automatically.
Method 2: Long press the MPB button of the left/right headset for about 3 seconds to power on the headset.
2. Power off
Method 1: Put the earphone back in the charging case, close the cover of the charging case, and the earphone will automatically shut down.
Method 2: The device automatically shuts down after 3 minutes of disconnection from the Bluetooth device.
3. Pairing
Step one: Open the top cover of the charging case, and the headset will turn on automatically.
Step two: Open the Bluetooth list of smart devices, search for "Monster Airmars XK013" to pair, and the connection is successful after that, you will hear the "Connector" tone.
* Headphones will try reconnecting to the device within 3 minutes when connection is lost.

NOTE:
* Fully charge the headphones and power off before an intended not-in-use period.
* Unplug the charging cable after charging.

Operation

Normal

Voice Assistant: Press and hold left MPB for 2 S
Volume +> Click right MPB
Volume -< Click left MPB

Music playback

Pause/Play: Double click Left/Right MPB
Last song: Three hits left MPB
Next song: Three hits right MPB

Phone

Answer: Double click the left/right MPB
Hang up: Double click the left/right MPB
Reject: Long press left/right MPB for 2 S

Game mode/Music mode switch: Connected device

Game mode: Press and hold right earphone MPB for 2 secondenter Game mode
Music mode: Press and hold right earphone MPB for 2 secondenter Music mode

Restore factory settings

When you turn on the headphone, make sure it does not connect to any Bluetooth device, and click the MP button 5 times to clear the pairing record, then turn off the headphone.

Precautions

1. Take out the earphone from the charging box, without pressing any button, the earphone will automatically turn on, connect or pair out the earphone into the charging box, and the charging box will automatically charge your headphones. Turn them off.
2. Often clean, long life, if not used for a long time, it is recommended to charge once every 15 days to extend battery life, and the charging part of the headset is often used with cotton swabs. Alcohol wipe, can help smooth charging, avoid bad contact, affect the use experience.
3. The battery (battery pack or battery combination) shall not be exposed to lightning, baking or similar overheating environment. Do not disassemble, knock, squeeze or throw in the fire, if there is serious swelling, do not continue to use. Do not place in high temperature environment. Do not use after soaking water.
4. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use it may be normal to have a brief, slight sound delay during the playing of music.

Warnings

1. Do not use headphones at high volume for an extended period of time.
2. Keep the headphones away from dust and water.
3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Hazardous Substances

Name of the Parts	Fluorine	Lead	Cd	Cu	Pb	Pb	Pb
Housing	0	0	0	0	0	0	0
Speaker	0	0	0	0	0	0	0
Microphone	0	0	0	0	0	0	0
PCBA	0	0	0	0	0	0	0
Accessories	0	0	0	0	0	0	0

This table is compiled according to SJ/T 11364.
0: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5cm between the radiator and your body.
FCCID: 2ABPV-QSMXX013
Environment Friendly Use Period (EFUP)
This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these (substances) will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name

Email

Contact number

Postal code

Mailing address

Product information

Product name

Product number

Product barcode / Serial number / Batch number

Vendor information

Name

Address

Contact number

Postal code

Sale date

Invoice number

Remark

合格证

Product No.: _____
Production Time: _____
QC: _____

文件名称	魔声XKO13说明书			材料	全书60g书纸+单黑印刷+骑马钉		单位	mm	厂商物料编号		变更履历		修改		日期	
文件尺寸	60X90mm (单P尺寸)			工艺	1C印刷 风琴折		公差	± 0.5mm	XXXXXXXXXX		02:修改指示灯低电说明		审核		日期	
设计日期	2023/12/21	文件版本	2023V03				比例	1:1					批准		日期	