


中

MONSTER



Monster Airmars XKT19

真无线蓝牙耳机  
使用说明书


#### 产品参数

- 蓝牙版本 ----- V5.4
- 传输距离 ----- 10m
- 喇叭直径 -----  $\Phi 10\text{mm}$
- 喇叭阻抗 -----  $32\Omega \pm 15\%$
- 灵敏度 -----  $106 \pm 3.0\text{dB}$
- 频率范围 -----  $20\text{Hz} - 20\text{kHz}$
- 电池容量 (充电盒) -----  $300\text{mAh } 3.7\text{V}$
- 电池容量 (耳机) -----  $35\text{mAh } 3.7\text{V}$
- 充电时间 (充电盒) -----  $\approx 1.5\text{小时}$
- 播放时间 (耳机) -----  $\approx 5\text{小时}$
- 配合充电盒播放时间 -----  $\approx 22\text{小时}$

#### 包装清单


|  |                  |  |              |
|--|------------------|--|--------------|
|  | 耳机 *2            |  | 充电盒 *1       |
|  | 使用说明书 *1         |  | Type-C充电线 *1 |
|  | 耳帽 L*2<br>耳帽 S*2 |  |              |

#### 产品示意图



#### 给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。



温馨提示：当关闭充电盒盖，充电盒指示灯呈红灯闪烁5次，请给充电盒充电。

#### 指示灯指南

| 模式       | 描述                                      | 语音提示           |
|----------|-----------------------------------------|----------------|
| 开机       | 耳机冰蓝色指示灯闪烁3次                            | "Power on"     |
| 关机       | 耳机红色指示灯长亮15熄灭                           | "Power off"    |
| 配对       | 耳机冰蓝色指示灯交替闪烁                            | "Pairing"      |
| 连接       | 耳机指示灯熄灭                                 | "Connected"    |
| 断开       | 耳机冰蓝色红色指示灯交替闪烁                          | "Disconnected" |
| 耳机低电     | 耳机红色指示灯快速闪烁                             | "Battery low"  |
| 充电盒给耳机充电 | 耳机冰蓝色指示灯常亮，充电电量熄灭<br>充电盒冰蓝色指示灯常亮，充满电量熄灭 | —              |
| 充电盒充满    | 充电盒红色指示灯亮                               | —              |
| 充电盒充电    | 充电盒红色指示灯闪烁                              | —              |
| 充电盒低电    | 充电盒冰蓝色指示灯快速闪烁至熄灭                        | —              |

#### 产品操作说明

##### 1. 开机

- 方式一：打开充电盒盖，耳机自动开机。
- 方式二：长按功能触摸键3秒，耳机开机。


##### 2. 关机

- 方式一：将耳机放回充电盒，关上充电盒盖，耳机关机。
- 方式二：与蓝牙设备断开连接3分钟后，耳机自动关机。

#### 3. 配对

- 步骤一：打开充电盒盖，耳机自动开机。
- 步骤二：打开智能设备的蓝牙列表，搜索 "Monster Airmars XKT19" 进行配对，连接成功后，你会听到提示音 "Connected"

- \* 超出距离，在新连接3分钟内，回到有效距离，自动连接设备。



#### 注意：

- \* 如果产品长时间不使用，应先充满电，并确保设备处于关机状态。
- \* 充电完成后，请将充电线拔出，避免长时间充电造成设备损坏。


#### 触控键操作

##### 常规模式

- 语音助手：长按2秒左耳机MFB
- 音量加：单击右耳机MFB
- 音量减：单击左耳机MFB

英

MONSTER



Monster Airmars XKT19

True wireless Bluetooth headphone  
instruction manual


#### Product parameters

- Bluetooth version ----- V5.4
- Transmission distance ----- 10m
- Driver diameter -----  $\Phi 10\text{mm}$
- Driver impedance -----  $32\Omega \pm 15\%$
- Sensitivity -----  $106 \pm 3.0\text{dB}$
- Frequency response -----  $20\text{Hz} - 20\text{kHz}$
- Battery capacity(Charging case) -----  $300\text{mAh } 3.7\text{V}$
- Battery capacity(Headphone) -----  $35\text{mAh } 3.7\text{V}$
- Charging time(Charging case) -----  $\approx 1.5\text{ hours}$
- Music playtime(Headphone) -----  $\approx 5\text{ hours}$
- Music playtime with charging case -----  $\approx 22\text{ hours}$

#### Product Schematic Description


|  |                                                |  |                         |
|--|------------------------------------------------|--|-------------------------|
|  | Headphone*2                                    |  | Charging case*1         |
|  | Instructions Manual*1                          |  | Type-C Charging Cable*1 |
|  | Silicone Earbuds S *2<br>Silicone Earbuds L *2 |  |                         |

#### Product Schematic Description



#### Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.



TIPS: When charging case closed and the LED flash red 5 times,pls charging the charging case.

#### Indicator guide

| Mode                               | Describe                                                                                                                                                             | Sound prompt   |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| Power On                           | The ice blue light of the headset blinks three times                                                                                                                 | "Power on"     |
| Power Off                          | The red indicator on the headset is on for 1S and off                                                                                                                | "Power off"    |
| Pairing                            | The ice blue and red indicators of the headset blink alternately                                                                                                     | "Pairing"      |
| Connected                          | Headphone light off                                                                                                                                                  | "Connected"    |
| Disconnected                       | The ice blue and red indicators of the headset blink alternately                                                                                                     | "Disconnected" |
| Low Battery                        | The red indicator on the headset blinks rapidly                                                                                                                      | "Battery low"  |
| Headphones placed in charging case | Headset ice blue indicator light is on, fully charged off<br>The ice blue indicator light of the charging case is steady on, and it is turned off when fully charged | —              |
| Charging case fully charged        | The red indicator of the charging case is steady on                                                                                                                  | —              |
| Charging case charged              | The red indicator of the charging case blinks                                                                                                                        | —              |
| Charging case low power            | The ice blue indicator light of the charging case blinks rapidly until it goes off                                                                                   | —              |

#### Product operating instructions

##### 1. Power on

- Method 1: Open the charging case,the headphones will turn on automatically.
- Method 2: Long touch the MF button of the headphones for 3s to turn on the headphones.


##### 2. Power off

- Method 1: Put the headphones into the charging case and close the cover.
- Method 2: After disconnected from the Bluetooth device for 3 minutes.

#### 3. Pairing

- Step one: Open the charging case, the headphones will start pairing automatically.
- Step two: Open the Bluetooth list of smart devices, search for "Monster Airmars XKT19" to pair, and the connection is successful. After that, you will hear the "Connected" tone

- \* Headphones will try reconnecting to the device within 3 minutes when connection is lost



#### NOTE:

- \* Fully charge the headphones and power off before an intended not-in-use period.
- \* Unplug the charging cable after charging

#### Operation

##### Normal

- Voice assistant: Press the left MFB for 2 seconds
- Volume +: Click right MFB
- Volume -: Click left MFB

#### 音乐播放模式

- 暂停/播放：双击左/右耳机MFB
- 上一曲：三击左耳机MFB
- 下一曲：三击右耳机MFB

#### 电话免提

- 接听：双击左/右耳机MFB
- 挂断：双击左/右耳机MFB
- 拒接：长按2秒左/右耳机MFB

#### 游戏模式/音乐模式/ANC模式 切换：已连接设备

- 长按2秒右MFB进入游戏模式
- 长按2秒右MFB进入音乐模式
- 长按2秒右MFB进入ANC模式

#### 恢复出厂设置

- 方式一：开机未连接状态：连击左/右耳机5次后左/右耳机关机（清除配对和连接的所有信息）。
- 方式二：开机连接状态：左/右耳机连击5次，35s内长按10S，清除耳机与蓝牙设备之间的配对信息后关机。

#### 注意

- 充电盒开盖后，不需按任何按键，耳机自动开机。配对并连接：耳机放入充电盒并合盖后，充电盒将自动给耳机充电，耳机关机。
- 常清洁，寿命长，如长期不用，建议15天充电1次，延长电池寿命，耳机电量充电部分经常用棉签酒精擦拭，能够避免充电接触不良，影响使用体验。
- 电池(电池组成电池组合)不得暴露在明火、烘烤或类似过热的环境中，禁止拆解、撞击、挤压或投入火中，若出现严重鼓胀，切勿继续使用，切勿置于高温环境中，浸水后禁止使用。
- 由于本款产品采用无线连接方式，在日常使用过程中，受到环境、手机品牌、使用行为等因素影响，可能在播放音乐过程中，会出现短暂、轻弱的声音卡顿属于正常现象。

#### 警告

- 长时间以高音量使用耳机可能会损害您的听力，建议只使用适当音量收听、通话和听音乐。
- 请不要冲洗或将产品浸入水中，以免造成故障。
- 不要自行拆卸产品及配件，以免导致损坏及保修失效。
- 请勿使产品受到强烈冲击或震动以免损坏。
- 请勿将化学溶剂或清洁剂滴洒在产品上。

| Name of the Parts<br>部件名称 | Pb | Hg | Cd | Cr(VI) | PBB | PBDE |
|---------------------------|----|----|----|--------|-----|------|
| Housing<br>外壳             | O  | O  | O  | O      | O   | O    |
| Loudspeakers<br>喇叭单元      | O  | O  | O  | O      | O   | O    |
| PCBA<br>电路板组件             | X  | O  | O  | O      | O   | O    |
| Accessories<br>电源线、连接线    | X  | O  | O  | O      | O   | O    |

This table is compiled according to SJ/T 11364.  
本表格依据SJ/T 11364的规定编制。

- O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
- X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
- X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

#### FCC 声明

根据FCC规则第15部分，本设备经过测试，符合B类数字设备的限制。这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生并使用可辐射射频能量，如果未按照指定安装和使用该指示可能会对无线电信造成有害干扰。然而，有不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或电视接收造成有害干扰，可通过转动来确定设备，关闭和打开时，鼓励用户尝试通过一个或多个以下更多措施：

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的距离。
- 设备连接到与接收不同的电路上的插座已连接。
- 请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分，操作受以下两个条件限制条件。

- (1) 本装置不得引起有害干扰。
- (2) 本装置必须接受任何接收到的干扰，包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用户对设备的操作权限失效。

FCC ID: 2ABPV-QSMXKT19

- Environment Friendly Use Period (EFUP)  
环保使用年限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

此标志标识的期间(10年)是电子电气产品中有毒物质在正常使用条件下不会发生外泄或突变，电子电气产品在使用期间电子电气产品不会对环境和或严重污染对人体伤害，则产品造成严重损害的产品。

#### 保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

| 用户信息       |  |      |
|------------|--|------|
| 用户姓名       |  | 电子邮件 |
| 联系电话       |  | 邮政编码 |
| 通讯地址       |  |      |
| 产品信息       |  |      |
| 产品名称       |  | 产品型号 |
| 产品条码/编号/批号 |  |      |
| 销售商信息      |  |      |
| 名 称        |  |      |
| 地 址        |  |      |
| 联系电话       |  | 邮政编码 |
| 销售日期       |  | 发票号码 |
| 备 注        |  |      |



产品编号  
生产日期  
检验员

#### Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

| User info                                      |  |                |
|------------------------------------------------|--|----------------|
| User name                                      |  | Email          |
| Contact number                                 |  | Postal code    |
| Mailing address                                |  |                |
| Product information                            |  |                |
| Product name                                   |  | Product number |
| Product barcode / Serial number / Batch number |  |                |
| Vendor information                             |  |                |
| Name                                           |  |                |
| Address                                        |  |                |
| Contact number                                 |  | Postal code    |
| Sales date                                     |  | Invoice number |
| Remark                                         |  |                |



Product No.  
Production Time

QC: