


英



Monster Airmars XKT32

True wireless Bluetooth headphones
instruction manual

产品示意说明

指示灯

功能触摸键 (MFB)

耳机

Type-C

指示灯

充电盒

断开	耳机充电指示灯显示交替闪烁	"Disconnected"
耳机低电	耳机红色指示灯闪烁	"Battery low"
充电盒给耳机充电	充电盒冰蓝指示灯长亮	—
充电盒低电	充电盒冰蓝指示灯闪烁	—
充电盒充电	充电盒红色指示灯闪烁	—
充电盒充满	充电盒红色指示灯长亮	—

触控键操作

常规模式



- 语音助手：长按2秒左耳机MFB
- 音量加：单击右耳机MFB
- 音量减：单击左耳机MFB

耳机开机后未与蓝牙耳机配对状态下, 左/右耳机配对成功, 连击左/右耳机5次后左/右关机 (清除配对和连接的所有信息)

脚踏式开关							
PCBA 电路板组件	X	O	O	O	O	O	O
Accessories 电源插, 连接线	X	O	O	O	O	O	O

This table is compiled according to SJ/T 11364.
本表格依据 SJ/T 11364 的规定编制。

○ 指示该 hazardous substance contained in all of the homogeneous materials to part 1 below the line requires in GB/T 26572.

X 表示含有该物质在材料中有材料中含量超过 GB/T 26572 标准规定的限量要求。

○ 指示该 hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

X 表示含有该物质至少在材料中的一种材料中含量超过 GB/T 26572 标准规定的限量要求。

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

这标志标证的期间（10年）是电子电气产品中有有害物质在正常使用的条件下不发生外泄或突变。电子电气产品用户使用该电子电气产品不会对环境造成严重污染或对其人身、财产造成严重损害的限制。

生产日期	_____
规格	_____
数量	_____

Product Schematic Description

The diagram illustrates the components of the Headphone and Charging case. On the left, the Headphone is shown with two earbuds. The left earbud has a circular 'Indicator' and a 'Multi-function buttons (MFB)'. The right earbud has a 'Multi-function buttons (MFB)'. On the right, the Charging case is shown with a 'Type-C' port and an 'Indicator'.

Headphone

Charging case

Connected	Headphones LED indicator is off.	"Connected"
Disconnected	Ice blue and red light of the headset flashes alternately	"Disconnected"
Low Battery	Red indicator on the headset blinks	"Battery low"
Headphones placed in charging case	Ice blue indicator light of the charging case is bright	—
Charging case low power	Ice blue indicator of the charging case blinks	—
Charging case charged	Red indicator of the charging case blinks	—
Charging case fully charged	Red light of the charging case is bright	—

NOTE:

- * Fully charge the headphones and power off before an intended not-in-use period.
- * Unplug the charging cable after charging.

Operation

Normal



Voice Assistant: Press and hold left MFB for 2 S

Volume + : Click right MFB

Volume - : Click left MFB

Restore factory settings

When you turn on the headphone, make sure it does not connect to any Bluetooth device, and click the MF button 5 times to clear the pairing record, then turn off the headphone.

This table is compiled according to SJ/T 11364

O: Indicates that this hazardous substance contained in all of the homogeneous materials of this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

10 Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Certificate of Approval
Product No: _____
Production Time: 00:00
QC: _____

文件名称	魔声XKT32说明书			材料	全书60g书纸+单黑印刷+骑马钉		单位	mm	厂商物料编号	变更履历	修改		日期	
文件尺寸	60X90mm（单P尺寸）			工艺	1C印刷 风琴折		公差	±0.5mm	XXXXXXXXXX		审核		日期	
设计日期	2024/01/25	文件版本	2024V02				比例	1:1			批准		日期	