


Hardware Setup 硬件设置



OOWOW OS Overview

Edge 2L comes with the built-in OOWOW operating system, which allows you to quickly download and install any Khadas officially maintained OS version from the cloud.

Please note the following when using OOWOW:

1. If no operating system is installed on the Edge 2L storage, the device will automatically enter OOWOW upon boot.
2. To manually enter OOWOW:
Press and hold the **Function** button, briefly press the **Reset** button once, then release the **Function** button. The device will boot into OOWOW.
3. After entering OOWOW, press the **Function** button to enable the Edge 2L Hotspot.
Connect to this hotspot using another computer to remotely manage the Edge 2L while it is in OOWOW mode.

Resources

1. User Guides and Development Documentation
Khadas Documentation: docs.khadas.com
2. Schematics and Design File
Khadas Download Server: dl.khadas.com/products/edge2l
3. Technical Support and Issue Reporting
Khadas Community Forum: forum.khadas.com

OOWOW 操作系统简介

Edge 2L 内置 OOWOW 操作系统，可帮助您通过云端快速下载并安装由 Khadas 官方维护的各版本操作系统。


使用 OOWOW 时，请注意以下事项：

1. 当 Edge 2L 存储中尚未安装操作系统时，设备开机后将自动进入 OOWOW 系统。
2. 如需手动进入 OOWOW 系统：
按下 **Function** 按键不放，短按一次 **Reset** 按键，然后松开 **Function** 按键，即可进入 OOWOW 操作系统。
3. 进入 OOWOW 系统后，按下 **Function** 按键，按键可开启 Edge 2L 的热点（Hotspot）。
使用其他计算机连接该热点后，即可远程管理处于 OOWOW 系统下的 Edge 2L。


资料指引

1. 使用教程与开发文档
Khadas Documentation: docs.khadas.com
2. 原理图及设计资料下载
Khadas 下载服务器: dl.khadas.com/products/edge2l
3. 技术支持与问题反馈
Khadas 官方论坛: forum.khadas.com

Interfaces (Front) 按键与接口 (正面)



Interfaces (Rear) 按键与接口 (背面)



FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.