



Accessories



White Noise Sound Machine × 1



Power cord × 1



Manual × 1

Warnings


1. Do not disassemble or repair the product by yourself to avoid damage.
2. Please keep away from water source to avoid damaging the product.
3. Please keep away from high temperature and fire source.
4. Do not use corrosive cleaner to wipe or clean the product.
5. Please wipe the surface with a soft wet towel.

01

Buttons Description



- ① **Sound Switch:** Light tap in the group 5 nature sounds, 5 waves sounds, 5 thunderstorm sounds, 2 hypnotic songs, 5 environmental sounds.
- ② **Time adjustment:** Long press 2 seconds to enter the time adjustment mode. Press + key combination to adjust time. Once set, press this key for 2 seconds to exit.



- ① **Fan sound switching:** Light tap tracks in the group to switch through the 5 fan sounds.
- ② **Time adjustment:** After entering the time adjustment mode, press this key to adjust the hour range. Press + Key combination to adjust the time. Once set, press this key for 2 seconds to exit.



- ① **White noise switching:** Light tap tracks in this group to switch through the 5 white noise.
- ② **Audio mode switching:** Long press for 3 seconds to automatically switch between Bluetooth mode and white noise mode.



- ① **Volume adjustment key:** Press once to decrease and increase the volume by one level, and long press to decrease and increase by one level every 0.5s until the maximum.
- ② **Time adjustment:** Press this key to adjust the time in time adjustment mode.

02




Power Button: Press normally for 3 seconds to turn on/off.

- ① **Light mode adjustment:** Colorful light, color selection, breathing light, rhythm light and warm light (touch the light button or tap the top lampshade).
- ② **Brightness adjustment:** 30%, 70%, 100% three gear adjustment.

- ① **Type-C DC 5V 1000mA input**
- ② **Timing toggle switch:** The toggle position corresponds to 30 minutes, 60 minutes and continuous playback respectively (After the corresponding timing playback time, the machine enters the energy-saving standby mode, and the power button needs to be pressed for the machine to enter the power on playback state again.)
- ③ **3.5mm earphone jack:** Earphone audio output.


03

App Introduction




- ① + ② Download XIULEMIAN software, turn on GPS positioning, turn on white noise power key, turn on XIULEMIAN, the software will automatically connect to Bluetooth, select the corresponding model at ③, and click ② to connect the device.
- ③ Mode can select the corresponding playback mode: music, fan sound, white noise, Bluetooth sound playback.
- ④ Sound can select the corresponding sound to play, and quickly put your favorite sound into the library.
- ⑤ Switch or pause sound.

04





- ④ Adjust the sound volume.
- ⑦ Adjust the light brightness.
- ⑧ Lighting mode selection: colorful light, color selection, breathing light, rhythm light and warm light.
- ⑨ Adjust the light color.
- ⑩ Timed shutdown.
- ⑪ Alarm clock adjustment.


05



- ① Light color selection
- ② Light change color DIY




06



Sound

Sound source library, you can select your favorite sound to the quick sound panel.



Custom

Set your favorite profile and add it to the quick panel.

07


Introduction To Special Functions

1. **Memory function:** Each time the sound source is selected and the playback duration exceeds 5 seconds, the shutdown system will remember and save the current sound source at this time, and the same sound source will be played next time it is turned on.

2. **Timing function:** Turn on and set the machine shutdown time, and the machine will be shut down when the set time is reached (dial 30 for 30 minutes, 60 minutes, circular playback setting or custom setting in mobile APP [this dial code is invalid when using APP timing]).

3. **Wake up light mode:** Turn on to set alarm time, turn on the wake-up function 30 minutes before the set time, the light will slowly brighten up, until the set time of the alarm clock is reached and the alarm will sound, tap the top lampshade or any button for light setting to enter the snooze mode with the alarm sound turned off, and the alarm will sound again 5 minutes later. If you need to turn off the alarm clock, press ② to turn off the alarm clock (The alarm clock can be turned off when the alarm clock start time is not reached during the wake-up process).

Sunset mode: Turn on the timed shutdown function. The sunset mode will be started 30 minutes before the shutdown. The light will dim slowly until the set time is reached and will turn off the machine (Setting the lighting mode at this time to colorful lights, breathing lights, rhythmic lights and warm lights will select the current color and darken slowly).



08

4. **Audio function:** Connecting to the mobile phone Bluetooth to play music (long press for 3 seconds to automatically switch to Bluetooth mode, click ② for the previous song, click ③ pause, and click ④ for the next song).
5. **Lighting DIY function:** You can customize the color sequence of colorful lights (you can select and set the color sequence in the [Color] interface on the mobile APP).

Precautions

1. The white noise device will automatically connect to the mobile device connected to the APP last time. If you need to switch to a new mobile device connection, please disconnect the APP connection status of the original mobile phone and activate the new mobile phone connection.
2. The audio connection status and APP connection status are dual channel connections. You need to ensure that the audio Bluetooth connection is successful before mobile music can be played.

Product Parameters

Product Model	FR006	Timing Function	30min/60min/Loop playback
Product Dimension	115*115*80mm	Output Power	5W
Accessories	5V1A adapter / Type-C interface data cable	Headset Function	Support Headset mode, maximum output 150mw
Power Supply mode	5V1A adapter charging or USB plug-in	Bluetooth Function	Support Bluetooth mode

09

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.



MEHRWEG

MADE IN CHINA

10