


Size : 70*50 MM


WiFi Temperature & Humidity Sensor

USER MANUAL



-1-

Product Presentation:



LED Indicator Reset Button hole



Battery Cover

-2-

Specification

Size: 71*26*20.7mm
Battery: LR03-1.5V/AAA*2 (Alkaline battery)
Wi-Fi Protocol: 2.4GHz IEEE 802.11b/g/n
Standby Current: $\leq 4\mu A$
Alarm Current: $\leq 20mA$
Temperature Measure Range: $-9.9^{\circ}C \sim 60^{\circ}C$
Temperature Accuracy: $\pm 1^{\circ}C$
Humidity Measure Range: 0% RH~100% RH
Humidity Accuracy: $\pm 5\% RH$

Checklist before using the device:

- Your smartphone has connected to a 2.4GHz Wi-Fi network.
- You have input the correct Wi-Fi password.
- Your smartphone must be Android 6.0 + or iOS 11 +.
- If the numbers of devices connected to Wi-Fi router reach the limit, you can try to disable a device to vacate the channel or try with another Wi-Fi router.



-3-

How to set up:

1. Use your smartphone to scan QR code, or search "Smart Life" app in Google Play Store or APP Store to download and install.




2. Create an account with your mobile number and authentication code.



-4-


3. Slide to open battery cover, install 2pcs new alkaline batteries. Connect your mobile to your Wi-Fi router, click "4" at the upper right corner of homepage or click "Add Device".



4. 1) Bluetooth Mode:

The app will advise you to turn on the bluetooth on your mobile, make sure the WiFi symbol is flashing, enter wifi name and password, it will search the device and add automatically.


-5-




-6-

2) Wi-Fi Mode:

Select "Temperature and Humidity Sensor (BLE + Wi-Fi)" from "Sensors", select "Blink Slowly", make sure the WiFi symbol is blinking slowly, if not, use the S/S pin to press the reset button till it is blinking slowly. Connect your mobile to the device's hotspot: "SmartLife-XXXX", then click to return to App interface, it will connect to Wi-Fi automatically, configuration completed.



-7-



-8-

Functions

1. Intelligent Linkage

You can create linkage scene with other Tuya smart devices like Smart IR Remote Controller. For example, when the indoor temperature $> 30^{\circ}C$, Air conditioner will turn on automatically, or when the humidity is $< 20\%$, the humidifier will spray.

2. Temp & humidity Alarm


You can preset the range of temperature and humidity in the Alarm, when the temperature and humidity goes out of the range, it will push alert message via app.



-9-

3. Temperature Unit Switch

You can switch temperature unit between Celsius and Fahrenheit by double-press the reset button with S/S pin, temperature unit ONLY change on the screen, you have to select the temperature unit in the Setting, then will change in the App.



4. Temp & humidity Calibration

You can calibrate the temperature and humidity in the Setting, select the calibration value, then use S/S pin to press the reset button once, the temperature or humidity value will sync on the screen and in app.

-10-

5. Low-battery Alarm

When the battery power level is low, it will push alert message via App to remind you to change battery.

6. Third-party Voice Control

You can enquiry about temp and humidity via Amazon alexa, Google assistant smart speaker.

OK Google, what is the <device> humidity?
OK Google, what is the <device> temperature?
Alexa, what is the <device> humidity?
Alexa, what is the temperature of <device name>?

-11-

FAQ

1) Please use new alkaline battery, don't mix use with used battery.

2) Please configure network connection instantly after the batteries are installed, to avoid power consumption.

3) Please make sure your wifi network works well, if the network is not good, the device will always try to connect wifi, then battery will run out soon.

4) Since it is a low battery-powered device, if there is no information reported within 24 hours, the app will remind you that it is offline.

5) When the ambient temperature change $\geq 0.5^{\circ}C$, or the humidity $\geq 5\%$, the temp and humidity will be updated every 2 minutes.

6) When the ambient temperature change $< 0.5^{\circ}C$ or the humidity change $< 5\%$, the temperature or humidity will be updated once an hour.

-12-

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.