











Size : 55*55MM

WiFi Temperature & Humidity Sensor User Manual  Model: TH08B -1-	Product Presentation:  ① Single-click to trigger backlight ② Double-click to switch °C/°F ③ Triple-click to switch 12H/24H ① Reset button ② Indoor temperature ③ Indoor humidity ④ Humidity Comfort Indication ⑤ Time ⑥ Battery Compartment DRY Humidity ≤ 40% COMFORT 40% < Humidity ≤ 65% WET Humidity > 65% -2-	Specification: Size: 56*56*23 mm Battery: LR03-1.5V/AAA*3 (Alkaline battery) Wi-Fi Protocol: 2.4GHz IEEE 802.11b/g/n Temperature Measure Range: -9.9°C ~ 60°C Temperature Accuracy: ±1°C Humidity Measure Range: 0% RH~99% RH Humidity Accuracy: ±5% RH -3-	Checklist before using the device: a. Your smartphone has connected to a 2.4GHz Wi-Fi. b. You have input the correct Wi-Fi password. c. Your smartphone must be Android 6.0 + or iOS 11 +. d. If the numbers of devices connected to Wi-Fi router reach the limit, you can try to disable a device to vacate the channel or try with another Wi-Fi router. -4-	How to Use: Push the cover of battery compartment downwards, install 3 pcs Alkaline batteries in the direction of positive and negative pole, then point to 2 slots, push the cover upwards to close.  -5-
How to set up: 1. Use your smartphone to scan QR code, or search "Smart Life" app in Google Play Store or APP Store to download and install.  2. Create an account with your mobile number and authentication code. -6-	3. Connect your mobile to your Wi-Fi router, click "+" at the upper right corner of homepage, then click "Add Device".  -7-	4. 1) Bluetooth Mode: The app will advise you to turn on bluetooth on your mobile, make sure the WiFi symbol is flashing, if not, hold the reset button till it is flashing, then enter wifi info, it will connect automatically.  -8-	 -9-	2) Wi-Fi Mode: Select "Temperature and Humidity Sensor (BLE+Wi-Fi)" from "Sensors", select "Blink Slowly", make sure the WiFi symbol is blinking slowly. If not, hold the reset button till wifi symbol is blinking slowly. Connect your mobile to the device's hotspot: "SmartLife-XXXX", click to return to App interface, it will connect Wi-Fi automatically, configuration completed. -10-
 -11-	 -12-	Functions 1. Backlight Display Single-click the reset button on the top, the backlight will be triggered and last for about 10s. It is more convenient to browse screen clearly in darkness. 2. 12/24-Hour System Switch Triple-click the reset button to switch between 12-hour and 24-hour system, then single press the reset button to report temp and humidity to tuya cloud, the time display is saved. -13-	3. Smart Linkage You can create linkage scene with other smart devices like Smart IR Remote control. For example, when the indoor temperature > 30 Celsius, the Air conditioner will turn on automatically.  -14-	4. Temp & humidity Alarm You can preset the range for temperature and humidity in Alarm. when the actual indoor temperature or humidity goes out of the range, it will push instant alarm message on your mobile.  -15-
5. Temp & Humidity Calibration You can calibrate the temperature and humidity in Setting, select the calibration value, then press the reset button once, the temperature or humidity will sync both on the screen and in the app. 6. Temperature Unit Switch Double-click the reset button to switch the temperature unit between Celsius and Fahrenheit, the temperature unit will ONLY change on the screen, you have to select the temperature unit in the Setting, then will change in the App. -16-	7. Temp & humidity records You can view the historic data of temp and humidity stored for 1 year, and export to your Email address.  8. Third-party Voice Control Support enquiring about temp and humidity via Amazon and Google smart speaker. -17-	FAQ 1. When the temperature and humidity is more accurate? About 30 minutes after configuration completed, the temp and humidity is closer to actual ambient environment, so the readings are more accurate and reliable. 2. When the temperature and humidity on the screen is not sync with the data in app? a) When deviation between temperature display on screen and in app is ≤ ± 0.5°C. b) When deviation between humidity display on screen and in app is ≤ ± 5%. -18-	3. a) When device detects the environmental temperature change is ≥ 0.5°C or humidity change is ≥ 5%, the temp and humidity will be updated every 2 mins. b) When device detects the environmental temperature change is < 0.5°C or humidity change is < 5%, the temp and humidity will be updated every 1 hour. c) When the backlight is triggered, the temp and humidity on the screen will be locked for 2 mins, if the backlight is triggered again within 2 mins, the temperature and humidity will be locked for no more than 15 mins. 4. Please keep it away from any heat source. -19-	5. If you want to calibrate Fahrenheit, you need calibrate Celsius firstly, then switch to Fahrenheit. 6. Please use Alkaline battery, and configure network connection immediately after the batteries are installed, and make sure the network works properly after configuration, if network is offline, the sensor will be always connecting network, which will consume battery power. 7. Voice commands for Alexa and Google: OK Google, what is the <device> humidity? OK Google, what is the <device> temperature? Alexa, what is the <device> humidity? Alexa, what is the temperature of <device name>? -20-

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with **minimum distance 20cm** between the radiator and your body.