




Manual

Thank you for choosing this product. In order to help you understand this product more quickly or solve any difficulties you encounter in using this product in the future, please be sure to read the product instruction manual carefully.

Package content

- 1x 1815 headset
- 1x TYPE Charging cable
- 2x Pairs Additional Earmuffs
- 1x Manual



Power on: Hold down the power button for 3 seconds, the blue LED flashes, accompanied by a voice prompt.

power off: Hold down the power button for 3 seconds, and the red LED flashes with a voice prompt.

Bluetooth connectivity

1. Turn on the phone's Bluetooth setting system and search for 1815 in the available devices search list.
2. After the headset is connected to the device through Bluetooth, the blue LED breathing light will flash slowly. Note: If there is a connection history between the device and the headset, they will automatically reconnect within working range.

Two devices are paired for connection

If you need to connect the headset to two different devices, connect the headset to the first device first. After the connection is successful, turn off both the headset and the device. Then, turn on the headset and connect it to another device, and turn on the previously connected device again, and the headset will connect to both devices.

Basic Functions

Play	Press the power button once to play
pause	Press the power button once to pause
Volume Up	Press the '+' button to increase the volume
Volume Down	Press the '-' button to decrease the volume
Next Track	Long press '*' button
Previous Track	Long press the '.' keys
Answer Incoming Calls	Press the power button when the incoming call
Hang Up Calls	Press the power button while talking
Reject Calls	Hold down the power button for 2 seconds
Charging	Plug the charging cable earphone port into the charging port on the earphone and connect the power end to the power adapter. When charging, the LED indicator will turn red.
Voice Assistant	Hold down the power button for 2 seconds to activate the voice assistant
The mode switch	Press the fourth key once to switch between game mode and music mode

Charging

- Plug the charging cable earphone port into the charging port on the earphone and connect the power end to the power adapter.
- When charging, the LED indicator will turn red.
- When the headset is fully charged, the LED indicator turns blue.

Headset specifications

Headset type	
Headset size	10mm
Frequency range	20Hz ~20KHz
The output	160
Bluetooth version	V5.2
The bluetooth configuration	hfp/hsp/a2dp/avrcp/spp/pbap
Bluetooth range	15~20m
Battery capacity	180 ma
Listening to music time	25Hours
Talk time	30Hours
Charging time	30 minutes
The sensitivity	-42 ± 3d B
Charging voltage	5v

Matters needing attention

Children are recommended for use under adult supervision.

Do not expose equipment to extremely hot or cold temperatures.

Control reasonable volume range to prevent hearing damage.

Do not use the device in a thunderstorm.

Do not disassemble the product.

Avoid using oily, volatile liquids and other cleaning products.

Keep accessories and packing parts away from children and pets to prevent accidental swallowing and suffocation.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.