


VAN RYSEL

INTERACTIVE TRAINER RCR HOME TRAINER INTERACTIF RCR


HVIN: D900V2





ASSEMBLY - ASSEMBLAGE

[illegible]

<https://support.decathlon.fr>




Non inclus / Not included


[illegible]

2



P.4 **ZWIFT**





P.14 CASSETTE





3








4.6




4.c








<https://support.decathlon.fr>




5.a




5.b











[illegible]

2


[illegible]

[illegible]8/9/10
ses/Gears *


5.a








5.b



5.c



<https://support.decathlon.fr>



STORAGE & USE - STOCKAGE & UTILISATION

Storage and use instructions for the device. The device should be stored in a cool, dry place. The device should be used in a cool, dry place. The device should be stored in a cool, dry place. The device should be used in a cool, dry place.

