

80.00 mm

80.00 mm

对折

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

INNOELEC

Automobile Holder

- Installation Instructions -




INSTALL 安装

- Turn the knob counterclockwise to release the clip.
定时针逆时针旋，松开夹子。
- Insert the air conditioner outlet, and then lock the knob clockwise.
插入空调出风口，然后顺时针针锁紧按钮。
- Confirm whether it is loose and the installation is complete.
确认是否松脱，安装完毕。

USE 使用

- ① Place the electronic device parallel to the vacuum suction head and push it firmly against the suction cup.
将电子设备平行于真空吸盘头，并用力推向吸盘。
- ② Let it stand for 1 second, and wait for the electronic equipment to suck tightly. Release your hand for use.
静置1秒，待电子设备吸紧后，即可松开手进行使用。
- ③ For electronic equipment with uneven back or air leakage at the back, Free electrostatic film can be pasted.
有些设备背面不平整或有漏气，可粘贴静电膜。
- ④ After the electrostatic film is posted firmly and smoothly. Use step 1.



360° ADJUSTABLE

- ① When the electronic device needs to be removed, press the button in the middle of the suction cup to easily remove the electronic device. (please do not pull it forcibly)
需要移除电子设备时，按压吸盘中间按钮，即可轻松取下电子设备。（注意请勿强拉）
- ② After the bracket is installed, use USB-A to USB-C or USB-C to USB-C to access the charging port of the bracket. The indicator light of the bracket is on. Put the mobile phone on to realize wireless fast charging.
支架安装好后，采用USB-A转USB-C或USB-C转USB-C（插入汽车充电口），支架指示灯亮，放上手机即可实现无线快速充电。



MATTERS NEEDING ATTENTION

注意事项

- a. In case of uneven back or air leakage of electronic equipment, please use electrostatic film, or use a flat and smooth protective sleeve for electronic equipment.
a. 如遇电子设备背面不平整或有漏气，请粘贴静电膜，避免电子设备脱落。
- b. Please do not pull the electronic device after it is firmly sucked. Please use the release button to remove it.
b. 电子设备吸紧后，请勿强行拉脱，取下请使用释放按钮。
- c. Do not absorb heavy objects more than 5kg.
c. 请勿吸附超过5kg的重物。
- d. Clean the suction cup surface regularly to avoid dust affecting the suction.
d. 定期清洁吸盘表面，避免灰尘影响吸力。