



Smart phone

Quick Start Guide



1. ABOUT PHONE

Overview



Function Keys

1	Waterproof test hole	2	Card tray
3	Receiver	4	Front Camera
5	Touch screen	6	Microphone

7	USB interface	8	Speaker
9	Power Key/Fingerprint	10	Volume Key
11	QVGA Camera	12	Photo flash
13	Rear Camera	14	Deputy LCD

Keys	Functions
Power Key	• Press to turn on/off the screen. • Press and hold to power off the phone, restart and Emergency.
Volume Key	• Press to adjust the volume of device.

2. BEFORE USING

The phone is a Dual SIM mobile that allows you to use two mobile networks.


Insert SIM cards and SD card

1) Switch off the mobile phone, Stick into the pin hole with eject tool, and then card tray will be out of phone.



2) Insert the SIM cards and SD cards to the card slots correctly.

Installing and removing SIM cards/ SD card



✓ **Note:** Set up-->Storage--> Click on this device to expand--> Select SD card--> Click on more-->Select Format (SD card can be formatted)

✓ **Note:**

- Do not remove the cards while the device is transferring data. Doing so may cause data to be lost or damage to the cards and device.
- The SIM cards and SD card are small parts. Please keep them away from children to

avoid swallowing the card by accident.

- Please do not touch the metal surface of SIM and SD card and keep them away from electromagnetic field to avoid damaged data.

Charge the Battery

Charge the battery before using it. Connect the USB cable to the USB power adaptor, and then plug the end of the USB cable into the USB Port.

3. GETTING STARTED

Basic Function

Turn on the phone

Press and hold the power key for a while to turn on the phone.

Turn off the phone

Long press the power key until a menu shows. Choose “Power off” to turn off the phone.

Restart the phone

Long press the power key until a menu shows. Choose “Restart” to restart the phone.

Lock the screen

Option 1: Press the power key to turn off the screen and lock it

Option 2: The screen will auto lock if you don't use the phone for a while.

Unlock the screen

Press the power key, and then slide to top for unlocking.

4. COMMUNICATION & CONNECTION

Make a call

- Touch the phone icon on the Home screen.
- Enter the phone number you want to dial.
- Touch the phone icon to dial the number that you entered.

Send a Message

You can use this phone to exchange text messages and multimedia messages with others. The messages from the same contact will be grouped into one conversation list. So you can see your entire message history with a person

conveniently.

WLAN

WLAN is a wireless networking technology that can provide internet access at distance of up to 25 meters, depending on the WLAN router and your surroundings. You can configure the WLAN as follow:

- **Settings-->Network & Internet-->Wi-Fi** to turn it on.

The device scans for available WLAN networks and displays the names of those it finds.

Tap one of the listed networks and enter the password, if asked to join in.

5. WARNING

The power supply type is TPA-10R120150VU01, output is 18.0W .



BE	BG	CZ	DK	DE	EE	IE	EL
ES	FR	HR	IT	CY	LV	LT	LU
HU	MT	NL	AT	PL	PT	RO	SI
SK	FI	SE	NO	IS	LI	CH	TR

In all EU member states, operation of 5150-5350 MHz is restricted to indoor use only.

Manufacturer Information:

HONGKONG YO YOUNG INTELLIGENT CO.,LIMITED

19H MAXGRAND PLAZA NO.3 TAIYAU STREET SAN PO KONG, KOWLOON, HONGKONG

FCC Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations as required by the FCC. For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 10mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

FCC ID:2A8X4-ACTION15