

C8 User manual

1. Operation instructions

power on	Take out the headset or press MFB key for 3S, headsets automatic pairing, The red and blue lights of the main headset flashes alternately, The blue light of the auxiliary earset flashes once every 3 seconds.	Power on
The two earsets pairing	Within about 15 seconds after startup, the two headsets are pairing automatically. The red and blue lights of the main headset flashes alternately, The blue light of the auxiliary earset flashes once every 3 seconds. The headset lights off after successful pairing.	Pairing
Single earset pairing	Take the headset out of the charging case (Or press and hold the touch key for 3 seconds) . The red and blue lights of the headset flash alternately, after connecting the phone, the light is off	Conneted
Bluetooth connecting	Open the mobile phone Bluetooth to search the headset pairing name, after connecting successfully, the earsets lights are off	N/A
Waiting for connection	The red and blue lights of the main headset flashes alternately, The blue light of the auxiliary earset flashes once every 3 seconds	Pairing

Bluetooth connected	Open the mobile phone Bluetooth to search the headset pairing name, after connecting successfully, the earsets lights are off. If it cannot be connected, switch the Bluetooth headset again and connect it again	Conneted
Disconnect	The red and blue lights of the main headset flashes alternately, The blue light of the auxiliary earset flashes once every 3 seconds	Disconneted
Next song	Press and hold the "touch" button on the right headset for 2 seconds, Go directly to the next song after hearing the beep.	Beep
Last sone	Press and hold the "touch" button on the left headset for 2 seconds, Go directly to the last song after hearing the beep.	Beep
Volume+	Right earset click "touch key", Music status and call status volume increase, Prompt tone at maximum (The volume increase needs to be synchronized with the phone, and the volume bar is displayed on the phone)	Beep
Volume-	Left earset click "touch key", Music status and call status volume decrease, Prompt tone at minimum (The volume decrease needs to be synchronized with the phone, and the volume bar is displayed on the phone)	N/A

Playing	Double-click the left/right "touch key"	N/A
Pause	Double-click the left/right "touch key"	N/A
Start SIRI	When the phone is connected, three clicks on the "touch" key (Both left and right earphones can be accessed) remarks: If the headset has a game mode and you want to keep this function then sets it: three clicks on the left earset is the game mode, and three clicks on the right earset is the voice assistant.	N/A
Coming call ringtone	The ringing tone of the phone needs to be synchronized with the headsets	
Answer incoming calls	Click the "touch" key	
Hang up	Press and hold the "touch" key for 2 seconds	Beep
Call rejection	Press and hold the "touch" key for 2 seconds	N/A
Stop calling	Click the "touch" key	Beep
Power off	Press and hold the "touch" button for 5 seconds and red light on (You can also turn off the earphone after connecting the mobile phone)	Power off
Power off	Put the headsets into the charging case, close the charging case, and the headsets are turned off.	Power off
No connection status	Automatic shutdown in 5 minutes when there is no connection. And can be connected back within 5	

	minutes.	
Charging for the earsets	The charging case charges the headset, and the red light of the headset is always on, The headset indicator light turns on blue when it is full, The blue light goes out after 5 seconds.	N/A
Low power	Low-power headphones red light up once every 5 seconds (3.3V low voltage alarm, 3.1V headset power off)	battery low
Clear pairing mode	Fast 5 clicks under power-on status (Both left and right headphones operate simultaneously) Then turn off the headsets, The pairing information between headset and mobile phone is cleared after restarting. (This function can be operated after connecting to or without connecting to the mobile phone)	Power off

2. FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note 2: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note 3: This device should be installed and operated with minimum distance 5mm between the radiator&your body.