User Manual

True Wireless Stereo Earbuds


MODEL:ET-BH035

Specifications

EN

Model	ET-BH035
Bluetooth Version	V5.3
Earbuds Battery Capacity	37mAh
Charging Case Battery Capacity	400mAh
Rated Voltage	3.7V
Earbuds Fully Charged Time	1.5H
Charging Case Fully Charged Time	1.5H
Music Playback Battery Life	6H (50% Volume)
Connected Standby Time	70H
Charging Port	Type-C
Input	5V/1A (Charging Case)
FCC ID	2A94QET-BH035

Accessories



Note:

Remove the insulation cover from the earbuds before first use. Put the earbuds into the charging case, and take out for use.

All images in this user manual is for illustrative purpose only. Please refer to the actual product.

FAQ

❶ The indicator is off when the charging case is being charged.

Make sure the charging port of the charging case is connected to power supply normally.

❷ Cannot hear anything from the earbuds

Make sure the earbuds are on.

Make sure the volume is set properly.

Make sure the earbuds are connected to the phone.

Make sure the earbuds are within the working range.

❸ Phone call effect is not good

Make sure the phone is in a strong signal area.

The effective working range of the earbuds is 10 meters, please make sure the earbuds are within the working range, and there are no obstacles between the phone and the earbuds.

❹ Cannot control with pause, resume and previous/next track while playing music

The device paired with the earbuds needs supporting AVRCP (Audio/Video Remote Control Profile) Protocol.

Using Your Earbuds



1. Charging

Charging Earbuds

When the earbuds prompt low battery, put the earbuds into the charging case, the earbuds will be in charging status automatically and the charging case lights up for 4 seconds before going off. The earbuds indicators stay solid blue while charging; the blue light goes off after the earbuds are fully charged.

Charging the Case

Connect the charging case to any 5V/1A power supply port with the included charging cable.

While charging, the charging case is breathing white slowly

After fully charged, the charging case stays solid white.

WEEE Compliance

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this

Manufacturer: Shenzhen Aspiron Technology Company Limited

Address: Room 2803B,Building C,Galaxy World Phase Ⅱ, Minle Community,Minzhi Street,Longhua District,Shenzhen,Guangdong,China

MADE IN CHINA

2. On/Off

Take out the earbuds from the charging case to turn on. Put back the earbuds to the charging case and close the lid to turn off.



3. Bluetooth Connection



For the first connection, open the lid of the charging case, take out both earbuds, and they will enter Bluetooth pairing mode automatically.

Earbuds pairing mode: primary earbud flashes blue and white, and secondary earbud has no lighting.

Search for "DualM NC BH035", select to connect, and the primary earbud lighting goes off after the connection is successful.

When the earbuds are turned on again, they will connect to the last paired device. If re-connection fails or the Bluetooth is disconnected, they will enter Bluetooth pairing mode automatically.



4. Dual Earbuds TWS Connection

Both earbuds were paired with each other when they were produced at the factory.

5. Clearing Pairing History

Make sure the earbuds were not connected to any device.

Tap the touch button of any earbud for FOUR times in any of the following status:

a.Single earbud pairing (alternatively flashes blue and white)

b.Dual earbuds pairing (left earbud flashes blue and white, right earbud has no lighting)

Both earbuds light up blue for 1 second than go off. Turn off the earbuds by placing them into the case.

Take out the earbuds to re-pair with your device.

6. Control & Functions



Music:	Pause/Play	Double tap L/R
	Previous Track	Triple tap L
	Next Track	Triple tap R
	Volume -	Tap L once
	Volume +	Tap R once
Calling:	Answer	Double tap L/R
	Hang Up	Double tap L/R
	Reject	Tap & Hold L/R for 2s
Gaming/Bass/Standard Mode:		Tap & Hold L for 2s
ANC/Pass Through/Standard Mode:		Tap & Hold R for 2s


(Mode switch is not available for single earbud)

仕様

JP

モデル	ET-BH035
Bluetoothバージョン	V5.3
イヤーバズバッテリー容量	37mAh
充電ケースバッテリー容量	400mAh
定格電圧	3.7V
イヤーバズ&充電時間	1.5時間
充電ケース&充電時間	1.5時間
音楽再生バッテリー稼働時間	6時間(50%容量)
接続時の待機時間	70時間
充電ポート	Type-C
入力	5V/1A(充電ケース)

アクセサリー



注意:

初回ご使用前に、イヤーバズから絶縁カバーを取り外してください。イヤーバズを充電ケースに入れ、取り出してご使用ください。

※ユーザーマニュアルのすべての画像は説明のためのものです。実際の製品を基準としてください。

よくあるご質問

❶ 充電ケースを充電しているとき、インジケーターが消灯状態になります。

充電ケースの充電ポートが電源に正常に接続されていることを確認してください。

❷ イヤーバズから何も聞こえません

イヤーバズがオンになっていることを確認してください。

音量が正しく設定されていることを確認してください。

イヤーバズがスマートフォンに接続されていることを確認してください。

イヤーバズが使用可能範囲内にあることを確認してください。

❸ スマートフォンでの通話に問題があります

スマートフォンが電波の強い場所にあることを確認してください。

イヤーバズの有効動作範囲は10mです。イヤーバズが動作範囲内にあり、スマートフォンとイヤーバズの間に障害物がないことを確認してください。

❹ 音楽の再生中、一時停止、再開、前の曲へ/次の曲への操作ができない。

イヤーバズとペアリングするデバイスはAVRCP (Audio/Video Remote Control Profile)プロトコルに対応している必要があります。

イヤーバズの使用方法



1.充電

イヤーバズを充電する

イヤーバズのバッテリー残量が少なくなった場合それと通知された場合、イヤーバズを充電ケースに入れると自動的に充電状態になり、充電ケースは4秒間点灯してから消灯します。充電中はイヤーバズのインジケーターが赤く点灯し、充電が完了するとインジケータが消灯します。

ケースを充電する

付属の充電ケーブルで、5V/1Aの電源ポートに充電ケースを接続します。

充電中、充電ケースは徐々に白く点滅します。

フル充電になると、充電ケースは白く点灯します。

2.オン/オフ

充電ケースからイヤーバズを取り出すと、電源がオンになります。

イヤーバズを充電ケースに戻しフタを閉めると、電源がオフになります。



3.Bluetooth接続時



初回接続時、充電ケースのフタを開けた、両方のイヤーバズを取り出すと、自動的にBluetoothペアリングモードになります。

イヤーバズペアリングモード: メインイヤーバズが青と白に点滅し、サブイヤーバズは点灯状態になります。

「DualM NC BH035」を検索し、接続を選択すると、接続後にメインイヤーバズのライトが消灯します。

イヤーバズの電源を再び入れると、最後にペアリングしたデバイスに接続されます。再接続に失敗したり、Bluetoothが切断された場合は、自動的にBluetoothペアリングモードになります。



4. 両イヤーバズTWS接続

工場生産時、どちらのイヤーバズも互いにペアリングされています。

5.ペアリングの履歴を消去する

イヤーバズが父母デバイスにも接続されていないことを確認してください。

以下のいずれかの状態で、いずれかのイヤーバズのタッチボタンを4回タップします。

a.片方のイヤーバズのペアリング（青と白が交互に点滅）

b.両イヤーバズのペアリング（左のイヤーバズは青と白に交互に点滅、右のイヤーバズは消灯状態）

両イヤーバズが1秒間だけ青く点灯し、その後消灯します。イヤーバズをケースに入れ、電源をオフにします。

イヤーバズを取り出して、デバイスと再度ペアリングします。

6.コントロール＆機能



音楽：	一時停止/再生	L/Rを2回タップ
	前の曲へ	Lを3回タップ
	次の曲へ	Rを3回タップ
	音量-	Lを1回タップ
	音量+	Rを1回タップ
通話：	受信	L/Rを2回タップ
	通話終了	L/Rを2回タップ
	着信拒否	L/Rを2秒間長押し
ゲーミング/音楽/標準モード：		Lを2秒間長押し
ANC/パススルー/標準モード：		Rを2秒間長押し

（片方のイヤーバズのみではモード切替はできません）

Technische Daten

DE

Modell	ET-BH035
Bluetooth-Version	V5.3
Ohrhörer-Akkukapazität	37mAh
Akkukapazität der Ladehülle	400mAh
Nennspannung	3.7V
Dauer bis zur vollständigen Aufladung der Ohrhörer	1.5h
Dauer bis zur vollständigen Aufladung der Ladehülle	1.5h
Akkulaufzeit bei Musikwiedergabe	6h (50 % Lautstärke)
Bereitschaftszeit bei bestehender Verbindung	70h
Ladeanschluss	Type-C
Eingang	5 V/1 A (Ladehülle)

Zubehör



Hinweis:

Entfernen Sie vor der erstmaligen Verwendung die Isolierabdeckung von den Ohrhörern. Platzieren Sie die Ohrhörer in der Ladehülle und nehmen Sie sie zur Benutzung heraus.

Alle Bilder in dieser Bedienungsanleitung dienen nur der Veranschaulichung. Orientieren Sie sich am tatsächlichen Produkt.

Häufig gestellte Fragen (FAQ)

❶ Die Anzeige ist aus, wenn die Ladehülle geladen wird.

Stellen Sie sicher, dass der Ladeanschluss der Ladehülle normal an die Stromversorgung angeschlossen ist.

❷ Keine Tonausgabe über die Ohrhörer

Stellen Sie sicher, dass die Ohrhörer eingeschaltet sind.

Vergewissern Sie sich, dass die Lautstärke richtig eingestellt ist.

Stellen Sie sicher, dass die Ohrhörer mit dem Telefon verbunden sind.

Stellen Sie sicher, dass sich die Ohrhörer innerhalb der Betriebsreichweite befinden.

❸ Qualität beim Telefonieren ist nicht gut.

Stellen Sie sicher, dass die Signalstärke des Telefons gut ist.

Die Betriebsreichweite der Ohrhörer beträgt 10 Meter. Achten Sie darauf, dass sich die Ohrhörer innerhalb der Betriebsreichweite befinden und keine Hindernisse zwischen Telefon und Ohrhörern vorhanden sind.

❹ Während der Musikwiedergabe ist eine Steuerung von Pause, Fortsetzung und vorherigen/nächster Titel nicht möglich.

Das mit den Ohrhörern gekoppelte Gerät muss das AVRCP- (Audio/Video Remote Control Profile) Protokoll unterstützen.

Ihre Ohrhörer verwenden



1. Aufladen

Ohrhörer aufladen

Wenn die Ohrhörer einen geringen Akkustand anzeigen, platzieren Sie sie in der Ladehülle und die Ohrhörer werden automatisch geladen. Die Ladehülle leuchtet 4 Sekunden auf und erlischt dann. Die Anzeigen der Ohrhörer leuchten während der Aufladung dauerhaft blau. Das blaue Licht erlischt nach vollständiger Aufladung der Ohrhörer.

Hülle aufladen

Schließen Sie die Ladehülle über das mitgelieferte Ladekabel an einen Stromversorgungsanschluss (5 V/1 A) an.

Während der Aufladung pulsiert die Ladehülle langsam weiß.

Nach vollständiger Aufladung leuchtet die Ladehülle dauerhaft weiß.

2. Ein/Aus

Nehmen Sie die Ohrhörer zum Einschalten aus der Ladehülle heraus.

Zum Ausschalten platzieren Sie die Ohrhörer wieder in der



3. Bluetooth-Verbindung

Öffnen Sie bei der erstmaligen Verbindung den Deckel der Ladehülle, nehmen Sie beide Ohrhörer heraus und sie rufen automatisch den Bluetooth-Kopplungsmodus auf.

Ohrhörer-Kopplungsmodus: der erste Ohrhörer blinkt blau und weiß, der zweite Ohrhörer leuchtet nicht.

Suchen Sie nach „DualM NC BH035" und wählen Sie die Verbindungsoption. Nach erfolgreichem Verbindungsaufbau erlischt die Beleuchtung des ersten Ohrhörers.

Wenn die Ohrhörer erneut eingeschaltet werden, verbinden Sie sich mit dem zuletzt gekoppelten Gerät. Wenn der erneute Verbindungsaufbau fehlschlägt oder die Bluetooth-Verbindung getrennt wird, rufen sie automatisch den Bluetooth-Kopplungsmodus auf.



4. TWS-Verbindung beider Ohrhörer

Beide Ohrhörer wurden bei der Herstellung im Werk miteinander gekoppelt.

5. Kopplungsverlauf löschen

Stellen Sie sicher, dass die Ohrhörer nicht mit einem Gerät verbunden waren.

Tippen Sie in einem der folgenden Zustände VIERmal auf die Touch-Taste eines Ohrhörers:

a.Kopplung eines einzelnen Ohrhörers (blinkt abwechselnd blau und weiß)

b.Kopplung zweier Ohrhörer (linker Ohrhörer blinkt blau und weiß, rechter Ohrhörer leuchtet nicht)

Beide Ohrhörer leuchten 1 Sekunden blau auf und erlöschen dann. Schalten Sie die Ohrhörer aus, indem Sie sie in der Hülle platzieren.

Nehmen Sie die Ohrhörer zur erneuten Kopplung mit Ihrem Gerät heraus.

6. Steuerung und Funktionen



Music:	Pause/Wiedergabe	L/R zweimal antippen
	Vorheriger Titel	L dreimal antippen
	Nächster Titel	R dreimal antippen
	Lautstärke -	L einmal antippen
	Lautstärke +	R einmal antippen
Telefonieren:	Annehmen	L/R zweimal antippen
	Auflegen	L/R dreimal antippen
	Ablehnen	L/R 2 s angetippt halten
Gaming-/Bass-/Standard-Modus:		L 2 s angetippt halten
ANC-/Passthrough-/Standard-Modus:		R 2 s angetippt halten

(Moduswechsel ist bei einem einzigen Ohrhörer nicht verfügbar)

Bluetooth® EN The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG,Inc. and any use of such marks by Sunvalleytek International Inc. is under license. Other trademarks and trade names are those of their respective owners.

FCC Compliance

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

80G

65x80mm

