

FRONT



OFFICIAL LIGHT STICK

BACK

SPECIFICATION	
LIGHT STICK SIZE 50 x 10 x 22 mm	MAIN FEATURE WIRELESS CONTROL LIGHT STICK
INPUT POWER 3x3.6V (AA)	
작업 시간/충전 시간 작업 시간 : 2시간 / 충전 시간 : 2시간	
타이핑 제품은 LED는 청색LED로 사용 용 발광한 공작에 관한 타이핑제품을 통해 고객에게 제품 수거 및 고장품 검사에 안내 드립니다. 성명 김민우 연락처 02-3821-6901 주소 서울 서대문구 연세로 220, 5F 이메일 jipin@jipin.co.kr 교/학과명 공과대학 / 광물공학	
이름	구분제
번호	구분제
주소	

the device complies with all 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference from licensed radio stations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

品質保證書

- 本产品是通过严格的工艺管理和质量检测生产出来的产品。
- 产品的保质期六个月(从购买之日起)
- A/S处理标准
 - 无条件修理
 - 从购买之日起在保质期外正常使用情况
 - 产品外理有异味、划痕等情况(仅限未使用产品)
- [有保修单]
 - 超过保质期的情况
 - 因故障造成发生破坏、出现故障的情况
 - 因火灾、洪水、雷击等自然灾害发生破坏的情况
 - 因故障造成拆换、修理及造成再次发生故障的情况
 - 即使在保质期外,如能证明有雷击后引发的话,也会产生相应费用。
- 请在官方销售点购买的产品才有进货、换货、售后服务等顾客服务和支援。
- 本保证书只针对韩国国内有效。

這事重要

- 如遭受强烈冲击, 可能导致使用故障。
- 不要将电池吸入水中。
- 产品的灯光部分开始闪烁, 请检查是否发光的部分。
- 不要将产品保管在阳光直射, 高温和潮湿的地方。
- 不要随意拆解或改造。
- 如果产品有损坏等异常情况, 请停止使用并委托售后服务, 可能会发生二次伤害。
- 请保管在婴幼儿无法触及的地方。
- 请按电池的(+)极到(-)极的顺序插入。
- 请使用正品AAA碱性电池。
- 不要将新电池和用过的电池进行混用。
- 请使用同一制造商生产的电池。
- 每次观看演出时, 请使用新的电池。
- 未使用时请将电池分开保管。
- 电池剩余电量过低时, LED将不进行工作。

출판인명

[illegible]

주의사항

- ▶ 강한 충격을 받은 경우 고장의 위험이 큼.
- ▶ 물에 닿거나 뜨거지 않게 함.
- ▶ 제품과 손가락이 닿을 때 방전된 부분만 분리해라 하세요.
- ▶ 지우개나 "고급" 지우개는 사용하지 마세요.
- ▶ 의도치 않게 손가락이 화면에 닿지 않게 하세요.
- ▶ 제품 사용 시 화면이 뜨거나 열에 접촉을 금지시키고 5~15의 하한선, 2~3 분을 가릴 필요 있음.
- ▶ 화면이 너무 밝거나 어둡게 조정할 수 없습니다.
- ▶ 건전지의 (-)극과 (+)극 순으로 삽입해 주세요.
- ▶ 제품 AAA 건전지 4개는 건전지를 사용하게 하세요.
- ▶ 건전지 사용 시 화면은 순환하여 건전지를 교체하세요.
- ▶ 휴대용 제품은 건전지를 사용하게 하세요.
- ▶ 배터리를 새 제품으로 건전지 사용하게 하세요.
- ▶ 이 제품은 전전지를 분리하여 교체할 수 없습니다.
- ▶ 건전지 전전지는 보통 품질 LED가 장착되지 않습니다.

How to use

Press the button briefly
Once you press the button, the LED mode changes.

Central control
When central control is activated in the concert hall, the lighting of the light stick will be automatically controlled without any additional button operation.
When central control is activated, users are unable to individually control the lighting of the light stick.

Inserting and replacing the battery

As shown in the figure below, rotate the bottom part of the handle to separate. Insert 3 AAA batteries in the direction written on the socket.
(The part with the spring in the socket is the (-) pole.)



使用方法

ボタンを短く押す。
ボタンを押すとの際にLEDモードが変更されます。

中央制御
会場で中央制御が始まると、別途のボタン操作なしに自動的にペンライトの両明が点灯されます。

乾電池の挿入及び交換

下記の通り、握り手の下端を回して取り外した後、内印にある乾電池/ソケットを取り出してください。
※4乾電池3個をソケットに書かれている方向に合わせて挿入してください。
(ソケットにスプリングがある部分が(-)極です。)



Certificate of quality

This product has been manufactured by strict process control and quality testing.

The production/warranty period is 6 months. (From the date of purchase)

Repair Service Criteria

(Free of charge)

- If the product is used normally within the warranty period from the date of purchase.
- There are no injury substances, scratches, etc., on the exterior of the product. (Limited to unopened products only)

(Paid repair)

- If the warranty period expires.
- In the case that the product has been damaged or malfunctioning due to the customer's carelessness.
- In the case of malfunction due to natural disasters, such as fire, flood, earthquake, etc.
- In the case of product malfunction caused by disassembly, repair, and modification by the customer.

- Even if it is within the warranty period, a fee will be charged if the repair requires payment according to the terms above.

- For products that do not support such as return, exchange, repair, etc. are available only for products purchased from official dealers.

This warranty is valid only in Korea.

Precautions:

- Strong shock may cause breakdown.
- Do not let the product touch or soak in water.
- Do not look at the illuminated part when the product is on.
- Do not store in a place with direct sunlight, high temperature, and humidity.
- Do not disassemble or remodel.
- If there is an abnormality including (but not limited to) damage to the product, do not use the product and request customer support. Secondary defects may occur.
- Keep out of reach of infants/kids.
- Insert in order of (+) pole to (-) pole of the battery.
- Use genuine AA alkaline batteries.
- Do not mix new and used batteries.
- Use batteries from the same manufacturer.
- Please use new batteries for each show.
- When not in use, please remove the battery and store it.
- If the remaining battery is low, the LED will not work.

品質保證書

※製品は一般的な工程で製造されており、品質検査を通して作られた製品です。

製品保証期間の4年です。(ご購入日から)

アフターサービス受取基準

(無償修理)

- ・購入日から6年保証期間内に正常に使用した場合
- ・製品の外部に異物、スクラッチなどがある場合(未使用品に限りず)

(有償修理)

- ・保証期間が経過した場合
- ・お客様が不注意による破損、故障が発生した場合
- ・火災、水災、地震など天災地災による故障が発生した場合
- ・お客様のご都合で交換、修理、返品、返金、返品した故障

※保証期間内でも有償アフターサービスに該当した場合は、料金を発生します。

・公式販売店にて有償アフターサービスに該当して、返品、交換、アフターサービス等のカスタマーズサービスとサポートを受けたい場合があります。

※本保証は日本国内でのみ有効となります。

注意事項

強い衝撃を受けると故障の原因となります。

水・水蒸気にためると危険です。

製品の穴が開いている時、見えない部分を目で見てください。

直射日光、高温や低温などの保管に避けてください。

任意に分解、入り組むと危険です。

電池と接触のある金属がある場合は、使用を中止しアフターサービスに連絡ください。

以下のような事象が発生する可能性があります。

1. 充電時の手の届かない場所に設置してください。

2. 充電室を閉鎖し充電の完了を確認し、取り出してください。

3. 充電室を閉鎖し、充電室の温度を確認してください。

4. 充電室と使用済みの充電室を区別して使用してください。

5. 同一メーカーの電池だけをご使用ください。

6. 同一公称電圧、同じ充電室に替えてご使用ください。

使用しない場合は電池を取り出し保管してください。

電池の性能が低い場合、LEDが動作しません。