

BOXROCKER

YOU DESERVE IT!
IT WILL ELEVATE YOUR LIFE AND REMIND YOU TO LOVE
YOURSELF FIRST



BATTERY FOR REMOTE

The rating label is underneath the battery.
To access, remove the battery cover and
battery Replace when done.




CHARGING INSTRUCTIONS

1. Turn your box rocker off by pressing power button to the extended position (popped out)
2. Plug in the supplied box rocker charging cable
3. Once plugged in the charging led indicator will glow solid red
4. Led charging indicator will glow green when charging is complete



USING YOUR NEW BOXROCKER

- THRUSTER SPEED CONTROL
- THRUSTING SHAFT STROKE LENGTH CONTROL



- LONGER STROKE
- SHORTER STROKE



TO USE YOUR OPTIONAL HANDS FREE STRAP

1. Clip strap onto anchor points
2. Slide legs into loop on either side of your box rocker
3. Strap can be used around thighs or pulled up around your hips for added pressure

THE FIRST WEARABLE, HANDS-FREE SEX MACHINE
THAT FITS IN YOUR NIGHTSTAND DRAWER.
THIS TRULY IS A TOP DRAWER TOY!

1. Use while on your back, side, stomach, standing up or even straddle it! It's the most versatile toy on the market today!
2. 2.5hrs of battery life at full speed!
3. Super comfortable hands-free nylon elastic strap!
4. Quiet.
5. Built to last with the highest quality materials.
6. Remote control, batteries, charger, strap and discrete storage bag are all included. Its ready to go!
7. Patent pending



USING YOUR NEW BOXROCKER



1. Turn the box rocker on by pressing power button to the compressed position (popped in)
2. Replace rear cover
3. Attach strap clips to your box rockers anchor points

USING YOUR NEW BOXROCKER



ADD WATER BASED
LUBRICANT BEFORE EACH USE!!

BOXROCKER



LOVE YOURSELF



Straddling




On your side legs to same side



Flat on back legs straight up and together



Standing



Flat on back legs spread wide



Flat on back knees up, feet on bed



Sitting



Flat on back knees wide, feet together



Flat on back legs together



VIBE PAD

THRUSTER


VIBE PAD CONTROL

1. Press and hold vibe pad button until it begins to vibrate
2. Once vibe has started "single click vibe pad button to cycle through the 9 different speeds and patterns

THRUSTING SHAFT CONTROL

1. Press and hold thruster speed control button to begin the thrusting action
2. Single click the "longer stroke" or "shorter stroke" buttons to increase or decrease the stroke length at any time

STRAP ANCHORS FOR HANDS FREE ACTION



DUAL STRAP ANCHORS TO GO HANDS FREE!

SILKY SMOOTH AND FIRM BODY SAFE MEDICAL GRADE SILICONE



LARGE VERY POWERFUL VIBE PAD TO COVER ALL THE IMPORTANT PARTS!



PERFECTLY CONTOURED TO FIT COMFORTABLY BETWEEN YOUR LEGS

STRAP ANCHORS FOR HANDS FREE ACTION



SUPER TOUGH AND DURABLE EXTERIOR



CURVED BACK ALLOWS FOR STRADDLING AT ANY ANGLE!



CURVED FACE TO GET COMPLETE COVERAGE AND PRESSURE AGAINST YOUR ENTIRE ZONE.



ENLARGED TIP TO HIT ALL THE RIGHT SPOTS.

INCREDIBLY POWERFUL THRUSTER! CONTROL SPEED AND STROKE LENGTH AT THE PRESS OF A BUTTON WITH THE INCLUDED REMOTE CONTROL!

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



INSTRUCTION
THE BOXROCKER TEAM