






GSM1900-661-1000~18000MHz




GSM1900-810-0.009~0.15MHz



GSM1900-810-0.15~30MHz




GSM1900-810-30~1000MHz




GSM1900-810-1000~18000MHz




GPRS1900-512-0.009~0.15MHz



GPRS1900-512-0.15~30MHz




GPRS1900-512-30~1000MHz




GPRS1900-512-1000~18000MHz




GPRS1900-661-0.009~0.15MHz



GPRS1900-661-0.15~30MHz




GPRS1900-661-30~1000MHz




GPRS1900-661-1000~18000MHz




GPRS1900-810-0.009~0.15MHz



GPRS1900-810-0.15~30MHz



GPRS1900-810-30~1000MHz



GPRS1900-810-1000~18000MHz




EGPRS1900-512-0.009~0.15MHz



EGPRS1900-512-0.15~30MHz



EGPRS1900-512-30~1000MHz




EGPRS1900-512-1000~18000MHz




EGPRS1900-661-0.009~0.15MHz



EGPRS1900-661-0.15~30MHz




EGPRS1900-661-30~1000MHz




EGPRS1900-661-1000~18000MHz




EGPRS1900-810-0.009~0.15MHz



EGPRS1900-810-0.15~30MHz




EGPRS1900-810-30~1000MHz



EGPRS1900-810-1000~18000MHz




Band2-9262-0.009~0.15MHz



Band2-9262-0.15~30MHz




Band2-9262-30~1000MHz



Band2-9262-1000~20000MHz




Band2-9400-0.009~0.15MHz




Band2-9400-0.15~30MHz




Band2-9400-30~1000MHz



Band2-9400-1000~20000MHz




Band2-9538-0.009~0.15MHz



Band2-9538-0.15~30MHz




Band2-9538-30~1000MHz




Band2-9538-1000~20000MHz



Band5-4132-0.009~0.15MHz



Band5-4132-0.15~30MHz



Band5-4132-30~1000MHz