AVIOT

WA-Q1
Bluetooth Headphones
スタートアップガイド

安全上のご注意

取扱説明書には、お使いになる方や他の人への危害と財産への損害を未然に防ぎ、安全に正しくお使いいただくために、重要な内容を記載しています。次の内容（表示・図記号）をよく理解してから本文をお読みになり、記載事項をお守りください。

⚠ 危険	この表示の注意事項を守らないと、火災・感電・漏液・発熱・破裂などにより死亡や大けがなどの人身事故が生じます。
⚠ 警告	この表示の注意事項を守らないと、火災、感電などにより死亡や大けがなどの人身事故の可能性があります。
⚠ 注意	この表示の注意事項を守らないと、感電やその他の事故により怪我をしたり、周辺の家財に損害を与えたりすることがあります。

⚠ 危険

- 火の中に入れない。
- 本機および付属品を、幼児やペットが触れるところに置かない。
 誤飲のおそれや故障の原因となります。
- 分解しない。

⚠ 警告

- 警告音など、周囲の音が聞こえにくくなるため、周囲の安全を確保できる環境で使用する。
- 湿気・ほこり・油煙・湯気の多い場所、火のそば・直射日光のあたるところ・車内など高温の場所で使用、保管、放置しない。
- 自動車やバイク、船舶、自転車など乗り物の運転時には絶対に使用しない。
 装着時は周囲の環境に注意してください。
- 内部に水や異物を入れない。
 水や異物が入ると火災や感電の原因になります。万が一、水や異物が入ったときはすぐにご使用を中止し、お買い上げ店にご相談ください。
- 本機を布団などでおおった状態で使わない。
- 本機または USB ケーブルが濡れた状態で USB プラグを絶対に挿入しない。
 濡れた状態で USB プラグを挿入すると、本機や USB ケーブルに付着した液体（水道水、海水、清涼飲料水など）や異物によるショートが発生し、異常過熱や故障の原因となります。
- 電池が漏液したり、異臭がするときには直ちに火気より遠ざけ、使用を中止する。
- 充電の際は、付属の USB ケーブルを使用する。

⚠ 注意

- 大音量・長時間の使用に注意する。
 聴力に悪い影響を与えることがあります。耳を守るため、音量を上げすぎないようにご注意ください。また、音量の大小にかかわらず、長時間のご使用は耳の負担になります。1 時間に 1 度程度を目安に耳を休めてください。
- 医療機器の近くで使わない。
 電波が心臓ペースメーカーや医療用電気機器に影響を与えるおそれがあります。
- 肌に異常を感じたときは使用しない。
 症状が回復しない場合は医師の診断を受けてください。
- 充電中の本機に長時間触れない。
 低温やけどの原因になることがあります。
- 航空機内で使用する場合は、客室乗務員の指示に従う。
 電波が影響を及ぼし、誤作動による事故の原因となるおそれがあります。

充電式電池の廃棄について
本機に内蔵されている充電式電池はリサイクル可能な資源です。本機を廃棄する場合は、絶対にお客様自身では分解せず、お住まいの市町村のごみ捨てルールに従って廃棄してください。

● Bluetooth® 製品の電波干渉について

- 無線 LAN が設置されている場所や、電子レンジなどの電磁調理器の周辺など、周囲の電波状態によって、ノイズや音切れ、通信の切断などが発生する場合があります。
- Bluetooth® は遮蔽物（人体、金属、壁など）や周囲の電波状態によって通信有効範囲が大きく変動します。
- Bluetooth® 機器が発生する電波は、他の電子機器の動作に影響を与える可能性があります。
 場合によっては、事故を発生させる原因になりますので、次のような場所では、本機および他の Bluetooth® 機器の電源を切ってください。
 - 病院内 / 電車内の優先席付近 / ガソリンスタンドなど引火性ガスの発生する場所 / 火災報知器の近く

● 長くご使用いただくために


- 過放電にご注意ください
 充電式電池は、長期間充電されないまま放置されると過放電により劣化する場合があります。長期保管する場合は、過放電防止のため、1 か月に 1 回程度の充電をお願いします。
- 変形や破損、衝撃にご注意ください
 本機に長時間力を加えたままにすると、変形したり、破損してしまうおそれがあります。保管には充分にご注意ください。また、精密な電子部品を使用しておりますので、落としたり、ぶつけたりするなど、強い衝撃を与えないでください。
- お手入れについて
 劣化や故障の原因になりますので、お手入れの際はベンジン、シンナー、アルコールなどの薬品は使用しないでください。

● 使用上のご注意

- 背面のクリアパネルは取り外さないでください。着脱することで外れやすくなり、使用中に落下するおそれがあります。

充電（初回使用時は充電をしてからご使用ください）


充電ポートに USB Type-C® ケーブルを挿し込み充電します。
所要時間は電池残量が 0％の状態から満充電まで約 2 時間です。



※ 保護機能により、規定電圧より高く、あるいは低くなった場合は充電できなくなる可能性があります。
※ 5V の AC アダプター以外を使用した場合、保護機能により充電が停止する場合があります。
※ 充電ができない場合は、USB Type-C® ケーブルに異常が無いことを確認し、5V の AC アダプターを使用して再度充電をしてください。
※ 定期的な充電をしてください。（推奨：1 か月に 1 回以上）

電源 ON/OFF


電源 ON：電源ボタンを 3 秒間長押し
電源 OFF：電源ボタンを 3 秒間長押し




※ 接続されていない状態のまま 5 分経過すると、自動的に電源 OFF に切り替わります。
※ 電源 OFF の状態で電源ボタンを 5 秒間長押しすると電源 ON になり、Bluetooth の自動接続をせずにペアリングモードに移行します。

ペアリング（初回設定時）

① 電源ボタンを 3 秒間長押しして電源を ON にし、ペアリングモードになっていることを確認します。




② お使いの接続機器の Bluetooth 設定画面から「AVIOT WA-Q1」に接続します。



接続機器の設定画面イラストは一例です。
詳しくはお使いの接続機器の取扱説明書をご確認ください。
※ ペアリングができない場合はリセットをお試しください。

リセット（操作に不具合が生じた場合）


① ＋ボタンと－ボタンを同時に 5 秒間長押しします。



※ リセットが完了すると LED が赤と青に点滅し、ペアリングモードに移行します。

操作方法一覧

ボタンを押すことで、装着しながら様々な操作ができます。



		NC モードボタン	電源ボタン	＋	－
⏻	電源 ON	–	3 秒間長押し	–	–
	電源 OFF	–	3 秒間長押し	–	–
	ペアリング	–	電源 OFF 時に 5 秒間長押し	–	–
♫	再生	–	1 回押す	–	–
	停止	–	1 回押す	–	–
	曲送り	–	–	1 秒間長押し	–
	曲戻し	–	–	–	1 秒間長押し
🔊	音量を上げる	–	–	1 回押す	–
	音量を下げる	–	–	–	1 回押す
📞	受話	–	着信時に 1 回押す	–	–
	通話終了	–	通話中に 1 回押す	–	–
	キャッチ通話	–	キャッチ着信時に 1 回押す	–	–
	着信拒否	–	着信時に 1.5 秒間長押し	–	–
NC	ANC ※ 1	1 回押すたびにモード切り替え（ANC / OFF / 外音取込）	–	–	–
	外音取込				
	音量制限 ON/OFF ※ 2	3 回押す	–	–	–
	ゲーミング ON/OFF（低遅延）	–	3 回押す	–	–
ボイスアシスタント		–	2 回押す	–	–

※ 1 ANC = アクティブノイズキャンセリング
※ 2 聴力保護のために、最大音量を制限するモードです。操作時は ON/OFF に応じたボイスガイダンスが流れます。

保証規定

本製品は、通常のお取扱いにより発生した自然故障に対し、無償での修理または交換を行わせていただきます。弊社へお問い合わせの際は、ご購入店のレシートや納品書など、ご購入とその日付を証明する書類または電子データをご用意の上、お問い合わせください。

①本製品のご使用前に、必ず取扱説明書をお読みください。
保証期間はご購入日から 12 か月です。
保証は購入国でのみ有効です。
保証対象はヘッドホンのみとなります。
検証・交換の際の付属品や外箱の破損は保証できかねます。
※ 保証期間内に無償・有償交換を行った製品でも、保証期間はご購入日より 12 か月です。無償・有償にかかわらず交換後に延長されるものではございません。
②本製品は改良などの為、予告なく変更する場合があります。
③以下の場合は原則として保証が適用されませんのでご注意ください。
a. 弊社専用登録フォームにて製品登録を行っていただいていない場合。
b. 正規販売店のレシートや納品書などご購入を証明する書類や電子データが無い場合。
c. 当社サポートセンター以外で修理、改造を行ったもの。
d. 誤用（過大入力での破損、焼損を含む）、落下、衝撃等、お客様の不注意による事故、保管上の不備によって、製品が劣化したり、破損した場合。また症状が発生した時期にかかわらず、故障しているヘッドホンに傷や誤用の可能性が認められる場合。
e. 規格以外の電源および電圧で使用された場合。
f. 消耗品に関するもの。
g. 故障の原因が、例えば携帯端末など本製品以外の他の機器にある場合。
h. 本体外装やプラグに傷、汚れなど外観に生じた損傷。（購入後発生したもの）
i. 故障・不具合が生じた日が保証期間内でもお問い合わせをいただいた日時が保証期間を過ぎている場合。
④弊社取り扱い以外の製品は保証致しかねます。
⑤修理、交換期間中の代替機の貸し出しは行っておりません。
⑥万が一、保証対象外と判断された場合、往復の送料をご請求させていただく場合があります。
⑦生産・在庫状況、その他の事情により、同一製品での交換ができない場合があります。

免責事項

全ての Bluetooth® 対応機器およびアプリとの接続および動作を保証するものではありません。本製品を使用することによって生じた、他の接続機器の故障・トラブル、およびデータの消失・破損等に関しまして、弊社は一切の責任を負いません。また、パソコンや OS、その他のソフトウェア、対応機器等の故障・トラブルおよびデータの破損・消失等による損害に関しましても、弊社は一切の責任を負いかねます。予めご了承ください。

よくあるご質問 / お問い合わせ

サポートページからご確認ください。

商標について

- **Bluetooth®** ワードマークおよびロゴは登録商標であり、Bluetooth SIG, Inc. が所有権を有します。プレシードジャパン株式会社は使用許諾の下でこれらのマークおよびロゴを使用しています。
- USB Type-C® と USB-C® は、USB Implementers Forum の登録商標です。
- その他の商標および登録商標は、それぞれの所有者の商標および登録商標です。

AVIOT

WA-Q1
Bluetooth Headphones
Startup Guide

Important Safety Instructions

Before using the product, read through the instruction manual to ensure that you will use the product correctly.

DANGER

- **Do NOT place the product into contact with fire.**
- **Keep the headphones and accessories out of the reach of children and pets.**
 Otherwise, it may lead to accidental swallowing or malfunction.
- **Do NOT disassemble the product.**

WARNING

- **Use the headphones in an environment in which you can ensure the safety of your surroundings because warning sounds and other sounds in your surroundings will be hard to hear.**
- **Do NOT use, store, or leave the product in an environment with excessive humidity, dust, oil fumes, or steam, or in a high-temperature environment near a source of fire, in direct sunlight, or inside a vehicle.**
- **Do NOT use the headphones when operating a motor vehicle, motorcycle, watercraft, or bicycle.**
 Be aware of the surrounding environment when wearing the headphones.
- **Do NOT allow water or foreign matter to get inside the product.**
 Otherwise, this may result in a fire or electric shock. If water or foreign matter accidentally gets inside the product, stop using it immediately and contact your distributor.
- **Do NOT use the headphones under a blanket or the like.**
- **Do NOT insert the USB connector when the headphones or USB cable is wet.**
 Inserting a USB connector in a wet state may cause the headphones to short circuit due to contact with the liquid (tap water, seawater, cold drinks, etc.), and foreign matter entering into the headphones may result in abnormal heat generation or product failure.
- **Stop using the headphones if there is battery leakage or a peculiar smell, and keep the product away from flames.**
- **Use the included USB charging cable to charge your headphones.**

NOTE

- **Do NOT use it for a long time at high volume.**
 Otherwise, your hearing might be damaged. To protect your ears, be careful NOT to turn up the volume too high.
 In addition, regardless of the volume, extended use will place a burden on your ears. Please rest your ears every hour.
- **Do NOT use the product near medical equipment.**
 Electromagnetic waves may have an impact on pacemakers and medical electronic devices.
- **Do NOT use them if the headphones cause any abnormal sensation against your skin.**
 If your skin condition does not return to normal soon, seek medical attention.
- **Do NOT touch the headphones for an extended period during charging.**
 Otherwise, it may result in a low-temperature burn.
- **Please follow the instructions of the flight attendant when using the product onboard an aircraft.**
 Electromagnetic waves may cause the device to malfunction, resulting in an accident.

Discarding rechargeable batteries
The built-in rechargeable battery this device is equipped with is a renewable resource. Dispose of the product according to local standards and regulations. Do NOT disassemble the product.

● For customers in the USA

FCC Notice
You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines.
This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).
FCC ID: 2A9B6WA-Q1

● Radio interference of Bluetooth® products

- Interference from electromagnetic radiation in the surrounding environment, such as that from wireless LAN equipment, microwave ovens, and other electromagnetic cooking appliances may result in noise, loss of sound, or communication being disconnected.
- The effective communication range of Bluetooth® may vary greatly due to the influence of shields (the human body, metal, walls, etc.) and the state of electromagnetic radiation in your surroundings.
- The electromagnetic radiation generated by Bluetooth® devices may affect the operation of other electronic devices.
 There is a risk of an accident occurring as a result in some cases, so turn off the power of the headphones and other Bluetooth® devices when in the following places:
 - Hospitals / near the priority seating on the subway / in the vicinity of gas stations and other places where combustible gas is generated / near fire alarms

● For long-lasting use


- **Beware of over-discharge**
 If the rechargeable battery is not charged for a long time, it may lead to over-discharge and deterioration. If storing for a long time, please charge the battery once a month to prevent over-discharge.
- **Beware of deformation, damage, and impacts**
 The headphones may be deformed or damaged if they are subject to stress for a long time. Please exercise care when storing them. In addition, avoid dropping the product or subjecting it to strong impacts, as it contains precise electronic components.
- **Cleaning**
 Do NOT use chemicals such as benzine, thinner, or alcohol when cleaning the headphones. Otherwise, the headphones may be deformed or damaged.

● Usage precautions

- Do not remove the clear panel on the back of the headphones. Removing it and putting it on again may cause it to become loose, resulting in it falling off during use.

Battery Charging (Please charge it first before use for the first time)


Insert the USB Type-C® connector of the USB charging cable into the charging port for charging.
It takes about 2 hours to go from 0% to fully charged.



* Charging may not be possible if the voltage becomes higher or lower than the specified voltage.
* If a charger other than a 5V AC adapter is used, the charging may be stopped by the protection function.
* If charging is not successful, confirm that the USB Type-C® cable is in a normal state and try to recharge it again with a 5V AC adapter.
* Please charge the headphones regularly. (Recommended frequency: at least once a month)

Turning the Power ON/OFF


Power ON : Press and hold the power button for 3 seconds
Power OFF : Press and hold the power button for 3 seconds




* If not connected for 5 minutes, the headphones will automatically turn off.
* In the power OFF state, if the power button is pressed and held for 5 seconds, the power will turn ON but automatic Bluetooth connection will not be performed and the headphones will enter pairing mode.

Pairing (during initial setup)

1. Press and hold the power button for 3 seconds to turn the power on, then confirm that the headphones are in pairing mode.




2. Connect to “AVIOT WA-Q1” from the Bluetooth settings screen of the device to be connected.



The illustration shows an example of the settings screen on a device to be connected.
For details, please refer to the instruction manual of the device to be connected.
* If pairing fails, please try the reset operation.

Resetting (in case of operation failure)


1. Press and hold + button and — button at the same time for 5 seconds.



* When the reset is completed, the LED will blink red and blue alternately, and the headphones will enter pairing mode.

List of Operation Methods

By pressing the buttons, various operations can be performed while wearing the headphones.



		NC mode button	Power button	+	–
⏻	Power ON	—	Press and hold for 3 seconds	—	—
	Power OFF	—	Press and hold for 3 seconds	—	—
	Pairing	—	Press and hold for 5 seconds in the power OFF state	—	—
♫	Play	—	Press 1 time	—	—
	Stop	—	Press 1 time	—	—
	Next	—	—	Press and hold for 1 second	—
	Previous	—	—	—	Press and hold for 1 second
🔊	Volume up	—	—	Press 1 time	—
	Volume down	—	—	—	Press 1 time
📞	Receive call	—	Press 1 time when there is an incoming call	—	—
	End call	—	Press 1 time during a call	—	—
	Call waiting	—	Press 1 time during call waiting	—	—
	Block incoming call	—	Press and hold for 1.5 seconds when there is an incoming call	—	—
NC	ANC*1	Press 1 time to switch between the modes (ANC / OFF / Ambient sound)	—	—	—
	Ambient sound				
	Volume limitation ON/OFF*2	Press 3 times	—	—	—
	Gaming ON/OFF (Low latency)	—	Press 3 times	—	—
Voice assistant		—	Press 2 times	—	—

*1 ANC = Active Noise Canceling
*2 A mode that limits the maximum volume to protect your hearing. When you switch this mode ON/OFF, voice prompt corresponding to the action will be played.

Warranty

This product will be repaired or replaced free of charge for spontaneous failure that occurs during normal use. When you contact us, have ready at hand the documentation proving the date of purchase, such as the receipt, delivery slip, or electronic data from the store you purchased the product.

1 Before using this product, be sure to read the instruction manual to ensure proper use.
The warranty is valid for 12 months, starting from the date of purchase.
This warranty is valid only in country or region of purchase.
Only the headphones are covered by the warranty.
Damage to accessories and outer packaging boxes during verification and replacement is not within the scope of the warranty.
* The warranty period of products replaced free of charge or with charge is also 12 months from the original date of purchase. The warranty period will not be extended accordingly after replacement.

2 This product is subject to change for improvement and the like, without notice.

3 This warranty does not apply to the following situations.
a. The product has not been registered on the company’s dedicated registration platform.
b. If you do not have the documentation or electronic data serving as proof of purchase, such as a receipt or delivery slip from the distributor.
c. The product has been repaired or modified outside of our service center.
d. The product has fallen into a state of disrepair or been damaged due to misuse (including damage and burnout caused by excessive input), dropping, shock, or other accidents caused by the customer’s carelessness or improper storage., etc.
Even though the symptoms occurred within the warranty period, if the issue with the product is deemed due to misuse.
e. The product was used with a nonstandard power supply or voltage.
f. The failure is related to consumables.
g. The cause of the failure is another device other than this product, such as a mobile device.
h. Damage to the exterior of the product, such as scratches on the main unit or the plug (which occurred after purchase).
i. Even though the fault or defect occurred within the warranty period, the date of consultation exceeded the warranty period.

4 We do not offer warranties for products from other companies.

5 We will not lend out alternative devices during the repair or replacement period.

6 If the issue with the product is deemed not to be covered by the warranty, we may request that you reimburse us for the round-trip shipping fee.

7 Depending on production, inventory, or other circumstances, it may not be possible to provide replacements for the same product.

Disclaimers

We do not guarantee connectivity or operability with all Bluetooth®-enabled devices and applications. We shall not be responsible for any malfunction, problems, loss of data, or damage to other devices caused by the use of this product. We shall not bear any responsibility for damage caused by malfunctions, problems, or loss of data in computers, operating systems, other software, or devices. Thank you for your understanding.

FAQ / Inquiries

Please check the support page.

About Trademarks

- The term **Bluetooth®** and its logo are registered trademarks that belong to Bluetooth SIG, Inc. Preseed Japan Corporation is using these trademarks and logos with authorization.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- Other trademarks and registered trademarks are trademarks and registered trademarks belonging to their respective holders.

Back

AVIOT

WA-Q1
头戴式蓝牙耳机
入门指南

重要安全须知

使用产品前，请仔细阅读使用说明书，确保正确使用本产品。

危险

- 请勿投入火中。
- 请将主机及其附属品放置于儿童和宠物接触不到的地方。
 否则可能导致误吞或故障。
- 请勿拆卸。

警告

- 使用时可能会导致听不清警告音等环境音，因此请在能确保周边安全的环境下使用。
- 请勿在多湿、多尘埃、多油烟、多蒸汽的环境，或靠近火源、阳光直射以及车内等高温环境下使用、保存或放置。
- 请勿在驾驶汽车、摩托车、船舶或骑行自行车等交通工具时使用。
 佩戴时请注意周围环境。
- 请避免水或异物进入内部。
 水或异物进入可能导致火灾或触电。如不慎进水或有异物进入，请立即停止使用，并咨询销售商。
- 请不要在盖着被褥等容易导致发热的情况下使用本机。
- 请勿在主机或 USB 线潮湿的状态下插入 USB 接口。
 潮湿状态下插入 USB 接口可能使附着于主机或 USB 线的液体（自来水、海水、软饮料等）及异物进入，导致短路，从而导致异常发热或故障。
- 发生电池漏液、有异味等时，请立即远离火源，停止使用。
- 请使用附带的 USB 充电线进行充电。

注意

- 请勿在大音量下长时间使用。
 否则可能对听力造成损伤。为保护耳朵，请勿过度调大音量。另外，无论音量大小如何，长时间使用都会给耳朵带来负担。每使用 1 个小时请让耳朵休息一次。
- 请勿在医疗设备附近使用。
 电磁波可能对心脏起搏器或医用电子设备产生影响。
- 若皮肤感到异常请停止使用。
 如症状一直未得到缓解，请及时就医。
- 充电时请勿长时间接触主机。
 否则可能导致低温烫伤。
- 在飞机机舱内使用时，请遵从空乘人员的指示。
 以避免无线电波可能造成的影响。

Li-ion

可充电电池的废弃
主机内置的可充电电池是再生资源。丢弃主机时，切勿自行拆卸，请按照居住地的垃圾丢弃规则进行废弃。

● Bluetooth® 产品的无线电干扰

- 在装有无线 LAN 设备、微波炉等电磁烹饪设备的周围，根据周围的电磁波状态可能会导致噪音、声音丢失或通信断开等情况。
- Bluetooth® 的通信有效范围受遮蔽物（人体、金属、墙壁等）及周围电磁波状态影响可能产生较大变化。
- Bluetooth® 设备产生的电磁波可能对其他电子仪器产生影响。
 严重时可能导致事故，因此在以下场所请切断主机及其他 Bluetooth® 设备的电源。
 - 医院内 / 地铁的爱心专座附近 / 加油站等产生可燃性气体的场所 / 火灾报警器附近

● 为了保证产品寿命


- 当心过度放电
 可充电电池如长期不充电，可能导致过度放电从而劣化。如果长期存放，请每月给电池充电一次，以防止过度放电。
- 注意变形、损坏及冲击
 主机如果长时间受力，可能会变形或损坏。请妥善保管。此外，本产品使用了精密的电子部件，请避免掉落或碰撞，以免产生强烈冲击。
- 保养清洁
 清洁时请勿使用苯、稀释剂或酒精等化学品，否则可能会导致产品劣化或故障。

● 使用注意事项

- 请勿拆下背面的透明面板。频繁拆装可能会导致其容易松动，并且可能会在使用过程中脱落。

充电（初次使用时请先充电）


将 USB Type-C® 充电线插入充电口进行充电。
从电池电量 0% 到充满电的所需时间约为 2 小时。



※ 如果电压高于或低于规定的电压，保护功能可能会阻止充电。
※ 如果使用 5V 的 AC 适配器以外的充电器充电，可能会因为保护功能而停止充电。
※ 如果发生无法充电的情况，请确认 USB Type-C® 充电线无异常，并使用 5V 的 AC 适配器重新充电。
※ 请定期充电。（推荐：1 个月至少 1 次）

电源 ON/OFF


电源 ON：长按电源按钮 3 秒
电源 OFF：长按电源按钮 3 秒



※ 在没有连接的情况下，5 分钟后电源自动关闭。
※ 电源 OFF 状态下，长按电源按钮 5 秒即可开机并进入配对模式，无需执行蓝牙的自动连接。

配对（首次设置时）

① 长按电源按钮 3 秒开机，确认头戴式耳机进入配对模式。




② 从要使用的连接设备的 Bluetooth 设定画面连接“AVIOT WA-Q1”。



插图为要使用的连接设备的设定画面示例。
有关详细信息，请参阅要使用的连接设备的使用说明书。
※ 如果配对失败，请尝试重置操作。

重置的正确方法（发生操作不良时）


① 同时长按＋按钮和－按钮 5 秒。



※ 重置完成后，LED 呈红灯和蓝灯交替闪烁，进入配对模式。

操作方法一览

通过按下按钮，可在佩戴头戴式耳机时执行各种操作。



		NC 模式按钮	电源按钮	＋	－
	电源 ON	－	长按 3 秒	－	－
	电源 OFF	－	长按 3 秒	－	－
	配对	－	电源 OFF 状态下 长按 5 秒	－	－
	播放	－	按 1 次	－	－
	停止	－	按 1 次	－	－
	切换下一首	－	－	长按 1 秒	－
	切换上一首	－	－	－	长按 1 秒
	调大音量	－	－	按 1 次	－
	调小音量	－	－	－	按 1 次
	接听电话	－	来电时按 1 次	－	－
	挂断电话	－	通话中按 1 次	－	－
	呼叫等待	－	有呼叫等待时按 1 次	－	－
	拒接来电	－	来电时长按 1.5 秒	－	－
	ANC※1	每按 1 次可切换模式 （ANC / OFF / 通透模式）	－	－	－
	通透模式				
	音量限制 ON/OFF※2	按 3 次	－	－	－
	游戏 ON/OFF （低延迟）	－	按 3 次	－	－
语音助手		－	按 2 次	－	－

※1 ANC = 主动降噪
※2 该模式限制最大音量以保护听力。当您操作开 / 关此模式时，将会播放相应的语音提示。

保修条款

对于本产品正常使用过程中发生的自然故障，我们提供免费的维修或换新服务。向本公司咨询时，请提供购买店铺的收据或送货单等，能证明购买及购买日期的纸面文件或电子文件。

① 使用本产品前，请仔细阅读使用说明书，确保正确使用。
保证期为自购入日起 12 个月。
仅适用于购买国或地区。
保证对象仅包括头戴式耳机。
核验、换新时的附件及外包装盒破损不在保证范围内。
※ 保证期内免费、收费换新的产品的保证期也是自购买日起 12 个月。无论免费还是收费，更换后保证期不会相应延长。
② 本产品可能因升级等原因发生变化恕不提前告知。
③ 以下情形原则上不适用本条款，敬请注意。
a. 未在本公司专用注册平台进行产品注册。
b. 不能提供正规销售店的收据或送货单等证明购买的纸面文件或电子文件的情况。
c. 在本公司服务中心以外的地方进行过修理、改造时。
d. 误用（含过大输入导致的破损、烧损）、掉落、冲击等，由于客户不小心导致的事故、保管不善引起的产品劣化、损坏等情况。以及无论是否是症状发生时期，发现可能存在对故障头戴式耳机的损伤或误用行为时。
e. 在不符合规定的电源及电压条件下使用的情况。
f. 消耗品相关部件。
g. 由于手机等本产品以外的其他设备导致故障的情况。
h. 本体外部或插头的损伤、脏污等外观上的损伤。（购买后发生的）
i. 即使故障或不良发生时间在保证期内，但咨询时已超过保证期时。
④ 本公司仅对本公司经销的产品提供保证。
⑤ 不提供修理、换新期间的代用机。
⑥ 假如被判定为非保证对象，我们将向您收取来回寄送的邮费。
⑦ 根据生产、库存及或其他情况，可能无法提供相同产品的更换。

免责事项

不保证本产品能与所有支持 Bluetooth® 的设备和应用连接及连接后的正常操作。我们对使用本产品可能导致的其他设备的故障、问题及数据丢失、损坏等不承担任何责任。另外，我们也不承担因电脑、操作系统、其他软件、支持设备等的故障、问题及数据丢失、损坏而导致的损害责任。敬请谅解。

常见问题 / 咨询

请查阅支持页面。

关于商标

- **Bluetooth®** 字样和图标是注册商标，归属于 Bluetooth SIG, Inc.。Preseed Japan Corporation 在授权下使用这些商标和标志。
- USB Type-C® 和 USB-C® 是 USB 开发者论坛的注册商标。
- 其他商标及注册商标是归属于各自持有者的商标及注册商标。

AVIOT

WA-Q1
藍牙貼耳式耳機
啟動指南

重要安全須知

使用本產品前，請務必詳閱使用說明書，確保以正確的方式使用本產品。

危險

- 請勿投入火中。
- 請將主機及其附屬品放置於兒童和寵物接觸不到的地方。
 否則可能導致誤吞或故障。
- 請勿拆卸。

警告

- 使用時可能會導致聽不清警告音等環境聲音，因此請在能確保周邊安全的環境下使用。
- 請勿在多塵、多油煙、多蒸氣的環境，或靠近火源、陽光直射以及車內等高溫環境下使用、保存、或放置。
- 請勿在駕駛汽車、機車、船舶或騎腳踏車等交通工具時使用。
 佩戴時請注意周圍環境。
- 請避免水或異物進入內部。
 水或異物進入可能導致火災或觸電。如不慎進水或有異物進入，請立即停止使用，並諮詢銷售商。
- 請不要在主機或 USB 線潮濕的狀態下插入 USB 接口。
 潮濕狀態下插入 USB 介面可能使附著於主機或 USB 線的液體（自來水、海水、軟飲料等）及異物進入，導致短路，從而導致異常發熱或故障。
- 發生電池漏液、有異味等時，請立即遠離火源，停止使用。
- 請使用附帶的 USB 充電線進行充電。

注意

- 請勿在大音量下長時間使用。
 否則可能對聽力造成損傷。為保護耳朵，請勿過度調大音量。另外，無論音量大小如何，長時間使用都會給耳朵帶來負擔。每使用 1 個小時請讓耳朵休息一次。
- 請勿在醫療設備附近使用。
 電磁波可能對心律調節器及醫用電子設備產生影響。
- 皮膚感到異常時請勿使用。
 如果症狀一直未恢復正常，請及時就醫。
- 充電時請勿長時間接觸主機。
 否則可能導致低溫燙傷。
- 在飛機機艙內使用時，請遵守空服人員的指示。
 電磁波產生影響，可能引起誤動作從而導致事故。

Li-ion

可充電電池的廢棄
主機內置的可充電電池是再生資源。丟棄主機時，切勿自行拆卸，請按照居住地的廢棄物清理法進行廢棄。

● Bluetooth® 產品的無線電干擾

- 在裝有無線 LAN 設備、微波爐等電磁烹飪設備的周圍，根據周圍的電磁波狀態可能會導致噪音、聲音丟失或通信斷開等情況。
- Bluetooth® 的通信有效範圍受遮蔽物（人體、金屬、牆壁等）及周圍電磁波狀態影響可能產生較大變化。
- Bluetooth® 設備產生的電磁波可能對其他電子儀器的動作產生影響。
 嚴重時可能導致事故，因此在以下場所請切斷主機及其他 Bluetooth® 設備的電源。
 - 醫院內 / 地鐵的博愛座附近 / 加油站等產生可燃性氣體的場所 / 火災報警器附近

● 為了持久使用


- 當心過度放電
 可充電電池如長期不充電，可能導致過度放電從而劣化。如果長期存放，請每月給電池充電一次，以防止過度放電。
- 注意變形、損壞及衝擊
 主機如果長時間受力，可能會變形或損壞。保存時請注意。此外，本產品使用了精密的電子部件，請避免掉落或碰撞，以免產生強烈衝擊。
- 保養清潔
 保養清潔時請勿使用石油醚、稀釋液及酒精等化學藥劑，否則可能造成產品的劣化或故障。

● 使用注意事項

- 請勿拆下背面的透明背板。若頻繁拆裝，則會變得容易脫落，且可能會在使用過程中掉落。

充電（初次使用時請先充電）


將 USB Type-C® 充電線插入充電口進行充電。
從電池電量 0% 到充滿需要約 2 小時。



※ 如果電壓高於或低於規定的電壓，保護功能可能會阻止充電。
※ 如果使用 5V 的 AC 專用插頭以外的充電器充電，可能會因為保護功能而停止充電。
※ 如果發生無法充電的情況，請確認 USB Type-C® 電源線無異常，並使用 5V 的 AC 專用插頭重新充電。
※ 請定期充電。（推薦：1 個月至少 1 次）

電源 ON/OFF


電源 ON：長按電源按鈕 3 秒
電源 OFF：長按電源按鈕 3 秒




※ 在沒有連接的情況下，5 分鐘後電源自動關閉。
※ 在電源 OFF 的狀態下長按電源按鈕 5 秒後會啟動電源，並以不執行 Bluetooth 自動連接的方式進入配對模式。

配對（首次設置時）

① 長按電源按鈕 3 秒開啟電源，確認貼耳式耳機進入配對模式。




② 從您要使用的連接設備的 Bluetooth 設定畫面連接 “AVIOT WA-Q1”。



插圖為您要使用的連接設備的設定畫面示例。
詳情請查閱您要使用的連接設備的使用說明書。
※ 如果配對失敗，請嘗試重置操作。

重置的正確方法（發生操作不良時）


① 同時長按＋按鈕與－按鈕 5 秒。



※ 重置完成時，LED 紅燈和藍燈交替閃爍，進入配對模式。

操作方法列表

按下按鈕，您可以在佩戴時執行各種操作。



		NC 模式按鈕	電源按鈕	＋	－
	電源 ON	－	長按 3 秒	－	－
	電源 OFF	－	長按 3 秒	－	－
	配對	－	電源 OFF 的狀態下 長按 5 秒	－	－
	播放	－	按 1 次	－	－
	停止	－	按 1 次	－	－
	下一首	－	－	長按 1 秒	－
	上一首	－	－	－	長按 1 秒
	音量大聲	－	－	按 1 次	－
	音量小聲	－	－	－	按 1 次
	接聽	－	來電時按 1 次	－	－
	結束通話	－	通話中按 1 次	－	－
	來電等待	－	有來電等待時按 1 次	－	－
	拒接來電	－	來電時長按 1.5 秒	－	－
	ANC※1	每按 1 次可切換模式 （ANC / OFF / 通透模式）	－	－	－
	通透模式				
	音量限制 ON/OFF※2	按 3 次	－	－	－
	遊戲 ON/OFF （低延遲）	－	按 3 次	－	－
語音助理		－	按 2 次	－	－

※1 ANC = 主動降噪
※2 用於保護聽力而限制最大音量的模式。當您操作開 / 關此模式時，將會播放相應的語音提示。

保固條款

對於本產品正常使用過程中發生的自然故障，我們提供免費的維修或換新服務。向本公司諮詢時，請提供購買店鋪的收據或送貨單等能證明購買及購買日期的書面檔或電子檔。

① 使用本產品前，請仔細閱讀使用說明書，確保正確使用。
保証期自購入日起 12 個月有效。
僅適用於購買國或地區。
保証對象僅包括貼耳式耳機。
核驗、換新時的附件及外包裝盒破損不在保証範圍內。
※ 保証期內免費、收費換新的產品的保証期也是自購買日起 12 個月。無論免費還是收費，更換後保証期不會相應延長。
② 本產品可能會因改進而發生變化，恕不提前告知。
③ 以下情形原則上不適用本條款，敬請注意。
a. 未在本公司專用註冊平臺進行產品註冊。
b. 不能提供正規銷售店的收據或送貨單等證明購買的書面檔或電子檔的情況。
c. 在本公司服務中心以外的地方進行過修理、改造時。
d. 誤用（含過大輸入導致的破損、燒損）、掉落、衝擊等，由於客戶不小心導致的事故、保管不善引起的產品衰劣、損壞等情況。以及無論是否是症狀發生時期，發現可能存在對故障貼耳式耳機的損傷或誤用行為時。
e. 在不符合規定的電源及電壓條件下使用的情況。
f. 消耗品相關。
g. 由於手機等本產品以外的其他設備導致故障的情況。
h. 本體外部或插頭的損傷、髒汙等外觀上的損傷。（購買後發生的）
i. 即使故障或不良發生時間在保証期內，但諮詢時已超過保証期時。
④ 本公司僅對本公司經銷的產品提供保証。
⑤ 不提供修理、換新期間的備用機。
⑥ 假如被判定為非保証物件，我們將向您收取來回寄送的運費。
⑦ 根據生產、庫存及或其他情況，可能無法提供相同產品的更換。

免責事項

不保証本產品能與所有支援 Bluetooth® 的設備及應用連接及連接後的正常動作。我們對使用本產品可能導致的其他設備的故障、問題及資料丟失、損壞等不承擔任何責任。另外，我們也不承擔由於電腦、作業系統、其他軟體、支援設備等的故障、問題及資料丟失、損壞而導致的損害責任。敬請諒解。

常見問題 / 諮詢

請查看支援頁面。

關於商標

- **Bluetooth®** 字樣和圖示是注冊商標，歸屬於 Bluetooth SIG, Inc.。Preseed Japan Corporation 在授權下使用這些商標和標誌。
- USB Type-C® 和 USB-C® 是 USB 開發者論壇的註冊商標。
- 其他商標及注冊商標是歸屬於各自持有者的商標及注冊商標。