

User Manual

Only suitable for
cold areas with an
altitude below 2000m

Only suitable for
warm-tropical
conditions

Do not open the case

Do not get wet

Wipe with clean cloth

No chemical cleaning

Do not cover the lens


Do not look directly into the lens

Disconnect power when not in use

- ◆ The best projection screen-range of this projector is 80-100 inches, allowing you to indulge in different audio and video horizons. It has native Android system built in. You can also play local videos via USB.
- ◆ This projector can play clear pictures and videos in a bright environment.
- ◆ With speaker built in, if you need a larger volume output, you can connect to an external audio system through the 3.5MM interface.

① 3.5mm Audio output
② HD output
③ USB 1
④ USB 2
⑤ Preset Interface
⑥ Infrared remote control receiving window
⑦ The power interface

projector Remote control Power cable User manual



When the projector is connected to the power supply, the projector enters the standby state:

Start up: press the power button on the body, or the power button on the remote control, and the projector will start to work.

Power off: press the power button on the body, or the power button on the remote control, and the projector will shut down.

 The image is blurred after power-on.
Please rotate the focal circle to clear the image.

Place the projector lens perpendicular to the projection screen or curtain wall, rotate the lens to adjust until the image is clear, that is, to complete the image focusing. During the focusing process, you can play the program or bring up the menu image of the product to match the focusing adjustment.

- Open "Settings" and enter "Projection Settings".
- Select "Trapezoidal correction", "vertical correction" and "four-point correction" respectively.

Vertical

M. four o'clock

The level of

Set up

Network Settings > Display

Network Settings	Location	Advanced Settings	The device information
GP Projection method ← The desktop is call →			

Set submenu functions

Network Settings

Find the network IP automatically obtain the IP address/Manually set the network address/Disconnect the network

Projection Settings

Projection method / desktop projection / desktop projection / lifting projection / lifting projection

projection/Advanced Settings

Language/Power management/Always time/Local upgrade/Online upgrade/Factory restore

2. Select Settings page from the OK key.

3. Select Network Settings, press down to select Wireless, and then press OK.Click or click "Third Network". To confirm the WiFi hot access on the right press OK for the confirm the WiFi to be connected. Check the actual keyboard on the computer's password; 3. After entering the password, press the "Back button" on the remote control, and then click OK to connect.

 Set up

Home > Settings > Network Settings

Advanced > properties > General > The network information

The wireless network

Click for the network

Automatic IP allocation

Status: P connection

P 100% link

Disconnect the network

IP-addr, MAC, SSID

TX-LINK_SSAD

TX-LINK_SSAD

TX-LINK_SSAD

1. Insert the USB flash drive into the USB port of the projector.
2. Select Media Center and press the OK key.
3. Select a file to play.

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can contain radio frequency components that may interfere with other electronic equipment. This interference may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur under all conditions. If the equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for uncontrolled environments. These limits are designed to provide a margin of safety between human exposure to electromagnetic fields (EMF) and the limits set by the FCC.

The product is suitable for areas with an altitude of less than 2000m in non-tropical climates, and the operating temperature is 25 degrees Celsius.



Do not disassemble or repair the machine.
Always use the specified power plug to avoid damage.