尺寸:72*120mm
材质:128g双面铜版纸

Cyboris S18

Magnetic Split Bluetooth Speaker




Manual

PARAMETER

Model	Cyboris S18	Input	Type-C 5V/1A
BT version	V5.3	F.R	100Hz-18KHz
BT range	⩽18M (Open field)	Distortion	⩽8%
Speaker	2*10W	Speaker size	52mm
Battery	3.7V 2000mAh*2	Full charge	3-4H

BUTTON FUNCTION



ACCESSORIES



Type-C cable*2

CONNECTION AND PLAY

•BT wireless playback

a.The light flashes after power on, and the speaker enters the Bluetooth waiting state;

b.Turn on the Bluetooth of the mobile phone, search for the Bluetooth name "Cyboris S18" and click connect;

c.With a beep, and the Bluetooth connection is successful.

• TWS connection and playback

a. Two new "Cyboris S18" will be directly connected when they are turned on at the same time (with prompt tone);

b. Open the mobile phone to search for the Bluetooth name "Cyboris S18" and click to connect; there is a prompt sound after the connection is successful, and you can enjoy the wireless stereo sound effect by playing music;

c.TWS can only be used in Bluetooth mode.

PS: When two speakers are not interconnected and powered on simultaneously, they will display two separate Bluetooth names, allowing each to be connected independently to two different devices as standalone speakers. To disconnect the interconnection while they are linked, press and hold the "+" and "-" buttons simultaneously on one of the speakers.
If the two speakers fail to interconnect, please disable Bluetooth on your phone, restart both speakers, and they will automatically reconnect.

• AUX cable playback

Connect the AUX cable to the device and the speaker to play.

• Micro SD card playback(up to 64G)

After inserting the SD card into the speaker, with a beep, the speaker will automatically read the card and play,and the blue light flashes (supports MP3 format playback).

• USB flash drive playback(up to 64G)

After inserting the USB flash drive into the speaker, with a prompt sound, the speaker automatically reads the card and plays, and the blue light flashes at this time (supports MP3 format playback).

Button	Operating	Function Description
⏻	Short press	When the music is playing: short press the play/pause
	Long press	Long press for 3 seconds to turn on/off.
M	Short press	Switch Playback Mode
	Long press	Turn on/Turn off the light
+	Short press	Volume up
	Long press	Next song
−	Short press	Volume down
	Long press	Previous song

POWER DESCRIPTION

a. Please use the charger that supports 5V/1A and the original Type-C cable for charging;

b. The red light is always on when charging, will turn off when fully charged;

c. When the voltage is too low, there will be a "beep" tone.

GUARANTEES SERVICE

After-sales service content:

1. Within 7 days from the day after you sign for the product, if there is a performance failure listed in the "Speaker Performance Failure Table", the product can be returned or exchanged for free if it is determined by testing;
2. Within 8-15 days from the day after you sign the receipt, if this product has a performance failure as listed in the "Speaker Performance Failure Table", it will be determined by the after-sales service center, and you can enjoy free replacement or repair services;
3. Within 12 months from the day after you sign for the product, if there is a performance failure listed in the (Speaker Performance Failure Table), it will be determined by the after-sales service center and you can enjoy free maintenance services.

《 Speaker Performance Failure Table 》

1. The device cannot be charged, or cannot be turned on normally after charging;
2. Device keys cannot be used normally;
3. The device can't make a sound;
4. The device function cannot be used normally due to other hardware failures.

No Three Guarantees Service:

1. Unauthorized maintenance, misuse, collision, negligence, abuse, liquid ingress, accident, alteration;
2. Improper use of accessories other than this product, or tearing up or altering the label;
3. The validity period of the three guarantees service has expired;
4. Damage caused by force majeure such as fire, flood, lightning strike, etc;
5. Does not meet the performance failures listed in the (Speaker Performance Failure Table);
6. Due to human reasons, this product and its accessories have performance failures listed in the (Speaker Performance Failure Table).

SAFETY PRECAUTIONS

1. The equipment complies with the standard GB 4943.1-2022
2. This product cannot be taken, please keep it out of the reach of children to prevent accidents;
3. Do not place the machine in a high temperature environment, including direct sunlight;
4. Do not place the machine near fire sources or other overheated environments;
5. Do not place the machine in a humid or humid place;
6. In addition to the provided charging cable, please do not try to use other methods to charge the machine;
7. Do not disassemble the machine, and prohibit any attempt to repair or modify the machine;
8. Please pay attention to drops, impacts, scratches or other behaviors that affect the function of the machine. If there is any damage, such as hot, high temperature deformation or corrosion, please stop using the product and equipment immediately and contact the merchant;
9. If the machine produces abnormal odors, higher than normal temperature, and abnormal changes in color or shape, please stop using the machine immediately and contact the merchant;
10. If the battery is incorrectly replaced, there is a risk of burning, and only the same type or equivalent type of battery can be used for replacement;
11. Using the machine at high volume for a long time may cause damage to your hearing.

KIND REMINDER

1. When the machine has not been used for more than 3 months, the machine needs to be charged before use;
2. When not in use for a long time, it is recommended to charge the machine once every 3 months, which can more effectively protect the battery;
3. It is recommended to use the machine after it is fully charged.

PRODUCTION INFORMATION

Product name: Magnetic Split Bluetooth Speaker
Model: Cyboris S18
Service telephone: 0755-2373-9380
Email: sales@cyboristech.com
Producer: Shenzhen Haisaite Technology Co., Ltd.
Manufacturer Address: 2nd Floor, 3rd Factory Building, Area A, Xiangli Industrial Park, No. 1 Xiangli Road, Longhua District, Shenzhen

www.cyborisaux.com

Cyboris
Create Your Better Life

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note:
The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.
The device can be used in portable exposure conditions without restriction.

Warranty Card

Dear customer, thank you for purchasing our products. In order to better serve you, after purchasing the product, please read carefully and keep this warranty card carefully

Warranty description

1. Please keep this warranty card properly for maintenance certificate
2. This product is warranted for one year from the date of purchase
3. Warranty equipment during the warranty period, in the state of normal use and maintenance, there are problems and failures in machine materials and processes. Upon verification, we will provide repair services free of charge
4. During the warranty period, if the following events occur, the company has the right to refuse service or collect materials and service fees according to the situation
 (1) Cannot provide this warranty card and valid proof of purchase
 (2) Product failure and damage caused by improper use by users
 (3) Man-made abnormal external force damage
 (4) Damage caused by disassembly by maintenance service personnel not authorized by our company
 (5) Failure or damage caused by natural disasters or other force majeure factors
 (6) Others intentionally damaged
5. Our company reserves the right to modify and explain all content

Product information

Maintenance Records	Date	Fault description
Product Model		
Customer Name		
Customer Phone		
Purchase Date		
Shipping Address		