

AUT208AP INTERNAL PHOTOS


EUT UNCOVER VIEW 1




EUT UNCOVER VIEW 2




MAIN BOARD TOP VIEW




MAIN BOARD REAR VIEW



BATTERY (FRONT)



BATTERY (REAR)




AUT208B INTERNAL PHOTOS


EUT UNCOVER VIEW 1




EUT UNCOVER VIEW 2




MAIN BOARD TOP VIEW




MAIN BOARD REAR VIEW



BATTERY (FRONT)




BATTERY (REAR)



AUT208N INTERNAL PHOTOS

EUT UNCOVER VIEW 1



EUT UNCOVER VIEW 2



MAIN BOARD TOP VIEW

