


LABEL AND LOCATION

1HORA | WIRELESS SPEAKER**MODEL: BOC300****INPUT: 100-240V~50/60Hz****BATTERY CAPACITY: 6000mAh / 7.4V / 44.4Wh****POWER: 60W****FCC ID: 2A9HV-BOC300****www.1hora.com****MADE IN CHINA****LOTE:OP0626**



NOT TURNING ON

1. Check whether the speaker has enough battery power.
2. Try another AC power cable to charge the speaker.
3. Remove the TF card, USB drive, and audio cable, then try again.

NO RGB LIGHTING EFFECT

1. Press and hold the LED button.
2. Press and hold the Bluetooth button and the LED button at the same time to restore the factory default settings. After the speaker automatically turns off, turn it on again.

MICROPHONE FEEDBACK

1. Adjust the "ECHO+" button.
2. Try another model of wired microphone.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PACKING LIST

Wireless speaker x1 AC Power Cable x1 AUX cable x1 User manual x1

WARRANTY STATEMENT

All products are guaranteed to be free from defective materials and workmanship. The warranty period of all equipment provided by our company is 12 months after purchase.

If you have any questions, please contact a customer service representative for assistance.

CUSTOMER SERVICE

✉ support@1hora.com 🌐 www.1hora.com

FCC ID: 2A9HV-BOC300



Reminder: According to the § 15.19(a)(3), warning statements have been added to the operation manual and the outer packaging.

