

快拆板配置详情
Quick release bracket configuration

型号 Model	59906	59927
适用机型 Suitable for motor	50700/50736	50718D/50737/50738

中山市雅太电器有限公司
Yatai Electric Appliances Co.,Ltd.
地址：中国广东省中山市三乡镇南龙新龙街四号
Add:No.4 Xinlong St.Nanlong, Sanxiang,
zhongshan, guangdong Province, China.
邮编/Postcode:528463
电话/Tel: +86 760 86692666
传真/Fax: +86 760 86692996
WWW.HASWING.COM

版本号/Version: V02
Printed in China

To The Owner

Thank you for selecting a Haswing electric outboard motor. It's designed for the purpose of superior performance, portability and environmental contribution. Enjoy using the Haswing Cayman B/with GPS!

This Owner's Manual contains important information pertaining to installation, correct operation and maintenance. Please read the manual before using this motor. If you have any questions contact your local Haswing distributor in the country of purchase.

★ We welcome comments regarding product improvement.

To avoid hazards and to obtain maximum performance and usage, special symbols are noted in this manual.



Failure to follow the instructions could cause severe injury.



Special precautions must be taken to avoid damage to the motor.



Information that makes the procedures easier and faster.

致用户

感谢您选购“汉飞”所生产的电动船用推进器。它具有低噪音、无污染、操作性强、方便携带等优点，充分满足广大船舶爱好者的需求。我们衷心希望您能尽情体验水上娱乐的美好时光。

本用户手册包含正确安装，操作，保养等重要说明。为了让推进器操作顺畅，建议用户在使用前应彻底理解手册上的内容及重要事项。如对手册上的操作或维护事项有所疑问，请咨询汉飞客户中心。

★ 为提高产品质量，我们欢迎广大用户给予评价及改进建议。

为确保操作顺畅，防止意外发生，在用户手册及产品上注有特别符号信息。符号类别如下：



表示如不遵守指示可能导致操作人员及他人严重受伤。



表示必须采取特殊措施以免推进器损坏。



表示使程序更容易，更快捷地完成。

Contents

Product features2

Before operating3

Installation

 ❶ Installing the propeller 3-4

 ❷ Installing the fin 4

 ❸ Mounting the motor 5

 ❹ Battery connection 5

How to operate the motor6-9

Audio Pattern9

Trouble shooting9

Maintenance10

Electric Circuit Diagram10

Package contents17

Read this page
before install

目录

部件图2

注意事项11

安装

 ❶ 螺旋桨安装11-12

 ❷ 电机鳍安装 12

 ❸ 推进器的安装 12

 ❹ 电源安装 13

推进器操作方式13-16


蜂鸣模式 & 故障与修复 & 维护与保养16

推进器电路图10


装箱清单17

首次安装前必阅

Before operating the motor



Only use deep cycle battery or batteries to power the motor. Incorrect or improper use, or connection of the battery could cause damage to the motor. Disconnect the battery when stowing the boat or not using for an extended period.



When motoring with the electric trolling motor in shallow water or around obstacles, reduce speed. Raise or retract the motor when in shallow water. Be aware of swimmers in close proximity to your vessel.

注意
CAUTION

IP68 waterproof level for the motor
IP63 waterproof level for all but the motor

1 Propeller installation

1.Install the drive pin (drive pin and cross-shaped slot in the propeller must align in order to correctly fit the propeller to the motor), anode, washer and self-locking nut onto the drive shaft. (Fig. 1)

注
NOTE

The cross-shaped slot (2 slots) allow the user to re-assemble the propeller if one slot is worn.






Fig.1



Always wear an approved life vest or PFD (personal flotation device) and comply with local boating regulations.



Remove any debris from around the propeller or propeller drive shaft. Wash with freshwater after using in saltwater.