

Luxury Massage Chair

Operation Manual

MODEL: A8818



FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

catalog

One, catalog	1
Two, Safety precautions	2
1、Usage environment	2
2、Not suitable for use	2
Three、Preparation before use	3
1、Cushion installation	3
2、Sitting posture adjustment	3
3、Moving method of massage chair	4
4、Placement of massage chair	4
5、Power on	5
Four、Main structure name and function	6
Five、Introduction of control panel function	7
Six、Massage program operating instructions	8
Seven、Daily maintenance	9
Eight、technical parameter	9

Warm tips: our company reserves the right to improve the products and instructions. We are subject to change without notice. The appearance of the products shall be subject to the actual products. If there is any difference between the products and the real products due to product upgrading or other reasons, please refer to the real products.

Product warranty card

Dear users:
Thank you for using our products. We will provide you with the following services with this warranty card in accordance with the relevant provisions of the consumer protection law:
1. During the warranty period, if the fault is caused by the quality problem of the product itself, please bring the filled warranty card to the repair center authorized by our company.
2. Once the warranty card is altered, the warranty will be invalid immediately.
3. Keep the warranty card as the warranty certificate of this machine. Please keep it properly.

Maintenance service guarantee

Please contact our customer service center if there is any problem with this product.
This product is guaranteed for one year.
One of the following conditions is not covered by the warranty:
1. Damage caused by improper use, storage and maintenance of consumers.
2. Damage caused by assembling, disassembling and repairing by the company's designated maintenance department.
3. Damage caused by force majeure.
4. Leather cover, manual controller and consumable accessories are not covered by the warranty.
5. Our company is not responsible for the quality accident caused by using our non-standard gifts.
6. This product is used for non home use and will not be covered by warranty.
7. Failure caused by human or improper use is not covered by warranty.
8. The machine failure caused by the parts that do not conform to the product parameters purchased without permission is not within the scope of warranty, and the accidents caused are not within the scope of our company's responsibility.
9. For products not covered by warranty, our customer service center will still serve you warmly.

This volume has been carefully checked, but it does not exclude possible printing errors or misunderstandings. We reserve the right of interpretation, please understand.

User warranty certificate

(saved by the user and presented to the maintenance site during maintenance)	
Product name: _____	
Model: _____	
Place of Origin: _____	
Warranty period: _____	
Purchase date: _____	
Maintenance records:	
Date of repair: _____	
Failure, maintenance and treatment: _____	
Maintenance unit: _____	Signature of maintenance personnel: _____

Daily maintenance

- (1) The massage chair should be kept clean and dust-free at all times, and placed in a non-damp place
- (2) If you will not use it for a long time, please cover it with a cloth.
- (3) Do not place the massage chair in the sun or in a high temperature place, which will cause the leather of the massage chair to fade and accelerate aging.
- (4) To clean the massage chair, please turn off the power switch and pull out the power plug.
- (5) Do not use cleaning agents containing organic solvents, such as benzene, to clean the massage chair, otherwise it will cause the leather to fade, age, crack, etc.

Technical Parameters

Product name: Luxury massage chair
Product model: A8818
Rated voltage: 110V~
Rated frequency: 50Hz
Rated power: 90W
Rated working time: 15~30 minutes

Safety Precautions

1. Use environment

- (1) Do not use or keep this machine in particularly humid environments such as bathrooms, saunas, hot springs, etc., to avoid mold, electric shock, fire or mechanical failure.
- (2) Do not use in an environment where the room temperature is above 40 degrees Celsius.
- (3) Do not use this machine outdoors.
- (4) Do not use the machine in an environment with too much dust, oil, or lack of oxygen.
- (5) Do not place the machine in a hot air stove, stove or a place exposed to direct sunlight. This will cause the massage chair's parts to overheat and cause fire hazards.
- (6) Do not use this machine on uneven places. Please place the bracket on a level place such as the floor for use.
- (7) To prevent electric shock, please confirm whether the socket is grounded. Please consult us when installing the ground wire in the socket.
- (8) Do not use when smoking.
- (9) When the airbag is inflated, do not pull out the limbs such as arms and legs, which will cause the airbag to fall off and need to return by itself.
- (10) Do not step on the side rollers or airbags, please pay attention to getting in and out of the massage chair. If it falls off, you need to fix it back.

2. Not suitable for users

The following people please consult a doctor before using


- (1) Patients suffering from malignant tumors or malignant pus
- (2) Patients with severe heart disease
- (3) Patients with severe skin diseases
- (4) Patients with severe bone hyperplasia
- (5) Those who are pregnant
- (6) Being recuperating under the instructions of a doctor, especially those who feel abnormalities in their body
- (7) Those who have abnormal spine or back curvature due to accidents or diseases
- (8) Those who need quiet
- (9) Those with joint deformities
- (10) Those who have medical devices such as pacemakers implanted in their bodies
- (11) Those with acute symptoms such as visceral diseases (such as gastritis, enteritis, hepatitis, etc.)
- (12) Those with severe blood circulation disorders in the legs
- (13) Persons with sensory impairments, the surface of the hot air piece becomes hot, and people who are not sensitive to heat must pay attention to it when using it.
- (14) Those with high fever symptoms
- (15) This product is not recommended to be used by people (including children) who are physically impaired, sensory or mentally impaired, or lack relevant experience and knowledge, unless someone responsible for their safety supervises and guides their use of this product.
- (16) Children should be taken care of and ensure that they do not play with this product.
- (17) If the power cord is damaged, it must be replaced with a special component obtained from its manufacturer or its maintenance department.

Do not allow people under 18 years of age and people who cannot control their behavior (such as: mentally, handicapped people, paralyzed patients, etc.) to operate the massage chair alone or touch various parts of the massage chair. This situation may cause electric shock or injury to the user or malfunction of the machine.



Three、preparation before use

1. Cushion installation



2. Seat adjustment

To adjust the seat back, press and hold the hand control adjustment switch to adjust the tilt angle of the seat back.




Requirement: When adjusting the backrest and leg cushion, make sure that there is enough space before and after the massage chair.

Six、Massage program operating instructions

- ON/OFF** Press the "standby key" key to enter the "leisure mode" operation by default, and then press the "standby key" key to shut down and enter the standby mode.
- Shoulder kneading** Press the "head and shoulder airbag" button to turn on/off the head and shoulder airbag function.
- Arm&Hip kneading** Press the "arm hip airbag" button to turn on/off the arm hip airbag function.
- Leg kneading** Press the "Leg Airbag" button to turn on/off the leg airbag function.
- Pressure+** Press the "Air+" button to turn on the airbag function button, and press the "Air+" button to increase the air pressure.
- Pressure-** Press the "air pressure-" button to turn on the airbag function button, and press the "air pressure-" button to reduce the air pressure.
- Airbag automatic** Press the "Airbag Auto" button to turn on/off the airbag automatic function.
- Kneading mode** Press the "Kneading mode" button to turn on/off the kneading mode massage function.
- Massage mode** Press the "Tuina Mode" button to turn on/off the massage function in Tuina Mode.
- Forward reversal** Press the "forward and reverse" key to turn on/off the forward/reverse massage function.
- Speed+** Press the "Speed +" button, the massage intensity will increase.
- Speed-** Press the "Speed" button, the massage intensity will decrease.
- Back auto-massage** Press the "Auto Back" button to turn on/off the automatic back massage function.
- Fully automatic** Press the "Automatic" key F1 "Relaxation", F2 "Fatigue Recovery", F3 "Relieve Muscles", F4 "Sore Improvement", F5 "Soothe the Mind and Help Sleep", and perform targeted massage in any one of the 5 modes (see details LCD screen).
- Timing** Press the "time key" key to select six time adjustment modes: "6 minutes", "10 minutes", "15 minutes", "20 minutes", "25 minutes" and "30 minutes".
- Sole massage** Press the "foot kneading" button to turn on/off the foot kneading massage function.
- Stable heating mode** Press the "constant temperature and heat" button to turn on/off the constant temperature and heat massage function.
- Zero gravity** Press the "Zero Gravity" button to make the massage chair go to the zero gravity state.
- Rise up** Press the "return" button, the legs begin to slowly descend, and the back begins to slowly rise: after the angle is in place, release this button to lock it.
- Lay down** Press the "Lean Down" button, the legs will start to rise slowly, and the back will slowly fall: after the angle is in place, release this button to be locked.
- Buttock massage** Press the "buttocks massage" button to turn on/off the buttocks massage function.

Five、Brief introduction of control panel function



3. Moving method of massage chair


When moving, lift the armrest on both sides and move it.

be careful! Don't move people. Don't use small pulleys to move on easily damaged floors.

4. Placement of massage chair

Please leave space around the massage chair when you are preparing for massage

- (1) There should be enough space for the massage chair to lie on the back and lift the foot rest.
- (2) Make sure there is at least 80 cm in the back and 50 cm in front of the chair.
- (3) Make sure there are no obstacles in front of and behind the massage chair.
- (4) In order to prevent the ground from being damaged, please place a carpet under the massage chair to avoid damaging the floor.




5. Power on

Insert the plug into the power socket and turn on the power switch.

! be careful

- ① Please check whether the power cord is pressed under the massage chair.
- ② Whether the ground wire is well connected.
- ③ Before inserting the plug, make sure that all operation buttons (including the main power switch) are turned off.



Four、Main structure name and function

