




User's manual

Attention

C idea tablet contain important security measures and the correct use of the product information,in order to avoid accidents,please make sure to read the manual carefully before using the device.

- > When charging,please only use C idea charger to protect your device
- > Please don't be in high temperature,moisture place
- > please don't put the device in the car
- > Don't crash or no stack on it.
- > Don't invade it by other article
- > Keep it away from the chemical or the water drop
- > Keep it away from the direct sunlight or the other heating article
- > Keep it away from the dust
- > Backup the files or important information stored in it
- > Don't refurbish or repair without the authorization
- > For those who because of damage to the product,repair or other causers of erased the memory.the company shall not be liable for any responsibility.please follow the user manual for the standardized operation to use the device



Power ON/OFF

Start or Shut the PC

Start the tablet pc

If power is off, press the “power on/off” button for continual 5 seconds

Shut the tablet pc(power off)

At any working status, press the “power on/off” button for continual 5 seconds, it will display 2 options: cancel ok

Reset

If the tablet pc “die” when working, press the “power on/off” button for continual 8 seconds. Re-start it

Unlock screen

At the screen-saving (black screen) status, press “power on/off” button shortly to siren the screen, and move the lock icon to the unlock location, then operate again.



Reset

Factory settings

If the device is infected with computer virus, or the applications by the third party, please prick the “reset” by using a needle and wait for the original factory settings.

First use

Battery management and charge

Before first using, please make sure the battery is charged 100% completely. please use the factory equipped adaptor and USB interface for tablet charging connecting. for the second times charging, please keep the charging term is about 6 hours. then 4 hours for each time.

Remark

The tablet must be charged once every month during storage, otherwise the battery will discharge. Device should be in standby status if for no long time using. because with device and screen consumption, it may cause longer charging term and damage the device.

OTG

It is the abbreviation of on-the-go, it allows the data-transferring and data-sharing between this device and other one without "host".

1, connect this device with other one for example flash memory through OTG converter

2, press "file manage" after this device display "external devices in", then press the icon  all the files will be listed.

Remark:

The original OTG converter is recommended. If other USB storage is found incompatible, please download the firmware from the authorized homepage.

When OTG being used, make sure the sufficient battery power inside this device. If other USB storage has the independent power supply, please turn on the power.

OTG is compatible with the external keyboard, mouse and other device.

Connecting with the PC

Connect this device with PC by USB cable, then it will work as the mobile storage for PC (remark: all the files inside the internal storage of this device is read only by PC. It can run other option like the WIFI internet etc. turn off USB storage, it can read the files inside itself again).

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.