

BENF-15

Quick Instruction Manual



Important Reminder:
Before installing the headset, please connect your mobile phone according to the quick manual guide to test the sound effect and volume.
If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

BENF-15

快速使用说明书



重要提醒:
耳机安装前, 请按快速手册指引连接手机, 试听音效和音量。
如安装到头盔后, 音效和音量有较大的差异, 请调整喇叭在头盔内的位置。

Power on/off

Double click to switch language broadcasting(Disconnect wireless)



Power on tone



Press and hold for 3 seconds to power on/off

LED light flashing rapidly

Wireless connection



Wireless waiting for pairing: LED light flashing rapidly

Wireless mode tone



Wireless pairing successful: LED light flashes slowly

Voice assistant



Long press the "Voice Assistant button" to wake up the voice assistant.


When the wireless connection is successful



Long press again to exit the voice assistant

Telephone function

Double-tap to toggle manual/automatic answer(when not connected to wireless)



Automatic (0 after 15 seconds)



Answer the phone (incoming call)



Manual answer "short press" (incoming call)



Answer the phone (incoming call)



Long press 2 seconds (incoming call)



Decline to answer the phone



"Short press" during a call



Hang up the phone



Double click



Redial the last number



Short press



Cancel a call

Music function



Short press (while music is paused)



Play (while music is playing)



Pause



Volume down button (while music is playing)



Short press Previous song (while music is playing)



Long press Volume down (while music is playing)



Volume up button (while music is playing)




Short press Next song (while music is playing)



Long press Volume up (while music is playing)

开机/关机

双击切换语言播报 (断开蓝牙)



开机提示音



长按3秒开/关机

LED灯快闪

蓝牙连接



蓝牙等待配对状态 LED灯快闪

蓝牙模式提示音



蓝牙配对成功 LED灯慢闪

语音助手



长按"语音助手键"唤醒语音助手

蓝牙连接成功状态下, 再次长按退出语音助手

电话功能

双击切换手动/自动接听 (未连接蓝牙)



自动 (0.15秒后) (来电中)



接听 (来电中)



手动接听"短按" (来电中)



接听 (来电中)



Long press 2 seconds (来电中)



拒绝接听 (来电中)



通话时"短按" (通话中)



结束通话 (来电中)



双击



未码重拨



短按



取消去电

音乐功能



短按 (音乐暂停时)



播放 (音乐播放时)



暂停



音量+键 (音乐播放时)



短按上一曲 (音乐播放时)



长按音量减小 (音乐播放时)



音量+键 (音乐播放时)




短按下一曲 (音乐播放时)



长按音量加大 (音乐播放时)

FM radio function

Short press to switch to the previous channel, Long press to decrease FM volume (in FM mode)



Short press to switch FM mode/wireless mode

Short press to switch to the next channel, Long press to increase FM volume (in FM mode)




Double-click Auto search station, double-click again to exit search station (in FM mode)

Short press to mute or play (in FM mode)


Charging function



Charging red light is always on



(With the machine switched on, plug in the charger to charge and the machine will automatically switch off)



Red light goes out when fully charged

Operation overview

Wireless Connection Operation Guide (FM is disabled by default at each startup)

I. Clear Pairings and Restore Factory Settings

Power on the device. While not connected to wireless, simultaneously press and hold the Volume Down and Volume Up buttons for 5 seconds. After the indicator light flashes rapidly, the device will restore factory settings and clear all paired devices.

II. Call Priority

After powering on, when the device connects to wireless, it will automatically prioritize phone calls regardless of its current mode. Whether receiving or making a call, the device will switch to phone mode. After hanging up, it will resume its previous mode.

Product List

BENF-15 Device*1




Speakers & Microphone*1



Clip on Base*1



Velcro Package*1



Type-C Charging Cable*1



User Manual *1

Caveat

- To avoid explosion please do not put the product into the flame.
- Please do not disassemble the product to avoid damage to the electronic components of the product.
- Please keep away from sharp objects to avoid damage to the product.
- Please keep in a dry place if not used for long time.
- Before using the wireless device, please fully charge it.
- If the red light does not come on while charging, it may be the voltage is too low.
- To extend the life of the built-in lithium polymer battery, please charge the device at least once a month.


Instruction warning

NOTE: This product has been tested, meet the restrictions of Class B digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio and television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures.
-Reorient or relocate the receiving antenna.
-Increase the separation between the device and receiver.
-Connect the device into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.
This device complies with Part 15 of the FCC Rules. The operation needs to fulfill the following two conditions.
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

* RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


FM收音功能

短按切换至上一频道, 长按减小FM音量 (FM模式下)



短按切换FM模式/蓝牙模式

短按切换至下一频道, 长按增加FM音量 (FM模式下)




双击自动搜台, 再次双击退出搜台 (FM模式下)

短按静音或播放 (FM模式下)

充电功能



充电时红灯常亮



(开机状态下, 插入充电器, 机器会自动关机)



充满熄灭

操作简介

蓝牙连接操作简介 (每次开机FM默认关闭)

一: 清除配对, 恢复出厂设置

开机在没连接蓝牙的情况下, 同时长按音量减和音量加键5S, 指示灯快闪后, 即恢复出厂设置, 清除所有配对信息。

二: 电话优先

开机后, 机器连接上蓝牙, 无论机器处在哪个模式下, 当机器来电或者去电, 都会优先自动进入电话模式, 挂断后恢复相应的模式。

产品清单

BENF-15主机*1



喇叭麦克风*1




夹式底座*1



魔术贴安装包*1



Type-C充电线*1



使用说明书*1



注意事项

- 请勿将产品投入火中, 避免发生爆炸;
- 请勿拆卸产品, 避免产品电子器件损坏;
- 请勿靠近尖锐器物对产品造成损坏;
- 长时间不用, 请放置于干燥处;
- 使用蓝牙设备前, 请先将其充满电;
- 如果充电时红灯不亮, 可能是电压过低;
- 为了延长内置聚合物电池的使用寿命, 请每月至少为设备充电一次。