Q08快速使用说明书

产品概览

重要提醒:
耳机安装前,请按快速手册指引连接手机,试听音效和音量。
如安装到头盔后,音效和音量有较大的差异,请调整喇叭在头盔内的位置。

开机/关机

双击切换中英文语音播报
(断开蓝牙)



长按3秒开/关机

显示屏显示开机图标

LED灯常亮

蓝牙连接



蓝牙未连接
蓝牙图标慢闪

蓝牙模式提示音



蓝牙连接成功
蓝牙图标常亮

EQ音效模式

长按切换6种音效



JAZZ 爵士音效模式
NOR 自然音效模式
POP 流行音效模式
COUN 乡村音效模式
ROCK 摇滚音效模式
CLAS 古典音效模式

FM收音

短按向下切换已保存的电台
(FM模式下)

短按向上切换已保存的电台
(FM模式下)

短按自动搜台
(搜完自动保存)
(FM模式下)



长按切换FM和蓝牙模式
(显示屏显示FM信号图标)

短按静音或播放
(FM模式下)

电话功能

双击切换手动/自动接听
(未连接蓝牙时)



自动(10秒后)

(来电中)

接听

手动接听"短按"

(来电中)

接听

长按2秒

(来电中)

拒绝接听

通话时"短按"

(通话中)

结束通话

双击

末码重播

短按

(去电时)

取消去电

充电模式



充电红灯常亮 (在机器开机情况下,插入充电器充电,机器会自动关机) 充满红灯熄灭



音乐功能

短按

(音乐暂停时)

播放

(音乐播放时)

暂停

音量-键



(音乐播放时)

短按上一曲

(音乐播放时)

(显示屏数字最小显示0)
长按音量减小

音量+键



(音乐播放时)

短按下一曲

(音乐播放时)

(显示屏数字最大显示30)
长按音量加大

LCD显示屏图标注解

电池

蓝牙

音量

FM信号

播放

暂停

温度摄氏度

温度华氏度

期待与您
再次同行
中文关机

爱·骑行
亲·生活
中文开机

语音助手



(蓝牙模式已连接蓝牙状态下)语音助手键

短按

唤醒语音助手

物品清单

Q08主机*1



喇叭麦克风*1



夹式底座*1



魔术贴安装包*1



Type-C充电线*1



使用说明书*1

注意事项

1、请勿将产品投入明火中,避免发生爆炸;2、请勿拆卸产品,避免产品电子器件损坏;
3、请勿靠近尖锐器,物对产品造成损坏;4、长时间不用,请放置干燥处。

Q08 QUICK MANUAL INSTRUCTION

Product overview

Notes:
Please follow the Quick Manual instructions to connect the device to your phone and test the sound and volume before installing the headset. If there is a large difference in sound and volume after installation to the helmet, please adjust the speaker position in the helmet.

Power on/off

Double-click the button to switch the Chinese and English voice broadcast (Disconnect Bluetooth)



Press and hold for 3 seconds to turn on/off the device

Power-on tone

LED blinks quickly

Intercom pairing



Connection failure, the green light blinks quickly

Connection succeed, the green light keeps on

Turn on the devices, short press the intercom button of one of the devices enter the intercom mode, before the Bluetooth connection. The green light keeps on, after the pairing succeed. You can start intercom call when hearing the "Dong" sound.

Bluetooth connection



Bluetooth waiting for pairing, LED blinks quickly.

Bluetooth mode tone

Bluetooth paired, LED blinks slowly.

Phone features

Double-click to switch manual /auto answering
(When Bluetooth is not connected)



Charging mode



The red light keeps on, when charging

If you plug in the charger, the device will shut down automatically when the device is turned on

Light goes out after fully charged

Music features



voice assistant



Voice Assistant button

Long press to turn on/off light, with light off memory.

Intercom reset

Press for 5 seconds at the same time



Introduction to Bluetooth intercom connection operation (After the intercom connection is successful, the Bluetooth music is turned off, the phone will automatically switch to the call mode when it comes, hang up the call and restore the intercom) :
1. Two devices are intercom connected for the first time: press the intercom button of one of the devices to enter intercom mode, and accompanied by the prompt tone "intercom pairing", there will be a prompt tone "intercom connection" after the device be paired succeed, when you hear a "dong" sound, start the intercom call, at this time the intercom indicator light keeps on after the device is turned on, in the case of Bluetooth disconnection.
2. When the Bluetooth has been connected to the mobile phone, you have to disconnect the Bluetooth before to connect the intercom after the device is turned on, short press the intercom button to enter the intercom mode, after the intercom connection is successful, use the mobile phone to search for Bluetooth connection.
Intercom back connection:
If the two devices connected before turned on, the two devices will be connected automatically, or one of the devices will be automatically back connected into the intercom mode, and the intercom indicator light will keep on after the connection.
Answering call: the two devices are successfully connected to the intercom, the Bluetooth of the two devices is also connected to the mobile phone, when a phone comes in, the device will switch to the phone answering automatically, after hanging up, the intercom is restored.
Clear the intercom pairing, restore factory Settings:
In the case of not connected Bluetooth and intercom, then, press the volume button 5S, when you hear "Dong" sound to release, it will start to restore factory Settings, clear all pairing information.
Use the device to connect a third-party helmet Bluetooth headset for intercom calls:
The two devices enter the intercom mode without Bluetooth connection to the mobile phone after turning on.After the Bluetooth headset is turned on and enter to Bluetooth mode, the two devices start the conection. You will hear the"Dong" sound after the connection succeed. Then you can start intercom call.

List of items

Q08 Host*1



Speaker microphone*1



Clip-on base*1



Velcro installation package*1



Type-C charging cable*1



Instruction manual*1

Notes

1. Do not put the product into the open flame to avoid explosion;
2. Do not disassemble the product. Avoid damage to product electronics;
3. Do not approach the sharp object, the object will cause damage to the product;
4. Do not use for a long time, please place in a dry place.

instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmfulinterference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmfulinterference to radio communications. However, there is no quarantee that interference wil not occur in a particular installation. ifthis equipment does cuse harmful interference to radio or television reception. whichcan be detemined by tuming the equipment offand on, the user is encouraged totry to correct the interference by one or more of the following measures.
-Reorient or relocate the receiving antenna
-Increase the separation between the equipment and rereiver.
-Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliancecould void the user's authority to operate the equipment. This device complies with Part 15 ofthe FcC Rules. Operation is subject to the following two conditions.
(1) this device may not cause harmful interference. and
(2) this device must accept any interference received, including interference that may cause undesired operation.