


V2 快速使用说明书

产品概览



重要提醒：
耳机安装前，请按快速手册指引连接手机，试听音效和音量。
如安装到头盔后，音效和音量有较大的差异，请调整喇叭在头盔内的位置。


开机/关机



蓝牙连接



对讲配对




V2 Manual de inicio rápido

Descripción general del producto



Recordatorio importante:
Antes de instalar el auricular, conecte su teléfono móvil de acuerdo con la guía rápida del manual para comprobar el efecto de sonido y el volumen.
Si hay una gran diferencia en el efecto de sonido y el volumen después de instalar en el casco, ajuste la posición del altavoz dentro del casco.

Encendido/apagado



Conexión inalámbrica



Emparejamiento del intercomunicador



电话功能



语音助手




音乐功能




交友模式配对(连接第三方)




Función de teléfono



Asistente de voz




Función musical




Emparejamiento en modo social (conexión con terceros)




对讲重置



充电功能




产品清单




注意事项

1. 请勿将产品投入明火中，避免发生爆炸；
2. 请勿拆卸产品，避免产品电子器件损坏；
3. 请勿靠近尖锐器物对产品造成损坏；
4. 长时间不用，请放置于干燥处；
5. 使用蓝牙耳机前，请先将其充满电；
6. 如果充电时红灯不亮，可能是电压过低；
7. 为延长内置聚合物电池的使用寿命，请每月至少为设备充电一次。


Restablecimiento del intercomunicador



Función de carga



Lista de productos




Advertencia

1. Para evitar explosiones, no exponga el producto al fuego.
2. No desmonte el producto para evitar daños en los componentes electrónicos.
3. Mantenga el producto alejado de objetos afilados para evitar daños.
4. Si no va a utilizar el producto durante un periodo prolongado, guárdelo en un lugar seco.
5. Antes de utilizar el dispositivo inalámbrico, cárguelo completamente.
6. Si la luz roja no se enciende durante la carga, es posible que el voltaje sea demasiado bajo.
7. Para prolongar la vida útil de la batería de polímero de litio incorporada, cargue el dispositivo al menos una vez al mes.

V2 Quick Start Manual


Product Overview



Important Reminder:
Before installing the headset, please connect your mobile phone according to the quick manual guide to test the sound effect and volume.
If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

Power on/off


Double click to switch language broadcasting(Disconnect wireless)



Wireless connection



Intercom pairing



V2 Hızlı Başlangıç Kılavuzu

Ürün Genel Bakış




Önemli Hatırlatma:
Kulaklığı takmadan önce, ses efektini ve ses seviyesini test etmek için hızlı kullanımı kılavuzuna göre cep telefonunuzu bağlayın.
Kaskı taktıktan sonra ses efekti ve ses seviyesinde büyük bir fark varsa, kaskın içindeki hoparlörün konumunu ayarlayın.

Güç açma/kapama

Çift tıklayarak yayın dilini değiştirin (Kablosuz bağlantıyı kesin)



Kablosuz bağlantı




Interkom eşleştirme




Telephone function


Double-tap to toggle manual/automatic answer(when not connected to wireless)




Voice Assistant



Music function



Social Mode Matching (Connecting Third Parties)



Telefon işlevi


Çift dokunarak manuel/otomatik cevaplama arasında geçiş yapın (kablosuz ağa bağlı olmadığında)



Sesli Asistan



Müzik fonksiyonu



Sosyal Mod Eşleştirme (Üçüncü Tarafları Bağlama)




Intercom reset


Introduction to wireless intercom connection operation (the intercom is turned off by default every time you turn on the power)
I: Intercom connection
After turning on, both machines press and hold the "Intercom/Voice assistant button" to enter the intercom pairing mode. After the pairing is successful, the "Intercom connection" tone will be accompanied to start the intercom. After the connected machine is turned on, press and hold the "Intercom/Voice Assistant button" to enter the intercom mode, and the two machines will connect back to each other autonomously.

II: Wireless back connection
In wireless mode, after the connected machine is turned on, it will automatically connect back to the phone it was paired with for the last time.
III: Clear the pairing and restore the factory settings
In the boot state, press and hold the volume down and volume up buttons for 5S at the same time to clear all pairing information. The blue+green LED light flashes for 3 seconds at the boot button, and there is a beep tone.
IV: Telephone priority
After turning on the power, the machine is connected to the wireless. No matter which mode the machine is in, when the machine calls or goes to the phone, it will automatically enter the phone mode first, and resume the corresponding mode after hanging up.
V: Music playback is not supported in intercom mode
VI: Does not support one-to-two functionality

Charging function



Product List




Caveat

- To avoid explosion, please do not put the product into the flame;
- Please do not intentionally damage the product or the electronic components of the product;
- Please keep away from sharp objects to avoid damage to the product;
- Please keep in a dry place if not used for long time;
- Before using the wireless device, please fully charge it;
- If the red light does not come on while charging, it may be the voltage is too low;
- To extend the life of the built-in lithium polymer battery, please charge the device at least once a month.


Instruction warning

NOTE: This product has been tested, meet the restrictions of Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.
-Reorient or relocate the receiving antenna.
-Increase the separation between the device and receiver.
-Connect the device into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.
This device complies with Part 15 of the FCC Rules. The operation needs to fulfill the following two conditions.
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.


Interkom sıfırlama



Şarj işlevi



Ürün Listesi



Uyarı

- Patlamayı önlemek için ürünü ateşe maruz bırakmayın;
- Ürünün elektronik bileşenlerinin zarar görmesini önlemek için ürünü parçalarına ayırmayın;
- Ürünün zarar görmesini önlemek için keskin nesnelerden uzak tutun;
- Uzun süre kullanılmıyacaksa kuru bir yerde saklayın;
- Kablosuz cihazı kullanmadan önce tamamen şarj edin;
- Şarj sırasında kırmızı ışık yanıyorsa, voltaj çok düşük olabilir;
- Dahili lityum polimer pilin ömrünü uzatmak için, lütfen cihazı en az ayda bir kez şarj edin.