

Y20Max快速使用说明书



产品概览




重要提醒:

耳机安装前, 请按快速手册指引连接手机, 试听音效和音量。
如安装到头盔后, 音效和音量有较大的差异, 请调整喇叭在头盔内的位置。

开机/关机

开机/关机

双击切换中英文语音播报
(断开蓝牙)



长按3秒开/关机




开机提示音



LED灯快闪

蓝牙配对



蓝牙未连接LED灯快闪




蓝牙模式提示音



蓝牙连接成功
LED灯慢闪

灯光开启与关闭



短按切换RGB灯效模式
长按关闭RGB灯光



灯效
(每次开机RGB默认关闭)



灯光

音乐功能



短按
(音乐暂停时)



播放
(音乐播放时)



暂停
(音乐播放时)




音量-键
(音乐播放时)



短按上一曲
(音乐播放时)



长按音量减小
(音乐播放时)



音量+键
(音乐播放时)




短按下一曲
(音乐播放时)




长按音量加大
(音乐播放时)

对讲配对



对讲键



短按进入对讲模式,
再次短按退出对讲模式;




长按切换
对讲发射和接收模式;

对讲连接条件: 需一台机器处于对讲接收模式, 一台机器处于对讲发射模式, 才能进行配对。

对讲模式灯光: 绿色指示灯快闪, 进入发射模式, 并有语音提示; 绿色指示灯慢闪, 进入接收模式, 并有语音提示; 此时两台对连, 连接成功后, 栅格内指示灯已1S间隔闪烁一次, 并伴有对讲连接成功提示音, 此时就可以进行对讲通话。

首次连接: 两台机器开机后, 短按对讲键, 进入对讲模式, 此时两台机器处于同一个模式对讲接收模式, 此时需长按其中一台对讲键, 使其进入对讲发射模式, 进行对讲配对。

语音助手



(蓝牙已连接状态下) 语音助手键




双击




唤醒语音助手

物品清单


Y20Max主机*1




魔术贴安装包*1




喇叭麦克风*1



Type-C充电线*1



夹式底座*1



使用说明书*1



注意事项

1. 请勿将产品投入明火中, 避免发生爆炸;
2. 请勿拆卸产品, 避免产品电子器件损坏;
3. 请勿靠近尖锐物, 物对产品造成损坏;
4. 长时间不用, 请放置干燥处。

电话功能

双击切换手动/自动接听
(未连接蓝牙时)



(来电中)



接听



手动接听“短按”
(来电中)



接听



(来电中)

长按2秒



拒绝接听



(通话中)

通话时“短按”



结束通话



双击



未码重播




短按




取消去电

充电模式



充电时长亮



充满关闭

(开机状态下, 插入充电器, 机器自动关机)

Product overview




Important Notice:

Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Power on/off

Power on/off

Double-click to toggle the Chinese and English voice broadcast (Disconnect Bluetooth)




Power-on tone




LED lights flash

Press and hold for 3 seconds to turn on the computer

Match



Power-on tone



Bluetooth not connected LED flash

Lights on and off



Short press to switch RGB lamp effect mode long press to turn off RGB lamp off


light effect (RGB is turned off by default every time you turn on the computer)




Lights

Phone features

Double-click to toggle manual auto answering (When Bluetooth is not connected)



automatic (After 10 seconds)




(Incoming call)



Answer



Manually answer "short press"




(Incoming call)



Answer



Press and hold for 2 seconds




Refusal to answer



"Short press" while on a call



End the call




Cancel outgoing calls



Last-code replay




Double-click




Last-code replay



Short press




Cancel outgoing calls




Cancel outgoing calls

Charging mode



The charging time is long and bright



be full of extinction

(When the machine is on, plug in the Charger and the machine will shut down automatically)

Music features

Pause/play music



Short Press




(music stops)




(music playing)



(music playing)



(music playing)



Reduce volume key



(music playing)



(music playing)



(music playing)



(music playing)



Volume Plus Key



(music playing)



(music playing)




(music playing)



(music playing)

voice assistant



(Bluetooth connected) Voice Assistant Key




double-click




Wake up the voice assistant


Intercom pairing



Intercom key



Short press to enter the intercom mode, Short press again to exit the intercom mode;



Long-press toggle Intercom transmit and receive mode;


Intercom connection conditions: One machine needs to be in intercom receiving mode and one machine needs to be in intercom transmitting mode before pairing can be performed.

Intercom mode light: the green indicator blinks quickly and enters the emission mode with a voice prompt. When the green indicator blinks slowly, it enters the receiving mode, and a voice prompt is displayed. At this time, the two pairs are connected. After the connection is successful, the grid indicator blinks once at a 15 interval and the intercom connection is successful. At this time, the intercom conversation can be started.


First connection: After the two machines are powered on, short press the intercom key to enter the intercom mode. At this time, the two machines are in the same mode of intercom receiving mode. At this time, long press one of the intercom keys to make it enter the intercom transmitting mode for intercom pairing.

List of items


Y20Max Host*1




Velcro installation package*1




Speaker microphone*1




Type-C charging cable*1



Clip-on base*1



Instruction manual*1



Notes

1. Do not put the product into the open flame to avoid explosion;
2. Do not disassemble the product. Avoid damage to product electronics;
3. Do not approach the sharp object, the object will cause damage to the product;
4. Do not use for a long time, please place in a dry place.

instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.