

Y21 Quick instructions for use

Product Overviews

Next Song/Volume Up Indicator light (blue)

Play Pause/ Answer hang up Bluetooth indicator (blue)

Warning Light (RGB Lights)

Previous Song/Volume Down Indicator light (blue)

RGB Light Area

Charging indicator (red) / Charging completion indicator (green)

Power On/Off Light key

Voice assistant Mode key (Bluetooth/FM)

Speaker/Marker Connector Charging Port

Important Reminder:
Before installing the headset, please connect your mobile phone according to the quick manual guide to test the sound effect and volume.
If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

Power On/Off/RGB Lighting

Double-tap to switch language broadcasting(Disconnect Bluetooth)

Press and hold for 3 seconds to switch on/off

Boot-up beep

LED flash

Switch off by default at power on

Short press to switch RGB lighting mode

Double click to switch off RGB light

Bluetooth connection

Bluetooth waiting for pairing status LED blinking

Bluetooth mode tone

Bluetooth pairing successful LED light flashes slowly

Switch warning light on/off

Double click to switch on the warning light, Double click again to switch off the warning light

Switch off by default at power on

Warning light (RGB cycle)

Music function

Short press

Loudness+inchpin

Playable

Pause (media player)

Short press on a song

Long press volume down

Long press to increase volume

FM radio function

Short press to switch to the previous channel, Long press to reduce FM volume(in FM mode)

Double click to switch FM mode/Bluetooth mode

Long press to search stations automatically, Long press again to exit Auto search (in FM mode)

Short press to switch to the next channel, Long press to increase FM volume(in FM mode)

Short press to mute or play (in FM mode)

Telephone function

Double click to switch manual/automatic answer (When Bluetooth is not connected)

Automation (15 seconds.)

Answer the phone

Manual answer 'short press'

Answer the phone

Press and hold for 2 seconds

Decline to answer the phone

'Short press' during a call

End a call

Double click

Final code redial

Short press

Call cancellation

Charging/Voice Assistant

Red light when charging, Green light when fully charged

In the state of connecting Bluetooth, Short press to wake up The voice assistant of the mobile phone, Press again to switch off the voice assistant.

Product List

Y21 Mainframe*1

Flared-mark wind*1

Clip-on base*1

Velcro Installer*1

Type-C Charging Cable*1

User's manual*1

Caveat

- 1.Do not put the product into open flame to avoid explosion;
- 2.Do not disassemble the product to avoid damage to the product electronics;
- 3.Keep away from sharp objects that may cause damage to the product;
- 4.When not in use for a long time, please place it in a dry place;
- 5.Please fully charge your Bluetooth device before using it.
- 6.If the red light does not come on while charging, the voltage may be too low;
- 7.To extend the life of the built-in polymer battery, please charge the device at least once a month.

Warning

NOTE: This product has been tested, meet the restrictions of Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device. This device complies with Part15 of the FCC Rules. The operation needs to fulfill the following two conditions.

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.